GNARBOX User Manual

Contents

Service and Support	2
How to Contact Us	2
About The GNARBOX	3
Features	3
Tech Specs	3
File Types Supported	3
Video Resolutions Supported	4
Operating System Compatibility	4
GNARBOX Mobile App Compatibility	4
Physical Description	4
LED Indicator Behaviors	5
The GNARBOX Ports	5
SD Port	5
MicroSD Port	6
USB3 Port	6
USB2 Port	6
Micro USB3 Port	6
Safety and Handling	6
Register your GNARBOX	7
Using Your GNARBOX	7
Powering On/Off/Resetting your GNARBOX	7
Charging Your GNARBOX	7
Download/Install the GNARBOX App for your Mobile Device	7
In-App Help	7
Connecting to the GNARBOX with your Mobile Device	8
Pro Tip: Connecting Multiple Mobile Devices	8
Collection View	8

Profile Page	8
Home Page	9
Recently Imported	10
Favorites	10
Accessing & Backing up Files on the GNARBOX	10
Files located on SD & MicroSD Card or on Devices inserted in the USB 2, 3 and Micro USB3 Ports	10
Backing Up Files to the GNARBOX, Other Connected Devices, and the Cloud	11
Editing Files On Your GNARBOX	11
Editing Photos	11
Editing Video Files	14
Saving Edited Files	16
GNARDROP: Sharing/Backing up from Your GNARBOX:	16
Task Manager	16
Regulatory Compliance	17
FCC & Industry Canada (IC) Class B Information	17
CAN ICES-3(B)/NMB-3(B):	18
FCC & IC RF Exposure Statements	18
CE Compliance for Europe	18
European Union -Disposal Information	18
For Australian Customers	19
Legal	19
GNU General Public License ("GPL")	19
Notices	19

Service and Support

Should you have any issues or problems using your GNARBOX, please do not hesitate to contact us. Many questions about the GNARBOX App can be answered by using the In-App Help function. For Mobile App tutorials, visit www.gnarbox.com/how/.

How to Contact Us

When contacting us, please have your GNARBOX product serial number ready. For all inquiries please call us at (844) 462-7269 or email us at support@gnarbox.com.

About The GNARBOX

The GNARBOX is a pocket-sized device that empowers you to backup, organize, edit & share HD videos and photos, laptop free. Your purchase of a GNARBOX includes a GNARBOX, USB3 Type A to Micro B Cable and a Quick Reference Guide.

Features

The GNARBOX features:

- Lightning fast mobile back up of your photos and videos Back up 128GB of footage at up to 4GB/min to the GNARBOX, then auto-organize your footage by time, type, and GPS.
- Video and photo editing from your mobile phone or tablet Open the GNARBOX app to start editing instantly, including 4K videos to .RAW photos. Add color correction, cropping, slow-motion effects, and create highlight reels on the go.
- Easy sharing of your media Upload your media and share it with the world from the convenience of your phone. GNARBOX lets you upload in full resolution directly to your social media networks, or cloud storage.
- Ability to connect to a multiple devices (1) USB3 Type A, (1) USB3 Micro B, (1) USB2 Type A, microSD and SD ports allow you to connect any camera to quickly access and manage your content. Connect an external SSD/HDD for additional space.
- **Rugged Design** Waterproof, Shockproof, Dustproof and ready for your adventure. Never lose your best moments again.
- Long Lasting Battery GNARBOX has a 4000mAh battery, so you can use it for 4-6 hours on a single charge. Run out of juice? Recharge using microUSB.

Tech Specs

- Intel ® Quad Core, 1.92GHZ CPU
- 4 Core Intel ® HD Graphics GPU
- Dual band 300mbps 802.11 a/b/g/n Wi-Fi
- SD Card Slots and USB3.0 ports allow 100MB/sec backup speeds & 270MB/sec export speeds
- 1 AMP Out per USB
- Compatible with CF Card Readers
- 128GB FLASH Memory

File Types Supported

The GNARBOX supports these file types:

- .MP4
- MOV
- .AVCHD
- XAVC
- IVA.
- .MTS

- .JPG
- .PNG
- .RAW files

Video Resolutions Supported

The GNARBOX supports video files shot with resolutions:

- <720p
- 720p
- 1080p
- 1440p
- 2.7k
- 4k

The GNARBOX supports videos shot with frame rates of:

- 12fps
- 15fps
- 24fps
- 25fps
- 30fps
- 48fps
- 60fps
- 80fps
- 90fps
- 120fps
- 240fps

Operating System Compatibility

You can connect your GNARBOX to computers running:

- Mac OS® 10 or higher, or
- Windows® XP or higher.

GNARBOX Mobile App Compatibility

The GNARBOX App can be used on:

- iOS Devices with iOS 7.0 or higher, or
- Android Devices with Android 4.1 or higher


Physical Description

As shown in Figure 1 below, the GNARBOX has:

- A power button
- (2) LED Lights

- Behind the two doors there is:
 - o An SD Port
 - o A MicroSD Port
 - o A USB3 Port
 - o A USB2 Port
 - o A Micro USB3 Port

Figure 1



LED Indicator Behaviors

The activity of the GNARBOX LED lights are as follows:

Warning/Performance of Task	LED Action
Low Battery	LED 1 will blink red.
Very Low Battery	LED 1 will stop blinking and become a solid red.
Working on a Task	LED 1 will blink green.
Import in Progress	LED 2 will blink blue.
Auto Import Enabled	LED 2 will remain blue.
Transfer Failed	LED 2 will blink red
Transfer Successful	LED 2 will turn green.

The GNARBOX Ports

SD Port

The GNARBOX can download files from SDHC and SDXC Cards. Simply insert the SD Card into the SD Card Port, then the GNARBOX Mobile App will automatically recognize the SD Card.

The SD Port is located behind the GNARBOX door. The SD Port is labeled on the box, but should you have any issues locating the port, please refer to Figure 1 for assistance in locating the SD Port.

MicroSD Port

The GNARBOX can download files from MicroSDHC and MicroSDXC Cards. Simply insert the MicroSD Card into the MicroSD Card Port, then the GNARBOX Mobile App will automatically recognize the MicroSD Card.

The MicroSD Port is located behind the GNARBOX door. The MicroSD Port is labeled on the GNARBOX, but should you have any issues locating the port, please refer to Figure 1 for assistance in locating the MicroSD Port.

USB3 Port

The GNARBOX can download files from devices attached to the USB 3 Port. Simply insert a USB3 cord into both your device and into the GNARBOX, then the GNARBOX Mobile App will automatically recognize the connected USB3 device.

The USB3 Port is located behind the GNARBOX door. The USB3 Port is labeled on the GNARBOX, but should you have any issues locating the port, please refer to Figure 1 for assistance in locating the USB3 Port.

The USB3 Port supports only USB3 cables.

USB2 Port

The GNARBOX can download files from devices attached to the USB2 Port. Simply insert a USB2 cord into both your device and into the GNARBOX, then the GNARBOX Mobile App will automatically recognize the connected USB2 device.

The USB2 Port is located behind the GNARBOX door. The USB2 Port is labeled on the GNARBOX, but should you have any issues locating the port, please refer to Figure 1 for assistance in locating the USB2 Port.

Micro USB3 Port

The GNARBOX upload files to a host device attached to the Micro USB3 Port. Simply insert a Micro USB3 cord into both your host device and into the GNARBOX, and the host device should mount the drive in its file system.

The Micro USB3 Port is located behind the GNARBOX door. The Micro USB3 Port is labeled on the GNARBOX, but should you have any issues locating the port, please refer to Figure 1 for assistance in locating the Micro USB3 Port.

The Micro USB3 Port supports only Micro USB3 cables.

Safety and Handling

The GNARBOX is built tough and water resistant, but it is important you handle it with care. To ensure the longest life of your GNARBOX and protect your content:

1. Make sure to avoid dropping it from heights above 3 feet (1 meter);

- 2. Close all doors covering the ports when not in use to prevent dust and moisture from penetrating the sensitive electronics stored inside the GNARBOX whenever you are in an outdoor environment;
- 3. Avoid inserting or plugging any wet or dirty SD Cards into the GNARBOX ports;
- 4. Only insert compatible SD cards or cables into the GNARBOX ports;
- 5. Only charge your GNARBOX by using the provided USB cord; and
- 6. Only have a GNARBOX authorized service provider perform services on your GNARBOX.

*****WARNING: Please be advised that damage to the GNARBOX or USB Cord could result in electrical shock. If the USB charging cable or the GNARBOX is damaged in any way, please cease using the affected component(s) immediately and contact our customer service to obtain a repair.****

*****WARNING: The GNARBOX Battery is a lithium-ion battery. Impact or damage to the battery could result in fire and/or an explosion. Please DO NOT ship, mail or travel by airplane with a GNARBOX that might have suffered impact or damage to its' battery.****

Register your GNARBOX

To ensure you get the latest updates on your GNARBOX and special offers, register your GNARBOX online at www.gnarbox.com/register.

Using Your GNARBOX

Powering On/Off/Resetting your GNARBOX

- Power on your GNARBOX by pushing the Power Button once. LED 1 will remain a solid green.
- Power off your GNARBOX by Pushing the Power Button once. LED 1 will show no color (off).
- Hard Reset your GNARBOX by holding down the Power Button for 12 seconds. A Hard Reset will turn off the power and then reboot the GNARBOX.

Charging Your GNARBOX

You can charge your GNARBOX using the supplied USB cord. Plug the USB cord into a dedicated USB charging port, like the A/C adapter for your mobile phone, or a charging downstream port, which likely can be found on your computer. If your GNARBOX is powered on, you can tell the GNARBOX is charging when LED 1 remains a solid blue. If your GNARBOX is powered off, you can tell the GNARBOX is charging when LED 1 flashes blue.

<u>Download/Install the GNARBOX App for your Mobile Device</u>

You can download the GNARBOX Mobile App on the Apple Store or the Google Play Store.

In-App Help

Within the GNARBOX Mobile App, there is an in-app help function to help you learn more about all features and functions. You can access the in-app help by tapping located in the upper tool bar.

Connecting to the GNARBOX with your Mobile Device

- Open the GNARBOX App on your mobile device. To install app please see <u>Download/Install the GNARBOX</u>
 <u>App for your Mobile Device</u> above.
- 2. Power on your GNARBOX.
- 3. Follow all on screen prompts in the GNARBOX Mobile App. The prompts will direct you to connect to the GNARBOX Wi-Fi network.

Pro Tip: Connecting Multiple Mobile Devices

Up to four (4) people can connect to a single GNARBOX Wi-Fi network and work on the device simultaneously.

Collection View

The Collection View is your quick access to your entire GNARBOX Library. Along the bottom tool bar of the Collection View, you can find access to your Profile Page, Home Page, Recently Imported and Favorites.

Profile Page

Tapping the Labrings up your Profile Page. The Profile Page contains access to your:

- Updates for your GNARBOX and GNARBOX Mobile App
- Auto Import Settings
- Wi-Fi Settings
- Tutorials
- FAQs
- Contact GNARBOX
- Settings Page

Settings Page

Within the Profile Page, tap the Other to bring up the Settings Page. The Settings Page contains access to:

- Edit Profile
- Change Password
- GNARBOX Connection (GNARBOX's built in Wi-Fi)
- Social Accounts
- Cloud Storage

GNARBOX Connection: GNARBOX Wi-Fi Settings

GNARBOX Connection is the GNARBOX's built in Wi-Fi. Tapping "GNARBOX Connections" opens the GNARBOX Connections settings. Here you can name/rename your GNARBOX Network Name and set/reset your GNARBOX Network Password.

****WARNING: Only share your GNARBOX Connection password with people you trust.****

Wi-Fi Networks


You can connect your GNARBOX to Wi-Fi networks to share your files and download software updates. Tapping "Wi-Fi Networks" opens the Wi-Fi settings.

Social Accounts

You can connect your GNARBOX account with various social networks and cloud networks. Tapping "Social Accounts" opens access to directly connect your social and cloud accounts to your GNARBOX account.

Home Page

Tapping the brings you to the Home Page of your entire GNARBOX photo and video collection. The collection view contains all files you have backed up and/or saved to your GNARBOX. The files are organized according to their chronological order.



Pro Tip: File Organization


Any files you edit and save to your GNARBOX will be organized by chronological order.

Searching for Files

You can search for files on backed up to or saved to your GNARBOX by tapping the when in the Collection View. You can search for files based upon:

- 1. Keyword
- 2. File Type

- 3. Dates
- 4. GPS



Recently Imported

Tapping the brings up the files you recently imported to the GNARBOX.

Favorites

Tapping the prings up the files you marked as a favorite.

Accessing & Backing up Files on the GNARBOX

Files located on SD & MicroSD Card or on Devices inserted in the USB 2, 3 and Micro USB3 Ports

You can access any files located on any devices or cards plugged into the GNARBOX by:

- 1. Opening the GNARBOX Mobile App on your mobile device;
- 2. Going to the "Devices Page;"
- 3. Selecting the device from the list; and
- 4. Then select any file you want.

Pro Tip: Card or Device Not Appearing in List

Should your card or device not appear in the list on the Devices Page; try unplugging and then re-plugging in the device to the GNARBOX.

Pro Tip: External Hard Drives

You can connect external hard drives to the GNARBOX. The GNARBOX will automatically recognize them and include the external hard drive in your Devices list.

Pro Tip: Using SD and MicroSD Ports at the Same Time

You CAN NOT use the SD and MicroSD Ports at the same time. The SD Port takes priority and will be the only SD device visible in your Devices list until the SD Port is unplugged.

Backing Up Files to the GNARBOX, Other Connected Devices, and the Cloud

You can backup single or multiple files directly onto either the GNARBOX hard drive, any other connected device, inserted card, or connected cloud account by:

- 1. Opening the GNARBOX Mobile App on your mobile device;
- 2. Going to the "Devices Page" and selecting the device you wish want to access;
- 3. Pressing the "Select" button;
- 4. Either pressing "Select All" button or select each individual file you want to backup;
- 5. Pressing the "Copy" button; then
- 6. Select the device you want to back the file up to.

To view the files backed up on your GNARBOX, return the "Home Page." The files will be organized according to date.

To view the files backed up on a connected device, return to the "Devices" list, then select the device and find the photo.

Pro Tip: Backing Up Files To Your Computer

You can back up files to your computer by plugging your GNARBOX into your computer. Your computer will recognize the GNARBOX as if it were any other external hard drive. You can access the GNARBOX drive by using your file operating systems file viewer.

Editing Files On Your GNARBOX

You can perform a multitude of post-production edits to both your photos and video on GNARBOX.

Once you are satisfied with the changes you have applied to the file, you can save a new file to either your GNARBOX or your mobile devices camera roll by tapping "Save" in the upper right hand corner of the file preview window.

Editing Photos

To edit a photo, select the photo file you want to edit and tap "Edit" in the upper right hand corner of any video file. To the photo you can:

- Crop the Photo
- Edit the Brightness
- Edit the Contrast
- Edit the Saturation

- Apply Highlights
- Adjust Shadows
- Adjust Temperature
- Adjust Gamma
- Adjust White Point
- Adjust Black Point
- Adjust Intensity

Pro Tip: Tap to View Original Photo

You can review the difference between the original file and the edited file by tapping once on the image preview to review the original, then tapping it again to review the edits that have been applied.

Crop

You can crop a photo by tapping the .

You can either drag the cropping icon on the screen to custom crop the photo as you desire or apply pre-selected aspect ratios by tapping the .

Exposure

To adjust a photo's exposure, tap "Exposure." This will bring up a slider that allows you to adjust the exposure of the photo.

This control sets the overall image brightness. Exposure values are in increments equivalent to aperture values (f-stops) on your camera. An adjustment of +1.00 is similar to opening the aperture 1 stop. Similarly, an adjustment of -1.00 is similar to closing the aperture 1 stop.

It is a good idea to adjust a photo's exposure before changing any other tonal values.

Contrast

To adjust a photo's contrast, tap "Contrast." This will bring up a slider that allows you to adjust the contrast of the photo.

This control allows you increase or decrease the photo's contrast by affecting the photo's mid-tones.

Saturation

To adjust a photo's saturation, tap "Saturation." This will bring up a slider that allows you to adjust the saturation of the photo.

This control allows you adjust the saturation of all the colors of the photo equally.

Highlights

To adjust a photo's highlights, tap "Highlights." This will bring up a slider that allows you to adjust the highlights of the photo.

This control allows you to adjust the bright image areas of the photo.

Shadows

To adjust a photo's shadow, tap "Shadows." This will bring up a slider that allows you to adjust the shadows of the photo.

This control allows you to adjust the dark image areas of the photo.

Intensity

To adjust a photo's intensity, tap "Intensity." This will bring up a slider that allows you to adjust the intensity of the photo.

This control allows you to adjust the vividness of the overall photo.

Temperature

To adjust a photo's temperature, tap "Temperature." This will bring up a slider that allows you to adjust the temperature of the photo.

This control allows you to fine tune the white balance using the Kelvin color temperature scale. Move slider to the left to make the photo appear cooler, and to the right to warm the photo colors.

Gamma

To adjust a photo's gamma levels, tap "Gamma." This will bring up a slider that allows you to adjust the gamma levels of the photo.

You can adjust the red, green and blue of a photo with the gamma tool. You can adjust all three colors at the same time by keeping the sliders locked, or each color individually by unlocking the slider.

To lock or unlock the slider, tap "Lock Sliders." The sliders will be locked when the shows. The sliders will be unlocked when the shows.

White Point

To adjust a photo's White point, tap "White Point." This will bring up a slider that allows you to adjust the white point of the photo.

You can adjust the red, green and blue of a photo with the White Point tool. You can adjust all three colors by keeping the sliders locked, or each color individually by unlocking the slider.

To lock or unlock the slider, tap "Lock Sliders." The sliders will be locked when the shows. The sliders will be unlocked when the shows.

This control allows you to manipulate the richness of the whites in the photo.

Black Point

To adjust a photo's black point, tap "Black Point." This will bring up a slider that allows you to adjust the black point of the photo.

You can adjust the red, green and blue of a photo with the Black Point tool. You can adjust all three colors by keeping the sliders locked, or each color individually by unlocking the slider.

To lock or unlock the slider, tap "Lock Sliders." The sliders will be locked when the shows. The sliders will be unlocked when the shows.

This control allows you to manipulate the richness of the blacks in the photo.

Brightness

To adjust a photo's brightness, tap "Brightness." This will bring up a slider that allows you to adjust the brightness of the photo.

Adjusting brightness mainly affects the photos mid tone colors. Brightness should be adjusted only after you have set the exposure, black point and white point.


Editing Video Files

To edit a video, select the video file you want to edit and tap "Edit" in the upper right hand corner of any video file. In the Video Editing Screen, you can:

- Cut & Slow Mo the clip
- Crop & Rotate the clip
- Export Frames
- Add clips to your Highlight Reel
- View your Highlight Reel

Trim & Slow Mo

You can trim the length of a clip or slow motion a clip by tapping X.



Trim

To trim you can drag the markers at the end of the Timeline to set the length.

Slow Mo

You can set the start point for slow motion by tapping the Slow Mo Bar and set the end point by tapping the Slow Mo Bar.

Pro Tip: Magic Marker

While watching a video, you can swipe down on the Clip Preview to place a Magic Marker on the timeline of the clip. When you apply a trim or slow motion, the tool will jump to the magic marker. You can use the Magic Marker to set an in point and then an out point.

Light & Color

You can adjust the light and color of a clip by tapping O.

Crop & Rotate

You can crop and Rotate the frame of a video by tapping 📮.

You can either drag the cropping icon on the screen to custom crop the photo as you desire or apply pre-selected aspect ratios by tapping the .

Export Frames

You can export a frame of a clip to an image by tapping . Select the frame you want to export, then tap "Export Frames."

The Highlight Reel

You can create an edit by assembling clips of videos into a highlight reel. You can view your Highlight Reel by tapping .

Adding Files to the Highlight Reel

Once you have finished editing a clip, you can add that file to the Highlight Reel by swiping upwards on the Video Preview in the Trim & Slow Mo tool.

Deleting Files from the Highlight Reel

You can delete clips by 1) swiping down on the clip in the Trim & Slow Mo tool in the Highlight Reel Preview Pane, or 2) swiping down on the clip in the Highlight Reel Preview.

ReOrder Clips in the Highlight Reel

You can rearrange clips the by 1) dragging and dropping the clip in the Trim & Slow Mo tool in the Highlight Reel preview pane, or 2) dragging and dropping the clip in the Highlight Reel Preview.

Add Music to the Highlight Reel

You can add music to the Highlight Reel by tapping \square . The GNARBOX uses hit points to sync music with your video.

To start, set the hit point (most exciting part) of your Highlight Reel. Find your hit point by scrolling on the timeline and dropping the marker on the timeline, then tap "Next."

Next, choose your song by either 1) searching, or 2) choosing from your Playlists, Albums, Artists or Songs. After choosing your song, select the hit point of the song by scrolling through the songs timeline and dropping your marker on the timeline. Then tap "Done."

You will then be returned to the Highlight Reel. You can still edit and arrange the clips of your Highlight Reel.

Saving & Sharing Your Highlight Reel

You can save and share your Highlight Reel by tapping $\hat{\Box}$. Choose where you want to save the Highlight Reel to or where to share it using the options available.

Saving Edited Files

You can save an edited file by tapping "Save." This will automatically save the edited file to your GNARBOX. Saved files can be found in your Home Page according to the date that file was saved.

Default Settings for Photo Export

When you save a photo, it is automatically exported as a high resolution 4k .JPEG file, or if the photo is less than 4k, the photo is exported at the maximum resolution possible for the photo.

Default Settings for Video Export

When you save a video, it is automatically exported as the same format as the original file with the same specifications.

Default Settings for Highlight Reel Export

When you save a highlight reel, it is automatically saved as a 1080p 30 frames per second .MPEG file.

GNARDROP: Sharing/Backing up from Your GNARBOX:

You can share files saved to your GNARBOX to other devices or to your social media. To share your saved files:


- 1. Go to your GNARBOX Home Screen
- 2. Tap "Select" and select the files you want to share
- 3. Tap \leq to access the GNARDROP Menu
- 4. Select the device or social media account you want to share to.

Task Manager

You can view what tasks the GNARBOX is performing by tapping on the when it appears in the GNARBOX Mobile App.

The task manager provides information on:

- The status of copied or deleted files
- Whether the copying of files has failed



Regulatory Compliance

FCC & Industry Canada (IC) Class B Information

This device complies with FCC Part 15 and Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This unit generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help. Any changes or modifications not expressly approved by WD could void the user's authority to operate this equipment.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CAN ICES-3(B)/NMB-3(B):

This device complies with Canadian ICES-3(B).

Cet appareil est conforme à la norme ICES -3 (B).

FCC & IC RF Exposure Statements

The product complies with the FCC and IC portable RF exposure limit set forth for an uncontrolled environment and is safe for intended operation as described in the user manual for this product. Further RF Exposure reduction can be achieved if the product can be kept as far as possible from the user's body or if the device is set to lower output power if such a function is available.

Le produit est conforme à la limite d'exposition RF portable FCC et IC établies pour un environnement non contrôlé et est sans danger pour le fonctionnement prévu, comme décrit dans le manuel d'utilisation de ce produit . Une réduction supplémentaire de l'exposition RF peut être réalisé que si le produit peut être maintenu aussi loin que possible du corps de l'utilisateur ou si l'appareil est configuré pour réduire la puissance de sortie si cette fonction est disponible.

CE Compliance for Europe

Marking by the CE symbol indicates compliance of this system to the applicable Council Directives of the European Union, including the EMC Directive (2004/108/EC), R&TTE Directive (1995/5/EC), RoHS 2 Directive (2011/65/EU), LVD Directive (2006/95/EC). A "Declaration of Conformity" in accordance with the applicable directives can be viewed at www.gnarbox.com/eucompliance.

European Union - Disposal Information



The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection

point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

For Australian Customers

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to major failure.

<u>Legal</u>

GNU General Public License ("GPL")

Software incorporated into this product may include third party copyrighted software licensed under the GPL or Lesser General Public License ("LGPL") (collectively, "GPL Software") and not GNARBOX's Hardware End User License Agreement or App End User License. In accordance with the GPL, if applicable: 1) the source code for the GPL Software may be provided by contacting Customer Service with a request within three years of the date of your purchase; 2) you may re-use, re-distribute, and modify the GPL Software; 3) with respect solely to the GPL Software, no warranty is provided, to the extent permitted by applicable law; and 4) a copy of the GPL is included herewith, may be obtained at http://www.gnu.org. Modification of or tampering with the Software, including but not limited to any Open Source Software, is solely at your own risk. MyGnar is not responsible for any such modification or tampering. MyGnar will not support any product in which you have or have attempted to modify the Software supplied by MyGnar.

Notices

Information furnished by MyGnar is believed to be accurate and reliable; however, no responsibility is assumed by MyGnar for its use nor for any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of MyGnar.

Purchase and use of the product is subject to additional terms and conditions which can be found by visiting www.gnarbox.com/hardwareeula; and by using the product you assent to these additional terms and conditions. This product is covered by a limited warranty, the acceptance of which is a condition of sale and can be found here www.gnarbox.com/warranty. Warranty valid only when purchased from a GNARBOX authorized reseller. Total accessible storage capacity and read and write speeds vary depending on operating environment. Product specifications subject to change without notice. Pictures shown may vary from actual product. Information is subject to change without notice. All rights reserved. © 2016 MyGnar, Inc. GNARBOX is a registered trademark of MyGnar, Inc. in the U.S. and other countries.

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries.

Android is a trademark of Google Inc. Microsoft is a registered trademark of Microsoft Corporation in the U.S. and other countries.

IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Other brand names mentioned herein are for identification purposes only and may be trademarks of their respective holder(s).

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.