I. Warning

Please read the concise rules. The breach of the rules may result in danger or violation of law.

1 Safety information

1.1 Traffic safety first

Please use the mobile phone carefully when you drive a car. Park your car at roadside and then use the mobile phone if the driving condition is bad.

1.2 Turn off in hospital

Please abide by relevant provisions or regulations. Please turn off your mobile phone near medical equipment.

1.3 Turn off in airplane

Wireless equipment has disturbance to the airplane, so the use of the mobile phone in airplane is dangerous and illegal.

1.4 Turn off when refueling

Please don't use the mobile phone in gas station or near fuels or chemicals.

1.5 Turn off near blasting sites

Don't use the mobile phone in blasting sites. Please observe relevant restrictions and carry out rules or regulations.

2 Cautions on mobile phone use

2.1 Interference

All phones may be interfered, which affect phone calls.

2.2Reasonable use

Use only in the normal position. Do not touch the antenna area unnecessarily.

2.3 Qualified maintenance service

Only qualified personnel may install or repair this product.

2.4 Water-resistance

Your device is not water resistant. Keep it dry.

2.5 Emergency calls

Ensure the phone is switched on and in service. Enter the emergency number and press the Dial icon.


3 Precautions for use of battery

- 3.1 Do not dispose of batteries near or in a fire to avoid dangers.
- **3.2** Do not dispose of batteries in the garbage. Dispose of batteries to assigned battery recycling center.

4 Cautions for children

Keep your device out the reach of children in case of accidental injury caused by incorrect use of the device as toys.

II. Keys and parts



► Home key

Press Home key at a non-standby screen to go back to standby screen

Volume key

Press Volume key to change the volume.

Menu Key

Press Menu key to enter wallpapers, hide apps, widgets, settings.

Back Key

Press Back key to go back to previous menu.

Power Key

Short press on the Power key shall lock the screen and a long press on the Power key shall switch on/off the device.

III. Start to use

1 Insert SIM card

The phone is a Dual SIM mobile phone allowing you to use the facility of two networks. To insert SIM card(s):

- 1. Switch off the mobile phone and remove the rear cover and battery.
- 2. Insert the SIM card correctly in the card slot(s)
- 3. Finally insert the battery and replace the rear cover of the mobile phone.

2 Insert Memory card

- 1. Power off the mobile phone and remove the rear cover and battery.
- 2. Insert the Micro SD card into the slot.
- 3. Finally insert the battery and the rear cover of the mobile phone.

Note: Use only compatible memory cards for use with this device. Incompatible memory cards may damage the card or the device and corrupt the data stored in the card.

3 Charge the battery

During charging, the battery indicator on the phone is a thunder icon. If the device is switched

off during charging, there will still be a charging indication on the screen that shows the phone is being charged. If the device is overused —when the battery is low, the charging icon might take some time to appear.

When the battery indicator on the screen says' charged', thunder icon will disappear, which means the completion of charging. During charging, the battery, the device and the charger will get hot. This is normal.

Unplug the charger from the AC electrical outlet and disconnect the wiring between the phone and the charger after charging. .

Cautions: Charge the phone in a well ventilated place in which the temperature is between -10℃ to +55℃. Use the charger provided by the manufacturer only. The use of unconfirmed charger may lead to dangers and violate the manufacturer's warranty clause. If the temperature is too high or too low during charging, the device will automatically send a warning and stop charging to avoid damage to the battery or any danger.

FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Specific Absorption Rate (SAR) information:

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value"

Before a new model phone is a available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this model phone has been tested and meets the FCC RF

exposure guidelines when used with an accessory designated for this product or when used with an accessory that Wontains no metal and that positions the handset a minimum of 10mm from the body. Non-compliance with the above restrictions may result in violation of RF exposure guidelines

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.