

Label Position

iSDR

Status: 14.09.2016

Revision 2

Author: Dr. Matthias Rabel matthias.rabel@indurad.com

To whom it may concern:

The label is placed on the bottom of the device.







iSDR-DN150



