that it is recycled in a manner that protects human health and the environment.

I his symbol means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure





including interference that may cause undesired operation. Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received,

warranty.

Ultimation One-Year Limited Warranty Summary
Ultimation warrants the included hardware product and accessories against defects in materials and
Workmanship for one year from the date of original retail purchase. Ultimation does not warrant against
normal wear and tear, nor damage caused by accident or abuse. To obtain service, visit www.talelight.tech.
Subject to the full terms and detailed information on obtaining service available at www.talelight.tech.

terms-and-conditions. If you submit a valid claim under this warranty, Ultimation will either repair, replace,
or refund your Talelight at its own discretion. Warranty benefits are in addition to rights provided under local
or refund your Talelight at its own discretion. Warranty benefits are in addition to rights provided under local





Thank you! Here is your new **Talelight: The Slicker Bumper Sticker**

Ambient light sensor

Taleight
The Slicker Bumper Sticker

Welcome to the World's First
Electronic Bumper Sticker!

Register your Talelight Display at Talelight.tech
using Hardware ID: 12345678
Install the Talelight App onto your smartphone.
Connect to your Talelight display with your Talelight App.

Welcome to **Talelight**: Let's get started!

1/ Wake up your Talelight. Your Talelight will wake up on its own as soon as you power it with a standard micro USB adapter or when you press the multifunction switch on the lower left side of the display. If it does not, charge it for ~45 minutes using a standard 5-volt USB charger. When it wakes up, simply follow the on-screen instructions.

2/ Register your device. Go to www.talelight.tech and create a user account. Once your account is created, login, access the Devices menu and add your Talelight to your account by entering your Talelight Hardware ID, which is shown on the first welcome screen. The Hardware ID is also the last 8 digits of the serial number printed on the labels on the side of the box and on the back of the Talelight display. It looks similar to this: 12345678.


3/ Create your bumper sticker library. You can purchase - or upload your own - bumper stickers through the www.talelight.tech Sticker Store. Purchased or created images are stored in your Library. From there, choose which sticker(s) you want to showcase and then go to the View Schedule page to program how it/they will be displayed on your Talelight. You can set up a simple rotation of your images or choose a specific date and time for each image to be shown.

4/ Install the free Talelight App on your phone. The Talelight app is available for iPhone and Android based smartphones. Search for "Talelight" in the Apple App Store or on Google Play. You will use the app to synchronize your Talelight display with your website account.

5/ Install your Talelight. Your Talelight device should be mounted on your vehicle with the provided gray adhesive pads. Depending on the surface curvature of your vehicle, cut and place the pads either on the sides or the top and bottom of the Talelight display as shown in the illustration to the right.

6/ Power your Talelight. The Talelight has an embedded battery which will power the display even if your car is off. The provided USB cable is used to supplement and recharge the battery. Run this cable between your Talelight and your vehicle's USB port or a cigarette lighter to USB adapter, we recommend an adapter with 2A or better current rating. Use the provided clear tape strips to secure the cable.

7/ Get support. For support on how to operate your Talelight, create your account, download or create your own images. FAQs and more, visit www.talelight.tech.







Your Hardware ID is here (8 last digits of serial number)



Side-mounted adhesive pads



Top-down adhesive pads



USB cable routed to your car's internal connector, either a USB port or a cigarette to USB adapter.