


BLUETOOTH HEADSET • USER MANUAL

Introduction

Thank you for choosing uvoks wz, Bluetooth headset. This manual will show you how to operate it, but you'd better familiarize yourself with the Bluetooth function of your mobile phone or other devices before hand. Please read the manual carefully, and keep it for future



Accessories List



1 × USB charging cable







6 × Closed ear tips(suitable for listening to music)



4 × Semi-closed ear tips(suitable for making phone calls) (normally the medium ones are suitable for 75% of people).

Wearing Your Headset



Push the headphones into your ears gently to get the best sound quality.

Getting Started



The headset will directly go into pairing mode the first time you turn it on, otherwise you will need to long press MFB until the indicator light flashes blue and red alternately to enter pairing mode.

■ HVOKS W2

Activate the Bluetooth function of your mobile phone, search for

Charging Your Headset

- 1. The indicator light will flash red when the battery level is low, and
- 3. The indicator light will turn red when charging, or blue when fully
- 4. Use only chargers approved by UVOKS, the use of any other chargers may invalidate the warranty, and may be dangerous.
- 5. Repeated charging and discharging of the headset will cause the degradation of the battery performance. This is normal for all rechargeable
- 6. If left unused, a fully charged battery will lose its charge over time, If the headset has not been used for over three months, please

General Functions

Function	Operation	
Power on	Press MFB for 1 second when the headset is off	
Power off	Press MFB for 3 seconds when the headset is on	
	or standby	
Enter pairing	Long press MFB for 6 seconds when the headset	
mode	is off	
Play/Pause	Press MFB to pause when playing music, press	
	again to resume playing	
Volume up/down	Short press "+" / "-" when playing music or	
	during a call	
Next/Previous	Long press "+" / "-" when playing music	
Answer a call	Press MFB once when there's an incoming call	
End a call	Press MFB once during a call	
Reject a call	Press MFB for 1 second when there's an	
	incoming call	
Redial the latest outgoing call	Double press MFB when the headset is standby	
USB sound card	Plug the USB cable between UVOKS W2 with	
	PC,earphone can hear the sound from PC	

The indicator light and voice prompt give a good indication of what

LED Indicator	Voice Prompt	Status of Headset
Flashes blue	Power on	Power on
Remains red for 2 seconds	Power off	Power off
Flashes blue and red alternately	Pairing	In pairing mode

Pairing

Pairing will create a unique wireless link between the headset with your Bluetooth device. If your headset was previously paired with a mobile phone, within operating range, they will automatically connect to each other when turned on in future; if with a computer, simply select "connect to audio device" will reconnect them in future.

Pairing with Your Computer

- and select the "search for Bluetooth devices" menu.

4. Once the headset is found, "UVOKS W2" will be displayed in the devices list, select it, right click and select "pair with this device". 5. Select "UVOKS W2" again, right click and select "connect to

Pairing with Your Mobile Phone

- Bluetooth headset (refer to the phone's User Manual).
- Select the name to connect.
- 5. When prompted by your phone to confirm this pairing, select OK

Multi-point Connection

Which allows you to connect it to two different Bluetooth devices at

- 1. Follow the pairing procedure to connect the headset to Device 1.
- 2. Turn off the headset, Follow the pairing procedure to connect the
- 3. Select "UVOKS W2" from the Bluetooth devices list on Device 1 to finish multi-point connection.

When you are already on a call, if there's an incoming call on the other phone, press MFB to answer the 2nd call and put the 1st call on hold.

Technical Specification

Bluetooth Version	V4.1	
Bluetooth Profile	A2DP, AVRCP, HFP, HSP	
Chipset	CSR8645	
Audio Codec	apt-X	
Noise Reduction	CVC 6.0	
Standby Time	180 hours	
Play Music	7~8 hours	
Charging Time	2 hours	
Dimension (L*W*H)	36*30*45mm	
Operating Range	33 ft/10m	
Weight	13g	

Safety Rules

- 1. Never disassemble or modify your headset for any reasons since are excluded from our warranty cover.
- 2. Keep the headset dry. Damage caused by liquid is also excluded
- 4. Do not use this headset during a thunderstorm. It may cause the irregular work of it and increase the risk of electric shock.
 - 5. Do not use harsh chemicals or strong detergents to clean the

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna.

- --Increase the separation between the equipment and receiver.
- --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device is measured RF output power is less than the SAR exclusion threshold value for human head and body. Therefore, SAR test is not necessary