
OKIN	Issue department: Bedding Division	Date:	2018-12-27
	ProductFunction	Author:	Allen
REFINED A Phoenix Mecano Company	instruction	No: MC210	
MC210		Version:	1.0
		Page 1 of 2	

MC210 Function instruction

1. Electrical configuration diagram:



2. Function Picture



OKIN REFINED	Issue department: Bedding Division	Date:	2018-12-27
	ProductFunction instruction	Author:	Allen
		No: MC210	
A Phoenix Mecano Company			
MC210		Version:	1.0
		Page 2 of 2	

1. Process of test

1.1. MOTOR port

Connect to head actuator, control by remote single:

Click head up button on the remote, head actuator moves out, stop when released;

Click headdown button, head actuator moves in, stop when released;

This function takes effect only by pressing the corresponding button on the remote.

1.2. SYNC port

Connect with the same other Control box or Other accessories;

1.3. Power LED

Power supply for control box, POWER LED turns on .

1.4. AC Power

Connect to the 220V AC;

1.5. Pair Function

Power up control box, pairing LED will be flash, the control box enters into mode of code paring;

Press and hold the paring LED of Remote, the backlight of paring LED flashes, the backlight of remote flashes, the remote enters into mode of code paring;

The backlight of paring LED of remote stops flashing, and the paring led of control box stop flash, it indicates that the code paring is successful;

If fails, repeat all the processes above;

OKIN REFINED	Issue department: Bedding Division	Date:	2018-12-27
	ProductFunction instruction	Author:	Allen
		No: MC210	
A Phoenix Mecano Company			
MC210		Version:	1.0
		Page 2 of 2	

FCC Warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

ISED RSS Warning:

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ISED RF exposure statement:

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Le rayonnement de la classe b repecte ISED fixaient un environnement non contrôlés. Installation et mise en œuvre de ce matériel devrait avec échangeur distance minimale entre 20 cm ton corps. Lanceurs ou ne peuvent pas coexister cette antenne ou capteurs avec d'autres.