
说明书, 材质: 牛皮纸, 正反面印刷, 成品对折80*100MM

Archeer Wireless Home Stereo Model:A320



User Manual

Product Features:

- 1. Elegant Appearance: Premium furniture grade bamboo-made front baffle, rear trim & deluxe rewind fabric covering
- 2.Double Connection Options: Fire up your euphonious tunes wired or wirelessly via Bluetooth or included
 3.5mm audio cable
- 3.Excellent Combination: Built with 2 clear tweeters and 1 powerful subwoofer to pump out stereo & stunning audio performance
- 4.Gorgeous Interior Ornament: Fits your dining table, nightstand, countertop, secretaire, bookshelf and coffee table as an exquisite indoor decoration


Package Contents

- 1x ARCHEER A320 Home Speaker
- 1x Micro USB Charging Cable
- 1x 3.5mm Audio Cable
- 1x User Manual

Specifications:

Product Model	A320
Bluetooth Version	4.0
Rated Power	5W*2+15W*1
Signal-Noise Ratio	Treble≥80dB; Bass≥75dB
Frequency Range	80Hz—20KHz
Battery Capacity	2600mAh/7.4V
Playback Time	7Hours
Charging Time	3.5-5 Hours
Operating Range	10 M/33 Ft
Dimensions	250*130*80MM
Net Weight	1. 4kg
	•

Structure Introduction:



- 1 Vol-(Previous track)
- 2 Vol+(Next track)
- (3) Play/Pause
- Power ON/OFF (SwitchMode)
- (5) Aux-in Port
- (6) RESET Button
- (7) Power Indicator
- (8) Charging Indicator
- O 3 3
- (9) Charging Port

Method of Use:

Power ON/OFF

Press the power button for 3 seconds to turn ON/OFF the speaker.

Pairing

- On first use, press and hold the power button for 5 seconds, the constantly flashing GREEN LED indicates that the speaker is ready for connecting.
- 2.Enable the Bluetooth function on your Cellphone or tablet; search and click "A 320" to establish connection; the slowly flashing BLUE LED stands for the connected status.
- 3.The speaker automatically turns OFF when there isn't an active Bluetooth connection within 10 minutes.

Playback Control

- 1.Open the music APP on your Cellphone or tablet; press the ►II button to play/pause the music.
- 2.Press the"—, + "button to adjust volume; press and hold the"—, + "button to skip to the previous/next tune.
- 3.Short press the power button during the playing period to switch between Bluetooth and Aux mode.
- 4.The playback control can be either operated on the stereo or on your phone.

Aux-in

- 1.Turn ON the home stereo and plug one end of the 3.5mm audio cable into the Aux-in port;
- 2.Plug the other end of the audio cable into the 3.5mm headphone jack of your Cellphone or tablet;
- 3. Open the music APP on your Cellphone or tablet to start music playing.
- 4.The stereo will detect and preferentially switch to Aux-in mode ONLY if the 3.5mm audio cable is plugged after startup.

How to Recharge

The dimming sound output indicates that the battery is in low or critical status. Under such circumstance:

- 1.Depress the power button to turn OFF the stereo;
- 2.Recharge the stereo via PC or a 5V DC adapter (NOT Included) with the included Micro USB cable;
- 3.The rear RED LED will light up during the charging period and will extinguish when fully charged.
- 4.Unplug the charger once you have finished charging the home stereo.
- 5.The charging speed may vary due to the different power input; in order to have a higher charging speed, we strongly suggest that you use a 5V/2A DC adapter.

Reset

If the home stereo cannot operate properly, the rear RESET button can help restoring to factory settings.

FAQ

- 1.My phone has been connected to the home stereo, why can't I hear any sound?
- a.Press the + button on your speaker or turn up the volume on your connected device.
- b.Make sure the music app is opened and press the MI button on your phone or the speaker to start your music.
- 2.Why can't my phone/tablet connect to the home stereo?
- a.Check to make sure the Bluetooth function is enabled on your phone.
- b.Check the battery status of the speaker and recharge it with an adapter.
- c.Use the RESETbutton to reset the home stereo and retry the pairing process.

Warranty

Guarantee by Archeer. Our company provides customers with 18-month warranty and 40 days money back guarantee since the date of purchase.

For any inquiries or comments concerning our products, please feel free to send email to service@archeer.com, we appreciate your constructional ideas and will respond to you as soon as possible.

Statement

We're only able to provide after-sales service for purchases made directly from Archeer. If you purchased from a different retailer, Please contact them for any exchange or refund requests.

Contact Us

Email:service@archeer.com Official Website:www.archeer.com



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.