Bluetooth headset should be used with the compatible devices which supports Bluetooth wireless technology. This allows you the freedom to make any calls and enjoy the music streaming any time.

Please read this user manual carefully before using the earbuds, and also read your device's user manual regarding the Bluetooth function, and pay attention to those important safety and maintenance information.

Please keep the earbuds away from children.

Specifications

| uetooth Specification | V4.1 |
|----------------------------|-----------------------|
| uetooth Profiles Supported | Headset, Handsfree, |
| | A2DP,AVRCP |
| ansmission Power | Class 2 |
| peration Range* | Up to 10 Meters |
| equency Range | 2.402~2.480GHz |
| attery | Built-in Rechargeable |
| | Li-polymer Battery |
| narging Voltage | DC4.75-5.25V |
| narging Time | About 2 hours |
| usic Playing Time* | Up to 6 hours |
| Ilking Time* | Up to 8 hours |
| andby Time* | Up to 200 hours |
| mensions | 23x17x14mm |
| eight | 10g/pair |

*May vary due to user's operation mode and device settings. 02

Basic Operations

Charging Your Headset

Prior to using the earbuds for the first time, the battery needs to be fully charged. Approximately 2 hours are required to fully charge the earbuds.

The indicator light turns red while being charged, and will turn blue automatically after being fully charged.

When the earbuds is running out of battery, the indicator light will flash red and voice prompt (the headset will switch off automatically when the battery is drained).

Please charge the earbuds as above steps in time to prolong the battery's life (Charging indication will be delayed for a few minutes if the headset has not been used for a long time or the battery is drained).

Note Not

O Do not attempt to force open the built-in battery as this could damage the earbuds.

 ∩ If left unused, a fully charged headset will lose its power automatically. It is recommended to charge the earbuds every three months.

O Do not leave the earbuds in a too hot or too cold condition which may affect the earbuds' operations.

Do not dispose of the earbuds into a fire or water.

Turning on the earbuds

In OFF MODE, press and hold MFB for about 3

seconds until hearing a short beep and the indicator light flashes blue, then the earbud will enter into STANDBY MODE.

04

Turning off the earbuds

In ON MODE, press and hold MFB for about 3 seconds until hearing a short beep and the indicator light flashes red, then the earbud will enter into OFF MODE.

Mate your earbuds and pairing with a Bluetooth Mobile Phone

- 1. Ensure both earbuds are off, the distance between the two earbuds, and your earbuds to the phone is within 1 meter.
- 2. Press and hold MFB for about 5 seconds until the indicator light flashes blue and red alternately as PAIRING MODE.

05

HOW TO PAIR

- 1. Press the MFB button for 5 seconds, until the light flash blue. voice prompt from both earbud "POWER ON"
- 2. Left and Right earbud will pair each other automatically in seconds, and voice prompt "CONNECTED"→"LEFT CHANNEL"/ "RIGHT CHANNEL"→"PAIRING"
- 3. Only the left earbud flash blue light, means they are ready to pair with mobilephone:
- 4. Open the mobilephone bluetooth, and searching, find SBT299, click it. voice prompt "PAIRING SUCCESSFUL"→"CONNECTED





KOV

SBT299R Bluetooth Stereo MATEarbuds User Manual FCC ID: 2AKERSBT299R



HOW TO WEAR

Adjust the earbuds to a suitable angle, confirm it is stable

- 3. The earbuds will find each other automatically to discriminate Left and Right channels then paired automatically
- 4. Activate the Bluetooth function on the phone: search Bluetooth devices (See the user guide of your phone for instructions).
- 5. Select headset "SBT299" from the found devices list of the phone.
- 6. Enter the passkey "0000" if requested; confirm to pair the earbuds with your phone. The headset enters into the STANDBY MODE, the indicator light circles
- 7. Ensure the distance between the earbuds and phone is within 10 meters, and without any obstacles. You can use the headset freely.
- 8. If the earbuds had paired with your phone but disconnected, it will paired automatically again when turns on within operation range.

✓!\ Note

Prior to pairing with your phone, need the two earbuds to be paired themselves, then pair it to your phone, otherwise you can only use 1 earbuds solely.

Answering/Ending a Call

♠ Press MFB once

Rejecting a Call

Press and hold MFB for 2 seconds

Voice Dialing

♠ In STANDBY MODE, press and hold MFB and say the voice tag as soon as you hear prompt (ensure your phone supports voice dialing function, and you have recorded the voice tag into your phone. See the user guide of your phone for instructions). 07

Last Number Redialing

ODouble Press the MFB under standby mode.

Adjusting Volume

Please adjust the volume from your phone

Play/Pause

Press MFB button once for music playing and press again to pause

Forward/Backward

Please operate via your phone

Disconnecting

To disconnect the paired earbuds from your phone, please turn off the earbuds or disconnect the headset from the Bluetooth menu of your phone.

08

Please adjust the volume from your phone Play/Pause

Ress MFB button once for music playing and press again to pause

Forward/Backward

Please operate via your phone

Disconnecting

To disconn ect the paired earbuds from your phone, please turn off the earbuds or disconnect the headset from the Bluetooth menu of your phone.



Due to the power consumption difference, when the Left earbud power drain, the right one may remain power, it is

You now can pair the right one to your phone for music playing and phone talk

Care and Maintenance

Do not use abrasive cleaning solvents to clean the

Do not allow the earbuds to come into contact with sharp objects and this will cause scratching and

Be sure to store the earbuds in a dry place, free from extreme temperatures, humidity and dust.

Additional Statements

The earbuds is compliant with the specified Bluetooth version. It does not guarantee compatibility of all functions on every Bluetooth enabled device. Please check your device's user manual for compatibility and functionality.

The above operations may vary due to different

Manufacturer reserves the right to final explanation of all the above statements



http://kovwireless.com/

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.