i7 Wi-Fi external SSD User manual

INDEX

- 1. Product Description
- 1.1 Product Features
- 1.2 Interface
- 2. Wireless Mode
- 2.1 Internet Connection Mode
- 2.2 USB Mode
- 3. Operating System
- 3.1 For Windows
- 3.2 For IOS
- 3.3 For Android
- 4. Service Setting
- 4.1 DLAN Service
- 5. External Solid State Drive Function
- 6. Power Bank Function
- 7. Note
- 8. Specification


1.Product Description

1.1 Product Features

- 1) Wifi802.11b/g/n technology, built in mSATA SSD, supporting multi-system(Windows,Mac,IOS,iPad,iPhone,iTouch,Android); To resolve all short storage issue for smart phone and pad; Supporting multi users to connect all smart devices and sharing.
 - 2) Two internet connection ways, wireless and RJ45 port;
 - 3) Type-c USB 3.1 port to connect PC directly with high speed.
- 4) Built in 2250 mah rechargeable Lithium Ion polymer battery, up to 4 hours working time and 8 hours standing time.

Use USB HOST port to emergency charge for your device.

1.2 Interface



| Interface | details |
|--------------------|--|
| power button | Keep pushing 3 seconds to ON/OFF. |
| | It only can be used as usb3.1 external ssd through USB3.1 port |
| | when power off. |
| USB3.1port | The battery only can be charged through USB3.1 port when |
| | power on. |
| reset button | Keep pushing 3-5 seconds to restore factory default setting. |
| | RJ45 plug(not included) to connect internet |
| USB host port | 5V1A charge-discharge, supporting U-disk |
| | Green Color Lighting: More than 30% available power Slow flashing(every two seconds): Battery charging Slow flashing(every seconds): Shutting down |
| Power LED: | Red color |
| | Flashing: Less than 30% more than 10% available power |
| | Fast flashing:Low power, please charge it immediately |
| | |
| | LED off: Power off |
| | USB mode: |
| | A. White LED: Lighting:USB 2.0 port connected |
| Read and write LED | B. White LED: |
| | Flashing: USB 2.0 port reading/writing |
| | C. Blue LED |
| | Lighting: USB 3.0 connected |

| | D. Blue LED |
|---------------|---|
| | |
| | Flashing: USB 3.0 port reading/writing |
| | Wireless mode |
| | A.White LED |
| | Lighting: SSD connected |
| | B.White LED |
| | Flashing: reading/writing |
| | Note:LED will be turned off under SSD sleeping mode. It will be |
| | turned on after SSD awaked. |
| | Blue LED: Flashing: Normal detection when power on, stop flashing when initialization process completed |
| | 2 . Blue LED |
| | Lighting: Wi-Fi signal detected. |
| Wi-Fi LED: | |
| | 3. LED OFF |
| | A. Wi-Fi signal not stable |
| | B. Power off |
| Internet LED: | A. Blue LED |
| | Lighting: Internet connected |
| | B. LED off: No internet connection |

2. Wireless mode

2.1 Internet Connection Mode

Two internet connection ways, wireless and RJ45(not included) port wired.

A.RJ45 wired

Connect internet through RJ45 port(not included), then use i7 as a router

B.Wireless Mode.

Connect internet through wi-fi signal, then use i7 as a router and repeater



2.2 USB Mode

Power off i7, it only can be used as normal external ssd,no more functions.

3. Operating System

For example: windows,IOS,Android

Install client app(irecadata) on your computer/pad/cellphone before using i7.

The app can be downloaded from our official website or IOS APP store/ android market.

3.1 For Windows

Make sure:

1.Computer has normal wi-fi function.

2. i7 power on

3.1.1. Lan Connection


Searching wi-fi signal from i7, it named irecadata, select it.

Note: The lan is only between computer and i7, it's nothing to do with internet.



3.1.2 . Web Management Interface

Open a browser, enter the IP address 10.10.10.254 to get log in page.



Type default User Name:admin. No password required this time.




A. Setting:


Setting page included network setting (i7 connects to the internet), wireless

LAN setting (to define the encryption type and wifi name), user setting (to define


web login password and the guests' password), DLNA/Samba service setting (time

setting, firmware upgrading, default resetting) and device information.










| Item | description | |
|-------------|--|--|
| SSID | Define new name | |
| Mode | Switch internet mode | |
| Security | Select security mode and set up password | |
| Mac address | Display mac address | |
| IP address | Default IP address:10.10.10.254 | |
| Mask | 255.255.255.0 | |
| Region | Select your country | |
| Channel | Auto,1-13 | |


A.User management page, to define log in password.


Note: Please restart i7 after any change.



B. File Explorer







3.2 For IOS

For example iphone

3.2.1 Install app

A . Download app from APP store for free,please searching "irecadata" .



3.2.2 Access i7 via app

Iphone setting--wifi setting--find iRecadata-xxx--click it(no password)--back to desktop--find app and click it



下午6:24


56% 💷


RECADATA 安徽 个人大数据中心












B i7 connects to the internet

App--system--WiFi_Disk Setting--Internet Setting--Configure your network

| Item | | description |
|---------------|--------------------|---|
| | WiFi Settings | Set up SSID,Channel,Mode,Security |
| | LAN Settings | Mac address,IP address, Subnet Mask |
| WiFi_Disk | Internet Select in | Select internet acess mode. |
| Setting | Settings | Configure your network |
| | System | User, Host Name, Disk information, Firmware upgrade |
| | Settings | |
| Guest user | On/Off guest user | |

| Cache | CPU cache | |
|-----------------------------------|---|--|
| Language | Set up language | |
| About | Company/Firmware/Version information | |
| Third party open setting | The default third-party software | |
| Log out | Log out. If you want log in again, please go back main page and click | |








图 4 图 5





3.3 For Android

For example: Huawei

3.3.1 Install app.


Download app from android market for free. Or, scan below picture






3.3.2 Access i7 via app

Cellphone setting--wifi setting--find iRecadata-xxx--click it(no password)--back to desktop--find app and click it




4. Server Setting

Path: Web log in page--Setting--Server--DLAN/SAMBA



4.1 DLAN




For example: Android device

Please make sure that our device is enable to launch DLAN.

If yes: Connect i7, select video/music/picture, you will find an icon on right side.

Push it, App will searching for existed DLAN device automatically. Then select your DLAN device after that.



5. External Solid State Drive Function

i7 only can be used as normal external SSD when power off.

6. Power bank function

Built in 2250mAh battery, it can be used as normal power bank to charge device via USB port.



Note: Input/output: 5V 1A

7. Note

A.client app dowload and upgrade path: www.irecadata.com

B. Website: www.irecadata.com

C. Customer server number: +86 0755-21009070

E-mail: supports@irecadata.com

8. Product specifications

Brand name: iRecadata

Model: I7

Condition: Brand new with package Interface: Wifi & USB 3.1(GEN1 type-c) Storage Capacity: 128GB/256GB/512GB Features: File Encryption Function

Color: black/white

Memery: Highest grade NAND Flash Size: 100x67x12mm, 4.3" x 2.6" x 0.5,

Weight: 100g, 3.5oz

Package includes: 1x external SSD, 1x User manual, 1x USB cable, 1x

warranty, 3 years warranty

Log in IP: **10.10.10.254**

Log in user name: admin

Password: No password required

Wi-Fi password: No password required

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.