#### **Function Introduction**

Bluetooth Version: AIROHA Bluetooth 4.1 (Bluetooth V4.1 Not includ BLE function)

This product supports Profiles:

- HFP V1.6 wideband speech(HD voice ready)
- ■HSP V1.2
- A2DP V1.2
- ■AVRCP V1.0

Effective distance: 10metres Work frequency: 2.4GHz ISM

Rated power: 4mW Maximum power: 6mW

Battery: 3.7V/85mAH Lithium Battery

Operating Current: 20mA Standby current: <50mA Charging Voltage: 5V

Charging Current: 60mA

# Support multi-point connection (simultaneous connection of two mobile phones)

Two mobile phones, one headset, a key to answer the call.

# Support voice report number

When phone call coming, automatic report telephone numbers to avoid important telephones.

E.g. "1" "0" "8" "6" phone call coming.

# **Support voice reminding function**

Real-time report to users the status of the Bluetooth earphone, handle skillfully.

E.g.: "Bluetooth is power on", "Bluetooth is power off".

iPhone: power consumption display function:

Display Bluetooth headset power on iphone, in order to consider whether need to charge the headset.

# TAKE A LOOK

- ◆Calls and streaming audio
- Take a call or end it (1 tap)
- Redial last telephone number (2 taps)
- •Use phone's voice-control feature to make a call

(2-second press until tone is heard)

- Play or pause audio (1 tap)
- ◆Micro USB charging port (control panel)
- 1hour before first use (LED is red until fully charged)
- 1.5~2hours for full charge
- ◆Power, pairing and tracking
- Power On & Pairing: Long Press the Power button for 5-7 seconds until red and blue lights flashing alternately activate pairing mode (Please do not loosen the button until red and blue light flashing alternately.)
- Power Off: Long Press the Power button for 5-7 seconds until red light flashing.

- Track Previous song: Press VOL+ (1 tap)
- Track Next song: Press VOL- (1 tap)
- ◆ Volume, selfie and mute
- Volume up and down (Long Press the volume + / Volume button for 2 seconds, add up the volume a maximum sound, a warning sound)
- Selfie: Double-Click on VOL+

#### **GET CONNECTED**

#### 1. Ready

First time, right out of the box:

Activate Bluetooth pairing mode by pressing Power/Pairing button on for 5~7seconds. The LED flashes red/blue to indicate pairing mode. Pairing new phone/reconnecting original:

With earbuds turned off, press Power/Pairing button until the LED flashes red/blue.

### 2. Set

Activate the Bluetooth feature on your device, then use phone menus to "add", "search" or "scan" for new Bluetooth devices.

Phones have different menus to select from:

iPhone: Setting > Bluetooth > On (starts the search for devices)

BlackBerry ® Smartphone: Settings/Options > Bluetooth: On > Search for devices

Android <sup>™</sup> Smartphone: Settings Bluetooth: On > Scan for devices

### 3. Connect

Select "Bluetooth" from the list of Bluetooth devices shown on your device.

If device asks for a passcode, enter four zeros (0000).

Some devices also ask to confirm connection after pairing.

The earbud's LED will stop flashing red/blue once successfully

paired/connected.

You can now make a call using your device's keypad or voice-dialing feature and enjoy audio listening from your device.

### **LEARN MORE**

# Stay near your device:

Bluetooth has a working "range" of up to 33 feet between your phone and earbuds before audio degrades and the connection is lost. For best audio reception, keep your phone on the right side of your body.

## Use your voice:

Some smart phones allow you to use voice commands to activate their features, such as voice-dialing or playing music.

To activate your smart phone's voice controls, press the Call/Audio button until you hear your phone prompt you for a command.

#### Never miss a call:

You will hear an incoming call alert while listening to stored or streaming audio. When you take the call, your stored or streaming audio will pause.

If you are listening to live streaming audio (Internet radio) then it will mute, not pause, during your call. Once you end your call, your playback or streaming will resume.

## **Check the battery level:**

If you are on a call or listening to audio you will hear a tone when the battery is low.

You can check the battery level by tapping the Power button. The LED flashes to show the charge level.

Blue flash = battery OK to full

Red flash = less than 15 minutes call time remaining

### ◆FCC Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.