MacDonald Humfrey's Hand held HF Tag Reader



Ergonomic Design

Simple Status

Indication
Single button
Operation

RFID Scanner Connection to PC via USB 1.1



RFID Scanner – Housing



RFID Scanner – LED Status Indication



To read a tag, with the scanner in Idle mode, hold the scanner head parallel to the RFID Tag and press the orange trigger button.



Powering on LED flashing amber



Good Read - LED indicates steady amber accompanied by a single long duration beep




LED Steady Green - Ready / Idle Mode



No Tag Read - LED indication flashes red accompanied by a multiple short duration beeps


RFID Hand Scanner – Access to internal components



RFID Scanner Main Circuit Board



RFID Scanner Main Circuit Board Rear View



RFID Scanner Circuit Board (Scanner Head)

