MacDonald Humfrey's Hand held HF Tag Reader



Ergonomic Design

Simple Status Indication

Single button Operation

RFID Scanner Connection to PC via USB 2.0



RFID Scanner – Housing



RFID Scanner - LED Status Indication



To read a tag, with the scanner in Idle mode, hold the scanner head parallel to the RFID Tag and press the orange trigger button.



Powering on LED flashing amber



Good Read - LED indicates steady amber accompanied by a single long duration beep




LED Steady Green - Ready / Idle Mode




No Tag Read - LED indication flashes red accompanied by a multiple short duration beeps

RFID Hand Scanner – Access to internal components



HF RFID Scanner Main Circuit Board SC01077-01_iss1-2



HF RFID Scanner Circuit Board (SC01077-02_iss1-2)

