# UGREEN®

Bluetooth audio adapter

MANUAL
PID:30444/30445

English

Thank you for purchasing the Ugreen products. For optimum operation, please read this manual carefully before use.

Product Details

• PID: 30444

1. LED indicator
2. Button
3. Micro USB Power Port
4. 3.5mm Stereo Sound Output

• PID: 30445

③
④
⑤

—1—

1. LED indicator
2. Button
3. Micro USB Power Port
4. RCA R/L Sound Output
5. 3.5mm Stereo Sound Output

How It Works

• PID: 30444

Mobiles   Tablets

Speaker Headphones   Charging Cable

—2—

• PID: 30445

Mobiles   Tablets

Speaker Headphones   Charging Cable

Speaker

Connection

Put the adapter into the transmit range of 10m/32ft and connect your 3.5mm headphones or RCA R/L speakers to the adapter.

—3—

Power On/Off

① Press and hold the button for 3 seconds then release. You will see the blue LED indicator start flashing and hear the sound "Power On". The device is now powered on and is ready to be paired.

② Press and hold the button for 3 seconds and then release. You will see the red LED indicator flashes and hear the sound "Power Off". The device is now powered off.

Notes:

If this adapter cannot find a device to pair with within 5 minutes, it will automatically shut down with the sound "Pair Fail Power Off".

Pairing this adapter with your cell phone

① Keep this adapter into the transmit range of 10m/32ft.

② Turn on this adapter.

③ Find the Bluetooth setting of your cell phone and start the search for Bluetooth devices.
(Please refer to the user manual of your cell phone).

④ You will find the "Ugreen-Bluetooth06"(PID 30444) or "Ugreen-Bluetooth05" (PID 30445) in your cell phone list and select it, and then you will hear the sound "Pair Successful Connected".

—4—

---

⑤ When this adapter is disconnected or unpaired, you will hear the sound "Disconnected".

Notes

• When this adapter is out of the transmit range of 10m/32ft, it will disconnect automatically.

• This adapter can store the paired ID, and automatically connect next time (5 ID could be stored max)

Playing Music

① Open the music player on your phone and play.

② Play and pause music by pressing the button.

Notes

• This adapter can't control volume. You can control the volume on your phone.

• Move to the previous song or the next song on your phone.

(Please refer to the user manual of your cell phone)

Charging this adapter

When the battery power is lower than 3.3V, you will hear the sound "Battery Low" and the red LED indicator starts to flash. And you need to charge the adapter in time.

—5—

① Charge the adapter completely before the first time use.

② Connect Micro USB cable (included) to the USB port of computer or connect a 5V power adapter.

③ When you charge with the adapter on, the red indicator stays on all the time and the blue indicator light flashes according to connection status; when you charge with the adapter off, the indicator stays red all the time.

④ When the adapter is fully charged, the LED indicator will stay blue.

⑤ Support charging while using.

Operation Introductions		
Status	Button	
	Short press	Long press for 3 seconds
Power off	-	Power on
Connected	-	Power off
Power on	-	
Music playing	Pause music	-
Music pause	Play music	-

—6—

Safety Notes

① Avoid using this unit in extreme high or low temperatures and humid environments.

② Do not expose this unit to dust, water, or extreme temperatures.

③ The adapter is radio signal. Please make sure there is no other signal interference.

④ Do not modify, repair or disassemble devices, if so, please contact manufacture.

⑤ To prevent possible hearing damage, do not listen at high volume levels for long periods.

⑥ This product is with built-in lithium battery, do not discard or throw it in the fireincase prevent explosions.

Package Contents

Wireless Bluetooth 4.1 Receiver Audio Adapter	x1
3.5 mm Audio Cable	x1
Micro USB Cable for Power supply	x1
Manual	x1
Warranty Card	x1

—7—