(AC/DC) Portable battery speaker system (AC/DC) Portable battery speaker system

			Tel:			
			P.C.:			
Followin	gs shall be filled into by th	e sales.				
		(Valid after stamping)	Date of sale:	Year _	Month	Date
			Invoice number:			

Technical specification

Output impedance ————————————————————————————————————	4Ω
Input impedance — — — — — — — — — — — — — — — — — — —	47K Ω
Frequency response ————————————————————————————————————	40Hz-20KH
Sensitivity	400mV
SNR	≥85dB

Note:

As the product is constantly updated, the Company reserves the right without prior notice to the product changes modify. Are subject to change without prior notice!

Professional Portable Speaker






PK15

(AC/DC) Portable battery speaker system (AC/DC) Portable battery speaker system

CONTROL PANEL



01:Main Volume + - 10:Mp3 prev/fm ch-

02:Main treble + - 11:Mp3 play or pause/fm search

03:main bass + - 12:Mp3 next/fm ch+ 04:Echo + - 13:Mp3 repeat

05:microphone Volume + - 14:Replay

06: extral 12V battery in 15:AUX Audio input 07:Fm antenna 16:Microphone input 08:USB/TF card reader 17: Power switch

09:Mode 18:Power AC100V-240V input


instructions


1, charge on the power cord, power supply switches off position, This charge can quickly, otherwise the charge will be too slow and imitation dissatisfaction electric.

2, battery if no power or cannot charge, you can plug in AC power cord, The power switch device in AC open position, power amplifier can work normally.

19: AUDIO INPUT

Cautions













Failure solution

Power failure

Please check if you turn on the power switch of speaker, the voltage indicator watch if show above 9V, please connect power cord and recharge the speaker correctly if the voltage is lower than 9V.

No sound when playing CD/MP3

- A, Please check if connect RCA audio cable and this speaker correctly,
- B. Please check if turn down the lowest volume.
- C, Please check if select the correct singal source,
- D. Please check if the audio source has fault.

USB equipment doesn' t read disc

- A, Please check if connect USB/SD card with the speaker,
- B, Please check if USB/SD has Mp3 file,
- C, Please check if USB/SD card has fault

Noise of speaker

Speaker has the property of low noise, sometimes the background noise of the VCD player and computer sound card is several times higher than that of speaker, therefore, please unplug the audio wire of the speaker when check, and the noise of the speaker shall not hear at 0.5m away.

Antimagnetic of speaker

The speaker adapts strong magnetic speaker, it is possible to cuase magnetic feild interrupt or magnetization if put the speaker close to the monitor. Then you should put the speaker a little far from monitor (Usually the distance should be above 1M)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.