

# **FM Transmitter**

# **INSTRUCTION MANUAL**

**SF66** 

#### **KEY FEATURES:**

- 1. LCD Display Screen
- 2. Built in Wireless FM Transmitter 199 Channel Freq Capable (88.1~107.9Mhz)
- 3. USB/SD Card Compatible
- 4. 3.5 Aux Input for IPOD, normal Mp3/4....
- 5. Supports folder switch
- 6. Fully Adjustable Arm for Multi Angle Viewing
- 7. Wireless Full Function Remote Control
- 8. Cigarette Lighter DC 12-24 Volt Compatible

# **USING THE FM TRANSMITTER:**

- \* Insert this FM transmitter into your vehicle's cigarette lighter or power port
- \*\* Tune to your radio to a desired FM frequency, then match that same frequency on to the player by using the buttons on the unit or on the remote control.
- ※ Plug USB disk or SD card into this product, It will play and transmit the Mp3 files automatic. (You have to copy the MP3 files into the USB disk or SD card in advance.)
- \*\* This product support other devices: normal mp3/4, CD... Using the audio cable provided. Plug one jack into this transmitter, The other end into normal Mp3/4,CD... It will play and transmit the songs from the Mp3/4,CD. And in this state. All functions will now need to be controlled on the device, not this transmitter or its Remote Control. Enjoy!



# **FCC Sttemet**

Changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.

This equipment has been tested and found to comply with the

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **QUICK GUIDE:**

Operation Guide	FM transmitter	Remote Controller
1.How to play and stop	Press "PLAY" Button : Play the music	Press PLAY/PAUSE
the music	Second Press "PLAY" Button: Stop	Button
2.How to adjust the Volume	Long Press "▶▶" button :Increase the Volume; Long press "◄" Button :Decrease the Volume	Press "VOL+"" Increase
		the Volume; Press
		"VOL-"" reduce the
		Volume;
3.How to change the frequency	Press "CH" button first, then press "▶▶": increase the frequency Press "♣•": decrease the frequency	Press "CH+" button:
		Increase 0.1MHZ
		Press "CH-" button:
		reduce 0.1MHZ
		Or press the number of
		the frequency what you
		desired,press"CH+"again
		to confirm
4.How to choose music	Short Press "▶"Button: Play the next song; Short Press "◀" Button: Play the previous song;	Press "NEXT"Button:
		Play the next song;
		Press "PREV" Button:
		Play the previous song;
		Or press the serial
		number of the song
		directly
5.How to set EQ	Cannot be controlled by the Transmitter, only from the remote.	Press "EQ" button to
		switch your favorite EQ
		omion your lavorito Eq
6.How to change loop mode	Long press "play/pause" button, four loop modes optional: folder, single, random, all	Cannot be controlled by the
		remote, only from the
		Transmitter.
7.How to switch folder	Cannot be controlled by the Transmitter, only from the remote.	Press "folder+" or "folder -"

#### Imported by:

LEED IMPORTS, INC

PO BOX # 86287

140 SOUTH ANDERSON STREET LOS ANGELES, CA, 90033 U.S.A.