







Quick Start Guide English




Thank you for buying Tamaggo™
360LiveCam. Prepare yourself for a unique immersive experience! To get you up and running quickly, please read this quide.

Overview









Before using



Please read the Warranty Policy, Safety and Security information included in the packaging box.

- Fully charge the battery before using the camera
- Make sure a microSD card is inserted, class 10 recommended, sold separately

Best camera orientations



Pointing up Everything around and up:

Self-standing



Hand-held

Pointing down Everything around and down:

- Ideal to be used self-standing on its ring.
 It will capture everything around and up
- Don't need to tilt or follow a subject, your camera sees everything!
- For ceiling view we recommend to position the camera at breast level
- For floor view we recommend to use a stick (sold separately) for a wider effect

For more tips and detailed info, please visit www.tamaggo.com

Capture





Capture a 360° Photo



- Yellow icon means photo mode is activated
- Default mode is set to Automatic, simply press the trigger button!
 Shutter sound indicates the photo has been taken
- To switch between Automatic or Timer mode, tap the Photo Capture icon a and switch with right and left arrows
- Save by tapping the Tamaggo icon
- In timer mode, the light ring indicator will flash for 10 seconds until the photo is taken



Capture a 360° Video

- Tap on the Video Capture icon
 Yellow icon
 means video mode is activated
- Press the trigger button to start recording your 360° video. Press again to stop
- A light indicator will keep pulsing while the 360° video is recording

View and manage





View and manage your content

- Tap on the Gallery icon 1 to navigate through photos and videos with the right and left arrows
- Play video by tapping on play icon
- To delete, tap on the bin icon m
- Tamaggo icon brings you back to main menu



Additional settings

- To access the Settings menu tap on the Settings bar at the top of the main screen
 ©
 ©
- Wi-Fi menu allows you to switch Wi-Fi On/Off
- Settings menu allows you to control Sound, choose Language, Format the Memory card or Reset to factory settings
- When enabled, USB mass storage allows you to access your content via USB cable connexion

Download Tamaggo App

For a complete experience download Tamaggo App for iPhone®, iPad® and Android™ smartphones.

Tamaggo App provides remote control of the camera, sharing features including a live streaming mode, and multiple view modes including Virtual Reality mode...

Discover more on www.tamaggo.com









Always put the lens cover when not using your camera.



Touchscreen

The LCD screen is a responsive touch screen. Make sure you actually "press" the icons, ideally with your finger nails.



SD memory card

Make sure the card is inserted into the slot with the card's connectors pointing up.



Charging

Connect your camera to a USB port or a USB charger (sold separately) via the USB cable provided. Only use the USB cable provided in the box.



Troubleshooting

For any question regarding your Tamaggo 360LiveCam, please check our FAQ on www.tamaggo.com or contact our helpdesk.



Guide de prise en main rapide

Français











Merci d'avoir rejoint la communauté Tamaggo™. Préparez vous à vivre des expériences d'immersion uniques! Pour maîtriser rapidement votre caméra, nous vous recommandons de lire ce quide.

Vue d'ensemble











Avant la première utilisation 🕟



Veuillez lire le manuel de sécurité et de ga-rantie contenu dans l'emballage.

- Chargez la batterie à 100%
- · Insérez une carte Micro SD de préférence de classe 10 (vendue séparément)

Recommandation d'orientation



Pointant vers le haut. capture tout autour et au-dessus:

Posé sur pied

Tenue en main

Pointant vers le bas. capture tout autour et en-dessous:

Tenue en main

- Posez de préférence la camera à plat sur son pied. Elle capturera tout autour et au-dessus d'elle
- · Pas besoin de viser ou de suivre un sujet, la camera voit tout! Pour des vues vers le haut, nous recom-
- mandons de tenir la camera à hauteur de poitrine
- · Pour des vues vers le bas, nous recommandons d'utiliser une perche (vendue séparément) pour une vision plus large

Pour plus de conseils et des informations plus détaillées, rendez vous sur www.tamaggo.com

Capture et visionnage



(a)

Capturer une photo 360°

- Pressez l'icone de Capture photo a
- L'icone jaune a signifie que le mode photo est activé
- Le mode par défaut est Automatique, pressez l'obturateur, le signal sonore indique que la photo est prise!
- Pour passer au mode retardateur, pressez l'icone Capture photo a et changez de mode en pressant les flèches droite ou gauche
- Sauvegardez en pressant l'icone Tamaggo
- En mode retardateur, le cercle lumineux clignotte pendant 10s puis la photo est prise



Capturer une vidéo 360°

- Pressez l'icone de Capture video
- L'icone jaune signifie que le mode vidéo est activé
- Pressez l'obturateur pour démarrer l'enregistrement et pressez à nouveau pour l'arrêter
- Le cercle lumineux clignottera lentement pour indiquer que l'enregistrement est en cours

Visionner et gérer



Visionner et gérer le contenu

- Pressez l'icone Galerie pour naviguer dans le contenu de la
- Pour visionner une vidéo, pressez l'icone lecture ▷
- Pour effacer un contenu, pressez l'icone corbeille m
- Pressez l'icone Tamaggo
 pour sortir de la galerie



Réglages

- Accédez aux réglages en pressant la barre en haut de l'écran
- Dans le menu WIFI, vous pouvez activer ou désactiver la connexion WIFI
- Vous pouvez aussi régler le volume sonore, choisir la langue, formatter la carte SD, ou revenir aux réglages par défaut
- Quand le mode stockage USB est activé, vous pouvez accéder au contenu de la caméra via une connexion USB

Télécharger l'App Tamaggo



Découvrez-en plus sur www.tamaggo.com

Utilisation quotidienne





Protégez la lentille Placez le capuchon

sur la lentille lorsque vous n'utilisez pas la caméra.





Touchscreen

L'écran tactile répond à la pression du doigt. Pour une utilisation optimale pressez avec l'ongle.



Carte mémoire SD

Assurez vous d'insérer la carte SD. connecteurs vers le haut.





Charge

Connectez la camera à un port ou un chargeur USB (vendu séparément) via le cable USB fourni. Utilisez uniquement le cable USB fourni dans l'emballage.



Questions

Pour toute auestion ou comportement anormal de la caméra, consultez nos conseils dans la rubrique Questions fréquentes sur le site tamaggo.com ou contactez notre service support.

English

This document states the warranty, safety and other useful information related to the use of your device and original accessories delivered with it (together named "Product").

Warranty Policy

Our Warranty

Your Tamaggo-branded Product is warrantied against defects in materials and workmanship for a period of one (1) year, or for a period corresponding to the minimum legal requirements valid in the country of initial purchase of the Product.

The Warranty Period starts from the date of the initial purchase of the Product.

If a defect arises during the Warranty Period, Tamaggo or its service partners, at their option and to the extent permitted by law, will either (1) repair the Product at no charge using new parts or parts that are equivalent to new in performance and reliability, or, (2) replace the Product with a functionally equivalent product that is new or equivalent to new in performance and reliability, or (3) refund the original purchase price in accordance with the terms and conditions stipulated herein.

Should your Product need warranty service, please return it within the Warranty Period to the dealer from whom it was purchased along with proper identification, a return authorisation number obtained from the Tamaggo website or provided by a Tamaggo representative, and the original proof of purchase.

Information stored on your device

Tamaggo and its service partners will not protect, recover, or return data during the warranty service. Please note that some of your personal settings, downloads and other information may be lost when your Product is repaired or replaced. At present, Tamaggo may be prevented by applicable law, other regulation or technical restrictions from making a backup copy of certain downloads. Tamaggo does not take any responsibility for any lost information of any kind and will not reimburse you for any such loss. You should always make backup copies of all the information stored on your Product before handing in your Product for repair or replacement.

LIMITATIONS

This warranty excludes damage resulting from normal tear and wear, misuse, accident, modifications, liquid and highly humid areas, or other causes that are not defects in materials and workmanship. It does not cover any failures caused by (1) installations, modifications, or repair or opening of the Product performed by a person not authorized by Tamaggo, or (2) use of accessories or other peripheral devices which are not Tamaggo-branded original accessories intended for use with the Product.

Tamaggo and its service partners reserve the right to charge a handling fee if a returned Product is found not to be under warranty according to the warranty conditions.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, TAMAGGO, ITS AFFILIATED COMPANIES AND SERVICE PARTNERS ARE NOT LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER ARISING OUT OF THE USE OR SERVICE OF THE PRODUCT. THE WARRANTY AND REMEDIES DESCRIBED HEREIN ARE EXCLUSIVE AND REPLACE ALL OTHER WARRANTIES, REMEDIES, AND CONDITIONS, WHETHER ORAL,

WRITTEN, EXPRESSED, STATUTORY OR IMPLIED. TO THE EXTENT PERMITTED BY APPLICABLE LAW, TAMAGGO, ITS AFFILIATED COMPANIES AND SERVICE PARTNERS DISCLAIM ALL IMPLIED AND STATUTORY WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IF IMPLIED WARRANTIES CANNOT BE DISCLAIMED, THEN SUCH WARRANTIES ARE LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Any recovery is limited to the original purchase price. No other person is authorized to modify this limited warranty, and your seller is solely responsible for any other warranties.

Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions will apply to the extent permitted by applicable law.

Safety and security

For Your Safety

To prevent damage to your Product or injury to you or to others, please read the following safety precautions in their entirety before using the Product and visit our website at tamaggo.com to obtain additional information related to the use of the Product.

Use the Product only for its purpose.

Turn off in the event of malfunction

Should you notice smoke and/or an unusual smell coming from the Product or the battery charger, unplug the charger immediately, taking care to avoid burns. Continued operation could result in injury or fire.

Do not disassemble the Product

This Product is not intended to be disassembled. Do not attempt to open it. Any such attempt will void the warranty and may result in personal injury.

Do not use the Product in the presence of flammable gas

Do not use the Product in the presence of flammable gas, as this could result in explosion or fire.

Handle the Product with care

Observe normal precautions with this Product, protect yourself and others of unappropriated manipulations. Keep, among others, any small ancillary parts out of the reach of children and animals, and do not place the carrying strap over a child's or animal's head and neck. Do not bite or suck the Product. In case of allergies to metal or certain paintings, itching, eczema, swelling of the skin could appear. Do not use the Product anymore and consult your physician if it was the case. During connection of the Product with another device via Bluetooth, avoid the Product to be too close (less than 15 cm) from health devices such as pacemaker, with which interferences could appear.

Observe the following precautions when handling the Product

Prevent falls and impacts on the Product. Do not put the connectors of the Product in contact with conductors, such as liquids, dust, metallic objects, or lead pencils or pens. Inadequate contacts with conductors may cause a short-cut, corrosion and could result a malfunction, a fire or electric shock.

Keep the Product dry and protected from dust and smoke. Smoke, dust, moisture, water on or in the Product may result in malfunction, fire or electric shock.

Keep clean and dry. Do not use cleaning or detergents. Dust on or near the AC connector should be removed with a dry cloth.

This product is not designed for continued use, which could result in overheating.

It is preferable to disconnect the battery charger from the line prior to the onset of an electrical storm. If connected, do not handle the connecting cable during an electrical storm. Failure to observe this precaution could result in electric shock.

Do not forcibly pull on or sharply bend the connecting cable, place under heavy objects, or expose to heat or flame. Should the insulation be damaged and the wires become exposed, please replace it.

Do not handle the Product with wet hands. Failure to observe this precaution could result in electric shock.

Do not use with travel converters or AC adapters designed to convert from one voltage to another or with DC-to-AC inverters. Failure to observe this precaution could damage the charger or result in overheating or fire.

The Product can be used in areas where the ambient temperature is between 0° C (32° F) and 35° (95° F). It must be stored at an ambient temperature of -20° C (-4° F) to +45° C (113° F), and of -10° C (14° F) to +25° C (77° F) if the storage is longer than 3 months. The use or the storage of the Product at different ambient temperatures than those recommended can damage the Product and/or reduce the battery's lifespan. In a context of very warm temperatures, over indicated range, like in a car during summer, the battery of the product could deteriorate itself and could explode. Do not put the product close to a heating device, like an oven or a radiator.

Use the provided cable

When connecting the cable to the Product connector, only use the cable provided or sold by Tamaggo for that purpose.

Attention to the break

Do not use the Product if it is damaged or broken. Do not intend to replace the battery. All inappropriate intervention or modification on your Product can void the warranty and expose yourself to an injury. If you wish to obtain some information regarding the possibility to fix your Product, please contact your seller or contact Tamaggo via the Tamaggo website.

Avoid contact with liquid crystal

Should the LCD display break, care should be taken to avoid injury caused by broken glass and to prevent liquid crystal from the display touching the skin or entering the eyes or mouth. If such a situation should arise, rinse abundantly with water and consult a physician.

Use appropriate communications modes

In locations such as airplanes and hospitals, observe the regulations concerning the use of wireless communications and switch off such modes as may be prohibited.

Throw in an appropriate manner



This marking means that the Product is an electronic device and should not be put with other waste without consideration. In order to protect the environment and the livings of an inappropriate exposure, use only responsible solutions for treatment and recycling available in your area of living.

Intellectual property

Patents, trademarks and copyrights

All intellectual property rights in the Product and Software are owned by Tamaggo and/or its affiliated companies ("Licensor") and its suppliers and licensors.

Tamaggo and its Tamaggo logo are trademarks or registered trademarks of Tamaggo or its affiliated companies. Other company names, product names and marks mentioned herein are the property of their respective owners and may be trademarks or registered trademarks.

Copyright © 2017 Tamaggo Entreprises

All rights reserved. This document may not be reproduced, displayed, modified or distributed without the express prior written permission of Tamaggo.

Certification, compliance, declaration of conformity



Product details for the following Product: 360livecam Device Model(s):10101

Declaration & Applicable standards:

We hereby declare, that the product above is in compliance with the essential requirements of the Radio Equipment Directive (2014/53/EU), the Electromagnetic Compatibility Directive (2014/30/EU) and the Low Voltage Directive (2014/35/EU) by application of the following standards:

EN300328 V2.1.1; EN301893 V1.8.1; EN62209-2:2010; EN50566:2013/AC:2014; EN62479:2010 EN301489-1 V2.1.1; EN301489-17 V3.1.1; EN55032:2015 CLASS B; EN55024:2010 + A1:2015 EN60950-1:2006 + A11:2009 + A1:2010 +A12:2011 + A2:2013



Per FCC Part 2 Section 2. 1077(a)

Product details for the following Product: 360livecam Device Model(s):10101

It's herewith confirmed to comply with the requirements of FCC Part 15 Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation. The result of electromagnetic emission has been evaluated by Compliance Certification Services Inc. laboratory and showed in the test report. It is understood that each unit marketed is identical to the device as tested, and any changes to the device that could adversely affect the emission characteristics will require retest.

The following manufacturer/importer is responsible for the above CE and FCC declarations: Tamaggo Enterprises SA, Rue du Mont-Blanc 14, 1201 Geneva, Switzerland. For the latest address or the phone number of Tamaggo, please check Tamaggo website: Tamaggo.com

Federal communications commission interference statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Caution

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

RF Exposure Information (SAR)

This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the EUT transmitting at the specified power level in different channels.

The FCC has granted an Equipment Authorization for this device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this device is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/eot/ea/fccid after searching on FCC ID: 2AKOR10101

Specifications of the Product

Field of view / Angle	360x220
Image type	Video and photo
Image sensor	12 Mp Sony
Photo resolution	8Mp, 2880x2800
Video resolution	1440x1440
Live streaming resolution	1440x1440
Angular resolution	MTF50 >3.0 cy/° across the field
Aperture	f2.2
Video encoding	MP4 H264
Bluetooth	4.1 (24 Mb/s) + BLE
WIFI	IEEE 802.11 a/b/g/n (5GHz band)
Port	micro usb
Orientation Sensor	9 axis (accelerometer, gyroscope, compass)
Memory	MicroSD card class 10 up to 128GB (not included)
Battery	Internal, 1500 mAh / 3.7V Li-po, 2 hours video, 1000 photos
Screen	Touch screen, image preview
Audio	Low-noise, 100 db SPL HDR microphone, 20-20 kHz bandwidth

Disclaimers

All users should check the terms and conditions of his purchase contract with his/her supplier. This publication contains information proprietary and confidential to Tamaggo. Any reproduction, disclosure or unauthorized use of this publication is expressly prohibited without written permission from Tamaggo.

Tamaggo has made every effort to ensure the accuracy of the information presented in its documentation. However, Tamaggo assumes no responsibility for the accuracy of the information published, and remains at disposal for any complementary info that could be wished. Tamaggo reserves the right to make improvements or changes without notice at any time in its software, hardware Product or Product documentation. Mention of products or services not manufactured or sold by Tamaggo for informational purposes only constitutes neither an endorsement nor a recommendation for such products or services. Just as technology and market conditions vary, Tamaggo's warranty, customer support and safety policies (including fees for services) and other policies and procedures may change over time. To obtain information about Tamaggo's warranty, policies and procedures, please visit our website at tamaggo.com or contact our customer support organisation at this website.

Contact

tamaggo.com info@tamaggo.com