



QUICK START GUIDE \$502

Getting to Know Your Phone





Power Key

- Press and hold to turn on or off airplane mode, power off or restart the phone.
- Press to turn off or on the screen display.

Home Key

Touch to return to the home screen.

Back Key

Touch to go to the previous screen.

Recent Apps Key

Touch to see recently used applications.


Volume Key

Press or hold either end of the key to turn the volume up or down.


Starting Up

Switch off your phone before installing or replacing the battery. The microSD card is optional and can be installed and removed while the battery is removed.

 Place your finger in the slot at the left of the back cover to lift and remove the cover.




 Hold your Nano-SIM card with its cut corner oriented as shown and slip it into the card holder



WARNING!


To avoid damage to the phone, do not use any other kind of SIM card, or any non-standard Nano-SIM card cut from a SIM card. You can get a standard Nano-SIM card from your service provider.

 Hold your microSD card with the metal contacts facing down and slide it into the microSD card slot.



NOTE:

Some applications may require a microSD card to work normally or may store certain data on it. Therefore, it is recommended that you keep a microSD card installed and not remove or replace it randomly. Align the connectors on the phone and the battery and slide the battery into the compartment. Then gently press the battery down until it is secured.



 Align the back cover with the back of the phone and press the cover back into place.
 Ensure that all the tabs are secure and there are no gaps around the cover.

Powering On/Off Your Phone

- Press and hold the Power Key to turn on your phone.
- To turn it off, press and hold the Power Key to open the options menu and touch Power off.

Restarting Your Phone

If the screen freezes or takes too long to respond, try pressing and holding the **Power Key** for about 12 seconds to restart the phone.

Calling and Voicemail

Making a Call

- Touch the Home Key > .
- Touch and enter the phone number or the contact name with the dialpad. The phone will display matching information from your contact list.
- Touch the matching contact to call the contact or touch to call the number.



You can also touch the search box at the top of the Phone app screen and enter the phone number or contact name you want to call. Touch the matching contact or **Call** [number] to place the call.




Checking Voicemail

- 1. Touch the **Home Key** > W > iii .
- 2. Touch and hold the 1 Key on the dialpad.
- Follow the voice prompts to listen to and manage your voicemail messages.



Creating a New Contact

- Touch the Home Key > and touch the all contacts tab CONTACTS.
- Touch to add a new contact.
- If you have multiple account types associated with your phone, touch the field above the name and select a contact type.
- Enter the contact name, phone numbers, email addresses, and other information.



Sending a Message

- 2. Touch + at the bottom.
- 3. Add recipients by one of the following ways.
 - Touch the To field and manually enter the recipient's number or the contact name. If the phone presents a few suggestions, touch the one you want to add.
 - ➤ Select recipients from your contacts by touching ♣ .
- 4. Touch the Type message field and enter the content of your text message.5. If you want to send a multimedia message,
- If you want to send a multimedia message, touch the paper clip icon to attach a file or a slideshow to the message.
- Touch > to send.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(1) Inis device may not cause narmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: The grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user 's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can redate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to endio or reteivain reception, which can be determined by turning the equipment of and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

SAR Statement

The SAR limit of USA (RCQ) is 16 W/kg averaged over one gram of tissue. Device types CDMA/LTE 4G Mobile Phone (FCC) LE 24K(NS)-8520) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification when properly owen on the body is 1.66W/kg. This doce was tested for pytical body-owen operations with the back of the handset kept 1.5cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5cm reparation distance between the use's body and the back of the handset. The use of Polt clips, holders and similar accessories should not contain metallic composition. The composition of the contain metallic composition of the properties of the product of the properties of the product of the p

FCC Hearing-Aid Compatibility (HAC) regulations for wireless devices

The PCC has adopted rules to ensure reasonable access to telecommunications services for persons with hearing disabilities. As part of this effort, the industry uses a rating system for wireless phones to help hearing device users find phones that may be compatible with their hearing devices (hearing add and cochlear implants). This hearing, add complating light (A), rating system is described in the American National Standards Institute (ANSI) C63.30 standard and includes the following ratings: M-Ratings: For phones that use acoustic coupling with hearing devices that are not operating in telecol mode. Phones rated M3 or M4 meet FCC HAC requirements and are likely to generate less radio frequency interference with hearing devices that phones with lower ratings. M4 is the better/higher of the row ratings. Your CDMA/LTE 4C Mobile Phones is rated M3.

better/ingher of the two ratings. Your LDMA/LLE4U, Mobile Phone is rated M4.

"Ratings: For phones that use indictive coupling with hearing devices operating in telecoil mode.

Phones rated T3 or T4 meet FCC HAC requirements and are likely to be more usable with a hearing aid." stdecoil than phones that are not rated. T4 is the better/higher of the two ratings. Your CDMA/LTE4 GMobile Phone is rated T3.

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some never wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone throughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering nose. Consult your service provider or the manufacture of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

The ratings are not guarantees. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs. Results will vary depending on a user 's hearing device, and hearing loss. For example, if some wireless phones are used near some hearing devices, users may detect a buzzing, humming, or withing nones. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully.