# Android All in one PCS



User Manual



# Contents

P series product diagrams
Z series product diagrams
Y series product diagrams
Y series product diagrams
Getting Started
Power On/OR.
Access to The Application
Worless Internet

Install APK
Uninstall APK
Date Transmission
Factory Reset

# Notes of Importance

2) Do not release hit the desire or clare comethinghous on it

4) Please keep the device away from became, diluents or other chemical. SI Keep the device away from water.

Fit The revolunt should be serviced by the professional servicemen, do not try

Ti Disease unroken the remove roken of the non-fact when not in use for a lover

time or during the rainstorm El la order to avoid damaping the touch gazel, never place the heavy or sharp

which we the touch panel when use or transport it. Of Assessed all cabber and cook to that excels and not are not likely to big.

# not allow children to play with cables and cooks Quad-core ARM cortex-AS, high performance processor

2 OMP camera on finet

Wi-Fi, windess internet, 802.11 b/s/n

Google browser support Chrome label style, Google search etc.

Support gravity sensor, auto-notate screen Surport 3G USB donale (external, not include in package of the device)

10 paints touch screen Support peripheral with USB port of mouse, keyboard. Ethernet and etc. Full format video play JMMVBAPEG1.MPEG2APEG4.VC1.MIXH.264 ect.


# P series product structure






# Z series product diagrams

## (Size:13.3\*/14\*/15.6\*/18.5\*/21.5\*/23.6\*/27\*/32\*)



# Y series product structure



# Y series product structure (Size: 21.5") VTSA Well

### Getting Started

 Insert the power lead into the DC socket, and then insert the other end into the namer socket

2) Turn on the product by holding the power button for 3 seconds.

1) Screen will show the starting loss.

Wait for about 30 seconds and enter into main



# Power On/ Off I Power our turn on the desire by holding the power button for 3 seconds.

when the product power off.

2) Power off: holding the power button for 3 seconds and click of to power.

off when the product at working status.

3) Short press power betton for sleep or awake the product when the product standing



## Access to The Applicati



In the main menu , click con to go to APPS menu screen.
 Slide the screen letheard/rightward fast, switch to the other menu screen.
 Click the ages icon to order into ages.

() Click the "RETURN" loon, return to previous page, click the "HOME" icon return to the main menu.



## Wireless Internet

- Enter into the settings and turn on the Wi-Fi, connect to the available networks.
- Enter into the APPS and click the "Browser", then you will get into the Google homepage.
- You can input the website on the top that you like, or you can search the interesting news and videos by the Google search.

hat in APPS, then you will enter into the of the following nicture





application.

# Uninstall APK

1) Click the "Settings" in the APPS, enter into

Select which application would you want to uninstall, as the following picture



 Select and click the Uninstall button to uninstall this application, as the following picture:



## Date Transmission

Connecting PC and device by using USB cable, USB icon 

will be appeared on the upper left side of status bar. it refers to USB has been connected. As follows:



In the main menu , click look to go to APPS menu screen.

2) Click the that in APPS, then you will enter into the APK File Manager select and a stee following picture:



.

## Factory Reset

Factory Reset

If your device has been contracted the virus, or worked unexpectedly by
installing thirth party applications, then you can erase all data from your device

via meet tablet.

Operation: click: Settings' + Backup & meet' + Tectory data meet',
then click the "Reset tablet" and "Ease everything", as the following:





This symbol on the product or in the instructions means that your electrical and electronic equipment inhould be disposed of at the end of its life separately from your household write. There are symptom collection systems for recycling in your country. For more information, please contact the local authority or your retailer where you purchased the product.

The determination complete with the 11 cited at NCT date Operation and option to the following two conditions: (i) this determination person conclusional conditions, and (c) this determination are specific conditions and conditions are considered as the condition are considered as a condition are repossible proposed by the pure specially for complete conditional conditions and conditions are conditional and conditions are conditional and conditional and conditions are conditional and condi

derice, purcure to Part II of the PCC Bulls. These limits are designed to provide reasonable protection against homeful sinchence in a residented attribution. This equipment powers, core instructions, sure cases beautiful sinchences to calcio communications. Serverel, there is no

guarance dus inschenses vill and voor in a particular installation. If this payment sher cover bounds inschenses to code or selection program, thick has be decreased by traving the opigetion of their last less the sect in converged in by the costs the introductor by one or control the following provinces:

Resident is solvable the extering settems.

Source the expectation between the optiginated and exterior:

Connect the optiginated case so confer as a contract different from that he which the excitors in

connected.

— Countil the deuter or an experienced paths TV fectoration for their

Countri the dealer or an experienced antio TV instancias for belg.

The dealers of between over and markets should be as less than Time.