## **User Manual**

## Wireless Door Bell Model No.: MRF20705

- 1. Function Introduction:
- 1.1. There are 3 buttons on the right site of the receiver, volume control and sound options keys from top to bottom.
- 1.2. There is red flash light function on the middle of the receiver.
- 1.3. Each button can be controlled as to your requirements.
- 1.4. This item has been learnt code before delivering so that you can use d irectly. If you long press the sound options key incautiously, the receiver maybe hard to fit to the learnt transmitter. And it should be learnt code again.
- 1.4.1. Learning code: When in an energized state, you press the volume cont rol key of the receiver for 3 seconds so that it will turn into the lear ning code mode. At the same time, push the button of the transmitter to learn and release the button after completing .It will show that it is s uccessful. (Between the learning code period, a receiver can be learnt w ith four transmitters at most.)
- 1.4.2, Many-to many mode: Through operating of the learning code, it will be realized between the internal system of receivers.
  - A, 1 receiver to 4 transmitters
  - B, 1 transmitters to many receivers
- 1.4.3, Eliminating code: When receiver is under the state of power off and after discharging (about 30 seconds), it will need to be learnt a new transmitting code which is different from the learnt one after power on again. And the last memory will be eliminated.

- 1.5. Super heterodyne technology, super-strong anti-interference, 36 melodi es for choosing freely.
- 2. Installation m ethod and Notice
- 2.1 Receiver can be plugged in indoor socket as to your requireme nts.(The height more than 1.5 m is better .)
- 2.2. Paste the double-side tap on the back shell of the transmitter, and stick in the proper sit e to use.
- 2.3. A void to install the transm itter under the rain and sunlight.
- 2.4. Please don't install the transmitter on metall object(such as iron gate, iron frame and so on), lest influence the transmitting range.
- 2.5. The p ractical rem ote control range will be changed by environmental factors.

## 3. FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.