Installation Steps

Cubinote has two print modes: Cloud Mode and Bluetooth Mode. Cloud Mode: Requires Wi-Fi and Internet.

Bluetooth Mode: Require Buetooth Connection.

Cloud Mode



Step 1

Please power on Cubinote. Green light will turn on.





Please turn on Wi-Fi on your phone, and make sure your phone is connected to the Internet.



Step 3

Please scan the QR code in the bottom right comer below. Download the App, and register a new account.



Please double click the button on the front of Cubinote, and scan the QR code using your phone to bind a new device(your phone) .



Please press the button on the front of Cubinote for 6 seconds to set Wi-Fi. Ensure your phone and Cubinote are on the same Wi-Fi network. Enter the password for your Wi-Fi network.



Setup is completed.

Bluetooth Mode (after setup in Cloud Mode)



Enable Bluetooth on your PC.



Step 2

Search for Cubinote Bluetooth device.



Step 3

Pair Cubinote Bluetooth device.

FAQ and Tips

- ★ Please use only the Cubinote power adaptor supplied.
- ★ 5G Wi-Fi networks are not supported.
- $\not \simeq$ Double click the front button to print a diagnostic report.
- ☆ Press and hold the front button for 6 seconds to reset Wi-Fi settings.
- ☆ Orange LED: Important Message. (restore when pressing the button)
- ☆ Red LED: Overheated or out of paper.
- ☆ Green LED : Setup is required.
- ☆ Blue LED On: Normal status/ Ready.
- ☆ Blue LED flashing: Flashes during printing or network connection.

Note-Print head temperature is 70°C. Please do not touch.

Contact Information

Support and Customer Service : email support@cubinote.com



App Download

背面

Cubinote

Quick Installation Guide

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1. This device may not cause harmful interference, and 2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. RF Exposure: A distance of 20 cm shall be maintained between the antenna and users, and the transmitter may not be co-located with any other transmitter or antenna.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) this device may not cause interference, and
(2) this device must accept any interference, including interference that may cause undesired operation of the device.
Le présent appareil est conforme aux CNR d'industrie Canada applicables aux appareils radio exempts de licence.
L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
This equipment complies with Canada radiation exposure limits set forth for uncontrolled environments. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



Correct Disposal of this product
This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, man health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used de use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe

Warranty Information

The manufacturer provides warranty in accordance with the legislation of the customer's own country of residence, with a minimum of 1 year (Germany: 2 years), starting from the date on which the appliance is sold to the end user.

The warranty only covers defects in material or workmanship

The repairs under warranty may only be carried out by an authorized service centre. When making a claim under the warranty, the original bill of purchase (with purchase

The warranty will not apply in cases of:

- Incorrect use, e.g. overloading of the appliance, use of non-approved accessories

 Use of force, damage caused by external influences

 Damage caused by non-observance of the user manual, e.g. connection to an unsuitable mains supply or non-compliance with the installation instructions
- Partially or completely dismantled appliances