Introduction

Thank you for purchasing the Vivitar Air Free True Wireless Earbuds, Item V400388T. You can use your earbuds with most smartphones and Bluetooth devices to stream music wirelessly. In addition, your earbuds come with a wireless charging case which allow you to charge your earbuds anywhere you go. In order to get the best results when using this device, please read this manual first before using.

Package Contents

-Vivitar V40038BT Air Free True Wireless Earbuds -Wireless Charging Case -USB Charging Cable -User's Manual with Warranty Information

Specifications

Bluetooth Rangel: Up to 35 feet 1(0 meters)
Battery type (charging case): 400mAh Lithlum Ion Battery
Battery type (charging case): 400mAh Lithlum Ion Battery
Charge Time (charging case): 42 feet 10 meters 10 me

"Applicable at 50% of maximum volume. Results will be lower when volume is higher.

Charging Your Earbuds







port of a computer or suit USB charging adapter.

can be used anywhere to charge your earphones. Simply place your earphones so they fit securely in

Important Safety Precautions

- Tech 1st. I harmorities series usine your schedules.

 Chen viring soft both or paper frow.


 Do not allow righted not be effected by the your exhibits without adult supervision.

 Do not allow righted not be effected by the properties of the proper

- Deficient for the control of the con



A Ouick Look at Your Device



Pairing Your Earphones Together

When using your earphones for the first time, it is necessary to first pair the two earphones together so that you can hear audio from both your left and right earphone. To do so, follow the steps below.





2. Your earbuds will power on and after a few moments they will pair together. Your left earphone will audibly say. 'LEFT CHANNEL.' while your right earphone will audibly say. 'RICHT CHANNEL.'

Pairing Your Earphones with a Smartphone





The LED indicator lights will alternately flash red and blue to indicate that your earphones are in pairing mode





Using Your Earphones

Powering Your earphones On and OFF

1. To power on your earphones press and hold the Power/Flay/Flause/Answer butterns until your

1. To power on your earphones, press and hold the Power/Flay/Flause/Answer buttern to your Bluetooth device, they will
automatically remain paired each time your power on your earphones.

2. Press and hold the Power/Flay/Flause/Answer button on either earphone for 5-6 seconds to
power them both off.

200.0 mm —

Listening to Music
- Playing or Pausing a Track: Press the Power/Play/Pause/Answer Button on either earphone to

play or pause a track. -Advancing to the Next Track in a Playlist: Press and hold the Power/Play/Pause/Answer Button on either earphone for three seconds while music is playing.

- Using the Phone Function

 Answering a Call: Quickly press the Power/Play/Pause/Answer Button on the left earphone.

 Reject an Incoming Call: Press and hold the Power/Play/Pause/Answer Button on the left
- Ending a Call: Quickly press the Power/Play/Pause/Answer Button on the left earnhone

FCC Statement

210.0

Changes or modifications not expressly approved by the party responsible for compliance could

This device complies with Part 15 of the ECC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the RC Tubles. These limits are designed to provide reasonable protection readilest adolf requency energy and, fron installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television recention which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Regrient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver is
- connected.

 Consult the dealer or an experienced radio/TV technician for help.

Vivitar One Year Warranty (continued)

VIVITAR ONE YEAR WAITANTY (CONTINUED)

NO WARRANTIES, WHETHER REVERS OR INHELDIN, INCLUDING, BUT NOT LIMITED TO, ANY IMPUED WARRANTIES OF MEEDLAND INCLUDING, BUT NOT LIMITED TO, ANY IMPUED WARRANTIES OF MEEDLAND REVERSES AND ANATY PERSON STRUCKED RUPER THAN THOSE EXPRESSLY DESCRIBED ABOVE AND OTHER EXPRESS WARRANTY OR OUARANTY CURN YEAR OF ANY PERSON, REM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, ABOTH THE PROLUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, ABOTH THE PROLUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, ABOTH THE PROLUCT SHALL BE BINDING ON THE NOT PROVIDED REPAIR REPLACEMENT, ABOTH THE PROLUCT SHALL BE BINDING ON THE ONE OF THE ONE ONLY ANY PROPERTY OF THE ONE OF T BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or Some countries disasses or provinces do not allow a many contributions on understand a many contribution of the contribution o

Vivitar One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What is Not Covered by Warranty
Damages or malfunctions not resulting from defects in material or workmanship and damages or
malfunctions from other than normal use including but limited to, repair by unauthorized parties,
tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information: Call 1-800-592-9541 in the U.S. or visit our website at

To receive Warranty service along with the name and address of an authorized product service To receive Warranty service along with the name and address of an authorized product service content, the original consumer purchase must contact us for problem determination and service content, the original consumer purchase with the problem of the problem and a valid return address to the authorized service center at your expension with the defective product. Any products received by which the defective product and the problem of the



