# **User Manual**



## MANUAL (ENGLISH)

- 1. Next Track Button/Volume Up
- 2. Multifunction Button
  (Power Button/Pause-Play/ Answer-Hang Up Calls)
- 3. Previous Track Button/Volume Down
- 4. LED Indicator
- 5. 3.5mm Auxiliary Port
- 6. Micro USB Charging Port

#### Charging the Bluetooth Headphones

- To charge your Vortex Bluetooth headphones, connect a Micro USB cable (not included) to the Micro-USB (6) charging port and connect the other end to a USB power outlet (5V adaptor not included). The LED charging indicator will light up red, indicating that the headphones are charging properly. When the LED indicator turns off, the headphones are fully charged. (To maximize the life of the battery, do not charge more than 3 hours.)
- For best sound performance, please make sure battery is fully charged before use.

### Operating the Bluetooth Speaker

- 1. Turn the headphones ON by holding the multi-function button ▶ 11 (2) for 3 seconds. The LED light indicator (4) will begin flashing blue and red.
- The headphones will enter pairing mode. Enable Bluetooth search mode on your audio device and search for pairing name "VORTEX" and select it on your audio device. Once the headphones have been successfully connected, the LED will flash blue.
- 3. Press the Multifunction ►■ Button (2) to answer calls, pause and play and hang up call.
- 4. To change to the next track, press the button (1)
- 5. To change to the previous track, press the | button (3)
- 6. To raise volume, press and hold the Volume " + " Button (1)
- 7. To lower volume, press and hold the Volume " " Button (3)
- 8. To power down the headphones, hold the multi-function button ▶II (2) for 5 seconds. The LED light indicator will flash red 3 times and remain off.
- 9. To use headphones from a wired audio source, plug in the a 3.5mm audio cable into the "Aux" port (5) (Aux cable not included). The headphones will automatically switch from "Bluetooth" mode to "Auxiliary" mode. (Please note that the music controls on the headphones will not function while in Auxiliary mode)

#### **ONE YEAR WARRANTY**

Xtreme warrants its products for ONE YEAR against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

\*Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect.

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product, please contact Customer Service at customerservice@xtremecables.com

# Package Contents:

Bluetooth Headphones

3

## **Safety and Care Instructions:**

- Do not attempt to disassemble the unit.
- Repairs to electrical equipment should only be performed by a qualified service person. Improper repairs may place user as risk and void warranty.
- Do not puncture or harm the exterior surface of the product in any way.
- Do not drop or let the unit fall from high places, as doing so may damage the device.
- Do not use this unit for anything other than its intended user or purpose. Doing so may damage the device and void warranty.
- This product is not a toy. Keep out of reach of children.
- Do not expose batteries or battery pack to excessive heat or open flame.
- Do not expose the unit to extremely high or low temperatures as this will shorten the life of the device, destroy the battery, and /or distort certain parts.
- Do not use abrasive cleaning solvents to clean the unit. In order to prolong battery life, turn off when not in use.

# FCC Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency

energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver

—Consult the dealer or an experienced radio/TV

is connected.

technician for help.

#### FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

5