# USER MANUAL

ifidelity - /ai•fə•del•[i]•tē/

experience originality



Metal Millennium Bluetooth® Speaker

#### FCC Statement:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

#### FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

Front Side page 2

#### Care and Maintenance:

Do not subject the unit to excessive force, shock, dust, or extreme temperatures.

Do not tamper the internal components of the unit. Clean the unit with a clean dry cloth,

Avoid leaving your unit in hot, humid, or dusty places. Keep your unit away from heating appliances and sources of electrical noise such as fluorescent lamps or motors.

Always keep your finger dry and clean before touching the buttons.

Do not dispose of the batteries in fire. Batteries may explode of leak.

#### User's Manual

Congratulations on your ifidelity Metal Millennium Bluetooth® Speaker!

Read carefully and follow all instructions in this User's Manual before using the Speaker. Keep this User's Manual in a convenient location for future reference.

Back Side page, 2

#### Precautions:

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all the safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

- Avoid contact with liquids and damp areas.
- Do not block or leave the case open.
- · Charge the battery fully before initial use.

## Specifications:

Playback Time: Pairing Name: Charging Time: 2 hours (max volume) Millennium 5-6 hours from 0-100%

The right to make technical and design modifications in the course of continuous product development remains reserved. This device has been tested according to all relevant and current CE guidelines, such as electromagnetic compatibility and low voltage directives, and has been constructed in accordance with the latest safety regulations.

ASSEMBLED IN CHINA

Front Side page, 3

### Package Contents:

- Speaker
- · Micro USB charging cable
- 3.5mm Audio cable
- User Manual

### Damage Requiring Service:

This unit should only be serviced by qualified service personnel when"


- Objects have been exposed to liquids.
- The unit has been dropped or enclosure damaged.
- The unit exhibits a marked change in performance or does not operate normally.


Do not attempt to service the unit beyond the methods described above. Seek assistance from a qualified professional.

### Periods of Non Use:

If the unit is to be left for a period of 1 week or more, the power cord should be unplugged from the unit to prevent damage or corrosion.

Back Side





## Charging the Speaker:

- Using the provided charging cable, insert the Micro-USB end into the charging port (9).
- 2. Insert the opposite USB end of the cable into a 5V USB wall plug or computer's USB port.
- The LED Indicator will glow Red while charging and will turn off once the device is fully charged.

04

page 3

Front Side page, 4

## Listening in AUX Mode:

- 1. Insert 3.5mm audio cable to "AUX IN" port.
- 2. To play or pause audio in Bluetooth® Mode, short press the Play/Pause button.
- 3. To Increase volume, press and hold the "+" button.
- 4. To decrease volume, press and hold the "-" button.
- \* Track selection must be made from audio device in this mode.

#### **Button Functions:**

- 1. Power ON/OFF Button/LED Indicator
- 2. Play/Pause Button
- Call Button
   Mic
- 5. Vol+ / Next Track
- 6. Vol- / Previous Track
- 7. 3.5mm AUX Line-in
- 8. Micro-USB Charging Port
- 9. LED Charging Indicator

Back Side page 4

#### LED Indicator:

| LED              | Status                           |
|------------------|----------------------------------|
| Flashing Blue    | Power ON / Pairing Mode          |
| Glowing Blue     | Bluetooth® connection successful |
| Glowing Red      | Speaker is Charging              |
| Glowing<br>Green | Charging Complete                |
|                  |                                  |

### Answering Calls in Bluetooth® Mode:

- 1. Speaker will sound a call ring indication tone when a call is incoming.
- To answer an incoming call in Bluetooth® Mode, short press the Call Button.
   To end a call in Bluetooth® Mode, short press the
- Call Button again.
  4. To redial the most recent number, short press the
- Call Button twice.

  5. To Increase volume, press and hold the "+" button.
- 6. To decrease volume, press and hold the "-" button.

Front Side page, 5

## Listening in Bluetooth® Mode:

- To play or pause audio in Bluetooth® Mode, short press the Play/Pause button.
- To skip ahead to the next track, short press the "+" button.
- To go back to the beginning of a track or to skip to the previous track, short press the "-" button.
- 4. To Increase volume, press and hold the "+" button.
- 5. To decrease volume, press and hold the "-" button.

#### Connection via Bluetooth:

- Press and hold Power Button to turn on speaker and enter Bluetooth® pairing mode. LED Indicator will begin flashing Blue.
- Tone will sound indicating that the speaker is discoverable.
- 3. From a Bluetooth® enabled audio device, select "Millennium" from the list of available devices. A
- tone will sound and LED Indicator will glow solid Blue to indicate pairing success.
- \* Once paired to this device, it will automatically connect upon being powered ON.