


Product Instruction Manual


1. Instruction Manual

Product Conposition

- 2. Surfboard Device
- 3. Surfboard 'Dedicated Cable' - USB OTG(On-The-Go) Cable



- 4. LED Status indication of device
- 5. Battery Cover
- 6. USB Port(for wire connection)
- 7. BT Power Botton (Wireless connection)



USB Connection


▶ Smart Device

Please use the "USB cable" included in the box ONLY!




There can be crossed during wireless operation.

: DO NOT use this device for human safety service.



Open the battery cover and insert two 'AA' batteries.



▶ BT. Pairing ※ Pairing Cancel 'ESC' Push 3 sec





- Host to Device 1 ... 0

Pin Code Enter

⇒ LED indicator is on in order of entering codes For Mac OS - Enter Pincode: '0000'

⇒ 'Fn' LED On

* If Bluetooth pairing is failed by unpairing, invalid code or any error occurs remove "Surfboard" from Host device and start pairing process over.

⇒ 'Fn' LED Off , LED indicator flashes purple

The slot stored already does not flashes - Slot status

The OS stored already does not flashes - OS status On your Host Devices, Search for BT device

and choose "SURFBoard"

⇒ No.1 ~ 7 LED indicator flashes


⇒ No.1 ~ 5 LED indicator flashes

(Pairing Mode)





===== OR ========



Choosing slot

Device Setting

BT. Connection

- 1. "SURFBoard" does not need other devices to set for basic use.
- X Surfboard does not need other devices to set for basic use.

You can download at our website, www.lentus.co.kr.

- 2. Press Setting button for 2 secs for Setting Mode. The support functions are following:
 - a. Select OS
 - b. Adjust pointer speed
 - c. Adjust pointer speed
 - d. "Maker" Initialization

► How to Use Setting Mode

Select OS

- Select OS * Windows * Mac
 - * ios * Android * etc.
- 4]… [8]

- ⇒ No.1 ~ 5 LED flash Current OS LED does not flash - OS Status

- Press for 2secs
- ⇒ LED No, '1', '2', '3' flash
- Adjust Pointer Speed
- Adjusting moving speed of the pointer.
- 11/2

ŏ

- ⇒ No,1 ~ 8 LED flash
- Current speed LED does not flash Speed status

- Adjust Scrolling speed
 - Adjusting operation speed of scroll.



- Select Speed Level
- ⇒ No. 1 ~ 8 LED flash
- Current speed LED does not flash speed status
- ⇒ Power : Red LED On

"Maker" Initialization

Once Power LED indicator(Red) is on and off, Initialization is completed.

Press Reset Button for 2secs

- Initialize every established setting

except for key-layout.

end

* Use **Mode** key for Switching typing and controlling pointer.

1. Basic Moed - Operate as a keyboard and a



Typing text: press keys

Controlling pointer

2. Pointing Moed - Operate as a mouse



Typing text: not available

Controlling pointer touch the surface For Click Press the surface

3. Typing Mode - Operate as a keyboard




Typing text: Press keys

Controlling Pointer

▶ SURFBoard Texting

 Every touching surface is pressed equally, which operates.




'Pointing Mode

► Controlling Pointer

Touch hold

Touch Tap

Touch Surface Tab
Touch surface movement




* Roll the scroll wheel



Click and drag the scroll wheel

Drag Mode (Drag & drop)



▶ Swiching Key Layout

X Click Layout x 2 key 'two times' to switch 'user-defined' layout to 'Standard'lavout.



X Download 'Use-defined' S/W at Lentus Website.

LED Status Indicating

1. Power (Status) LED

	On -	Flashing -
Red		Warning for low power of BT
Blue	USB Connected	BT. Connected
Purple		BT. Pairing

* BT Connection:

Red and Blue light flash alternately while Bluetooth connection.

***** BT Low power mode :

Blue LED light is off in deep sleep mode. Blue LED light will flash again if you touch any surface.

- 2. Check Drag Mode
- Pointer LED indicator flashes



3. Check 'User-defined layout'


- Enter custom layout
- Fn LED Flashes Every 2 seconds (On for 1.0 second, off for 1.0 second)
- Fn key on at custom layout
- Fn LED Flashes Every 2 seconds

(On for 0.25 second, off for 0.25 second)

Key Layout

* Click scroll wheel button

1. Standard Lavout



2. Setting Layout




How to Use Funtion Key

1. How to Use Shift Kev

end

- Shift LED indicator is off using shift key.

After typing text, Shift LED indicator is automatically off.



- 2. How to Use Ctrl / Alt / Win key
 - Same as using Shift key.
 - XYou can hold function key
 - Use for typing function key for more than one time.



How to Use 'User-defined'

1. How to Use 'User-defined' www.lentus.co.kr



Download our 'User-defined' APF





XFor more details, visit our website.

FCC Statements

• NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residental installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no grantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, Which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receving antenna.
- Increase the separation between the equipment and receiver,
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

Caution in use



Caution

- Radio wave can affect electronic medical devices. Do not use this device near the medical device or inside the healthcare facility
- Do not use the device within 22cm of the person wearing a defibrillator or heart pacemaker.
- Do not expose the body of the device to rain or moisture to reduce the risk of fire and electric shock,
- Since the wireless facility is capable of transmitting radio interference, there is no service associated with life
- The contents of this manual are subject to change without prior notice for improvement of performance and
- It is prohibited to use or copy the contents of this manual or all of the contents of this service.
- The contents of this manual are made entirely out of doubt, but please understand that there may be some mistakes or discrepancies
- The illustrations used in this manual may differ from the examples for illustrative purposes.
- The specifications and appearance of this product can be changed without prior notice for the quality improvement, and Lentus Corp. has the right to change.
- We are not responsible for any loss of data and inability to access during this product use.
- Depending on the individual user's environment, product performance and functionality may be limited or

Certification

Certified Manufacturer: Lentus, Inc.

Model Name : EI14010

Date of Manufacture: 2017. .

Manufacturer : Lentus, Inc.

Contury of Manufacture: Republic of Korea

• Certificate Number: MSIP-CMM-Let-El-14010

 This device is intended as a household (Class B) electromagnetic compatibility device, primarily for use in homes, but it can be used in any place.

