SteadXP+

GUIDE DE DÉMARRAGE RAPIDE

Manuel d'utilisateur complet sur steadxp.com/manual Besoin d'aide ? support@steadxp.com

— PLUG. BRANCHER.

AVANT VOTRE PREMIÈRE UTILISATION

- · Insérez une carte mémoire (non fournie*) microSD ou microSDHC, d'une capacité de 1 à 32Go
- · Insérez la batterie, modèle pour GoPro® HERO3** (non fournie*) une fois chargée.
- · Pour la correction d'horizon, calibrez les gyroscopes de votre SteadXP+ en le laissant allumé sur une surface stable sur la plage de températures d'utilisation prévue.

BRANCHEMENT

- · Insérez SteadXP+ sur la griffe de flash de votre appareil et fixez-le avec la molette de serrage, dans l'alignement de l'optique.
- · Allumez en branchant le câble audio (non fourni*) sur l'entrée micro stéréo de votre appareil. Option : avec les caméras genlocker compatibles. vous pouvez SteadXP+ sur son entrée RCA (signal bi ou tri-level).
- · L'indicateur lumineux (LED) de SteadXP+ alterne d'abord entre le rouge et l'orange (1), puis clianote après quelques secondes (2), variant du vert au rouge en fonction du niveau de batterie.

Vous êtes prêt à filmer!

— SHOOT, FILMER

RÉGLAGES

- · Veillez à désactiver l'EIS/OIS de votre appareil et/ou de votre optique.
- · Utilisez une focale fixe. L'usage de zoom est déconseillé.
- · Fixez vos paramètres de prise de vue. Astuce: plus la focale est longue, plus la séquence sera dynamique, plus la vitesse d'obturation devra être élevée (entre 1/150 et 1/1000s).

PRISE DE VUE

· Branchez SteadXP+ et allumez la caméra. Attention : la LED de SteadXP+ doit clignoter pendant toute la durée de la prise de vue (2).

- · En début d'enregistrement, il est conseillé d'effectuer un mouvement brusque de faible amplitude, en visant un arrière plan à plus de 5m et sans premier plan.
- Il est conseillé de débrancher-rebrancher le câble audio entre chaque prise, afin de créer un nouveau fichier de données.

Laissez libre cours à votre imagination!

— ENJOY! PROFITER!

CONFIGURATION LOGICIELLE

- Windows 7, 8, 1, 10
- Mac 10.11 (El Capitan), 10.12 (Sierra)
- · Système d'exploitation 64bits
- · 2Go de RAM disponible

PREMIÈRE UTILISATION LOGICIELLE

Après avoir démarré le logiciel, renseignez l'adresse mail de contact associée à votre commande, ainsi que le numéro de série figurant sur l'étiquette de certification de votre SteadXP+ (SN:XXXXXXX).

TRANSFERT DES DONNÉES VIDÉO

Utilisez la fonction « Parcourir » (Browse) ou laissez le logiciel détecter automatiquement les données vidéo de votre appareil, via son unité de stockage.

TRANSFERT DES DONNÉES STEADXP

- · A l'aide d'un câble USB (non fourni*). branchez SteadXP+ à votre ordinateur, puis démarrez-le. Le logiciel détecte automatiquement les données mouvement de votre SteadXP+ et les synchronise avec les données vidéo de votre appareil.
- · Vous pouvez également les importer via la carte mémoire.

ETAPES DE STABILISATION

- · Input Sélectionnez votre profil caméra. Pour un meilleur résultat, calibrez vos optiques en suivant les instructions du logiciel SteadXP Calibration. Chaque optique doit être calibrée séparément dans le mode d'enregistrement approprié.
- · Svnc Aiustement semi-auto des données image par image, après contrôle visuel, cliquez sur « Lecture » (Play) puis sur « Valider » (Validate).
- · Preview Découpez vos séquences, ajustez vos paramètres de stabilisation, puis cliquez sur « Optimisation » (Optimize).
- · Advanced Choisissez vos options d'export. puis cliquez sur « Rendu » (Renderina).

Plus d'infos sur le logiciel SteadXP sur steadxp.com/manual ainsi que les tutos

(!) PRÉCAUTIONS D'EMPLOI

* NOUS VOUS RECOMMANDONS

- Une carte microSD FAT16 de 2Go 9191AA 2G 07SM1 de Transcend Information Inc.**.
- · Une batterie Li-ion Polymer Battery Pack 3.7V 1180mAh 4.37Wh AHDBT-302 de GoPro®** rechargeable avec un câble USB 2.0 A to Micro B 975111 de Conrad SAS**.
- Un câble audio I 8-BK TRS 3.5mm male to male 7cm de FiiO Electronics Technology Co., Ltd.**.

Consultez les directives des fabricants pour leur utilisation. Après chaque utilisation, éteignez votre caméra et déconnectez SteadXP+.

Températures d'utilisation : 0 / +50°C. Températures de stockage : -10 / +60°C. Taux d'humidité: 80% max. Altitude: 2000m max. SteadXP+ n'est pas étanche.

Votre SteadXP+ ne doit être rechargé que via un port USB 2.0.

Tous les équipements reliés à votre SteadXP doivent être de type TBTS (Très Basse Tension de Sécurité) et être des Sources à Puissance Limitées conformément aux chapitres 2.2 et 2.5 de la norme EN 60950-1 ·2006 + A11 ·2009 + A1 ·2010 + A12 ·2011 + A2 ·2013

Utilisez exclusivement le modèle de batterie recommandé.

Il v a risque d'explosion si la batterie est remplacée par une batterie de type incorrect. Mettre au rebut les batteries usagées conformément aux instructions.

Enlevez la batterie de votre SteadXP+ après chaque usage, et tout particulièrement lors d'un voyage en avion.

Conditions de garanties complètes sur steadxp.com/warranties.

** GoPro, HERO sont des marques déposées par GoPro, Inc. SteadXP SAS n'est pas affilié à GoPro, Inc. Les autres noms et marques sont la propriété de leurs propriétaires respectifs.

SteadXP® Fabriqué en FRANCE

SteadXP SAS - 8a chemin de la Cour 38660 St Hilaire du Touvet Contact: (+33) 4 28 70 00 38

FCC ID: 2ALGS-P16V1 (€





Collecte séparée des produits électriques et électroniques. CAN ICES-3(B) / NMB-3(B) Modèle P16V1

SteadXP+

QUICK START GUIDE

See the complete user manual at steadxp.com/manual Need some help? support@steadxp.com

— PLUG.

BEFORE YOUR FIRST USE

- Insert a microSD or microSDHC memory card (not supplied*), with a capacity of between 1 and 32GB.
- · Insert the battery, model for GoPro® HERO3
- ** (not included *), when charged.
- · For horizon correction, calibrate the gyros of your SteadXP@ by leaving it lit up on a stable surface over the recommended operating temperature range.

CONNECTION

- · Insert SteadXP+ into the flash shoe of your device and secure it with the tightening wheel in alignment with the lens.
- . Turn it on by plugging the audio cable (not included*) into the stereo microphone jack of your device. Option: You can genlock the SteadXP+ by using its RCA input (bi- or tri-level signal) with compatible cameras.
- · At first, the indicator light (LED) of the SteadXP+ will alternate between red and orange (1). After a few seconds, it will flash (2), varying from green to red according to battery level.

You're ready to shoot!

— SHOOT.

SETTINGS

- · Ensure that you disable the EIS/OIS on your device and/or your lenses.
- · Use a fixed focal length. Zooming is not recommended.
- · Set your shooting settings. Tip: The greater the focal length, the more dynamic the footage will be, and the more the shutter speed should be increased (between 1/150 and 1/1000s).

SHOOTING

- · Plug in SteadXP+ and switch the camera on. Warning: The LED light on the SteadXP+ will flash for the duration of shooting (2).
- · At the beginning of shooting it is advisable to make a sudden movement of low amplitude, aiming at a background with more than 5m and without a foreground.
- · It is advisable to disconnect and then reconnect the audio cable between each shot.

in order to create a new data file. Let your imagination run wild!

- ENJOY!

SOFTWARE SYSTEM REQUIREMENTS

- Windows 7, 8,1, 10
- Mac 10.11 (El Capitan), 10.12 (Sierra)
- · 64-bit operating system
- · 2GB of RAM available

USING THE SOFTWARE FOR THE FIRST TIME

After starting up the software, enter the contact email address linked to your order, as well as the serial number found on your SteadXP+ certification label (SN:XXXXXXX).

TRANSFERRING VIDEO DATA

Use the «Browse» function, or let the software automatically detect video data from your device via its storage unit.

STEADXP+ DATA TRANSFER

- Use a USB cable (not included*) to connect SteadXP+ with your computer, then turn it on. The software automatically detects the movement data of your SteadXP+ and synchronizes it with the video data from your
- You can also import data using the memory card.

STEPS FOR STABILIZATION

- · Input Select your camera profile. For best results, calibrate your optics following the SteadXP Calibration instructions. Each lens has to be calibrated separately in the appropriate recording mode.
- · Sync Semi-automated adjustment of the frame-by-frame data. Once you have reviewed it. click on «Plav» and then on «Validate».
- · Preview Split your clips, modify your stabilization settings, then click on «Optimize».
- · Advanced Select your export options, then click on «Rendering».

Find more information on SteadXP software, as well as video tutorials, at steadxp.com/ manual.

(!) PRECAUTIONS FOR USE

* WE RECOMMEND USING

- A 2GB FAT16 microSD card of type 9191AA 2G 07SM1 from Transcend Information Inc.**.
- A rechargeable GoPro®** Li-ion 3.7V 1180mAh 4.37Wh Polymer Battery Pack of type AHDBT-302 with a USB 2.0 A to Micro B 975111 cable from Conrad SAS**.
- · A 7cm, 3.5mm male-to-male L8-BK TRS audio cable from FiiO Electronics Technology Co., Ltd.**. Check manufacturer's directions for use.

After each use, turn off your camera and disconnect SteadXP+.

Operating temperatures: 0/+50°C (+32/122 F). Storage temperature: -10/+60°C (+14/140 F). Humidity: 80% max. Altitude: 2000m max. SteadXP+ is not waterproof.

Charge your battery only via a USB 2.0 port. All equipment connected to your SteadXP must be SELV (Safety Extra Low Voltage) and Limited Power Sources, as defined by chapters 2.2 and 2.5 of standards EN 60950-1 :2006 + A11:2009 + A1:2010 + A12:2011 + A2:2013. Always use the recommended battery type. Use of a battery of wrong type may cause explosion Never use a damaged or flat battery.

Make sure to remove the battery from your SteadXP+ after each use, especially when traveling by air.

IMPORTANT NOTE: FCC Caution Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority the equipment. NOTE: This operate equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For full warranty terms, see steadxp.com/ warranties.

** GoPro, HERO, BacPac are trademarks of GoPro, Inc. SteadXP SAS is not affiliated with GoPro, Inc. Other names and trademarks are the property of their respective owners.

Stead XP® Made in FRANCE

SteadXP SAS - 8a chemin de la Cour 38660 St Hilaire du Touvet Contact: (+33) 4 28 70 00 38

FCC ID: 2ALGS-P16V1 (€





Separate collection for electrical and electronic equipment. CAN ICES-3(B) / NMB-3(B) Model P16V1