

LED Candle Speaker

M0716B



INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY
& RETAIN FOR FUTURE USE

Getting Started

Remove the product from the box.

Remove any packaging from the product.

Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents

- Flameless LED Candle with Wireless Speaker
- USB charging cable
- Instruction manual


Features

- 1. Flameless LED Candle
- Made from Real Wax
- 3. Flickering Flame-Effect
- 4. Built-in Bluetooth Speaker
- 5. Stream wireless music from up to 10 metres away
- 6. Built-in Rechargeable Battery
- 7. Compliments any home décor
- 8. Simple and easy to use

IMPORTANT SAFETY INFORMATION

- 1. Read all instructions before using this product.
- 2. Do not leave this product unattended while connected to the power supply.
- 3. Do not use if product has been dropped or damaged in any way.
- 4. Repairs to electrical equipment should only be performed by qualified personnel. Improper repairs may place user at serious risk.
- 5. Place product on sound, even surface, free of vibrations and away from sources of heat
- 6. Do not put objects into openings.
- 7. Keep free of dust, lint, hair etc.
- 8. Do not use this product for anything other than its intended use.
- 9. Keep this product out of reach of children.
- 10. This product is not a toy.

Description of Parts:



S. No.	Description	S. No.	Description
1	ON/OFF Switch (bottom)	4	LED Light
2	Charging Port	5	Charging LED Indicator
3	Real Wax		

INSTRUCTIONS FOR USE

LED Candle Speaker

For best results, fully charge the product before its first use.

- Connect the USB charging cable (included) to the charging port of the Flameless LED Candle and insert the other end into a port on your computer or similar power source.
- 2. Red Charging LED Indicator turns on indicating that the battery is being charged. It takes around 3 hours to fully charge the device. When the battery is fully charged, LED Indicator will turn to Green.

Turn On/Off the LED Candle Speaker

Slide the ON/OFF switch to turn on/off the candle. Bluetooth speaker turns on/off automatically, when the candle is turned on/off.

Turn the speaker to Bluetooth pairing mode -

- 1. Slide the ON/OFF switch to turn on the speaker. This also turns the LED Candle on.
- 2. You will hear the indication tone, indicating that your speaker is entering the

"pairing" mode.

(Note: Speaker automatically pairs with the previously paired devices)

Pairing your smart phone, tablet etc with the Bluetooth Speaker –

Your **Bluetooth Speaker** can wirelessly stream audio from any Bluetooth enabled device such asn your smart phone, tablet etc within the distance of 26-33 Feet. Simply follow the below steps.

- 1. Slide the ON/OFF switch to turn on the speaker. This also turns the LED Candle on.
- 2. You will hear the indication tone, indicating that your speaker is entering the "pairing" mode.
- 3. Turn on the Bluetooth on your smart Phone or Tablet or Computer.
- 4. It will search for nearby Bluetooth devices.
- 5. You'll find this product in the list of scanned devices as "CANDLE SPEAKER". Tap on "CANDLE SPEAKER" from the list, in order to pair it with your smart phone etc.
- 6. If required, enter the password '0000' to confirm the pairing.
- 7. Once paired successfully, you would hear another indication tone.
- 8. If you fail to pair it within the time frame or you want to pair it with a new source please follows the steps outlined above.

Select your favorite song at the source device (your smart phone, tablet etc) and music would now stream through Bluetooth speaker. All functions, like play/pause/skip forward/skip backward/volume control etc, can be only controlled from the source device.

Do's and Don'ts

Do not play music at excessive levels. Damage to hearing and/or equipment may result.

Specification

Bluetooth version : 4.2 Speaker : 3 Watts

Product Size : Dia. 3"xL6" max.

Product Weight : 8.7 oz

Play time : up to 2 hours
Charge Voltage : DC5V (USB)
Charging time : Up to 3 Hours
Bluetooth Range : 26-33 Feet

Built-In Rechargeable

Battery : 3.7V / 500mAh

(Note: Battery life & charging time may vary based on individual usage, handling & types of

devices connected)

Troubleshooting

Problem	Possible Cause	Solution
Low sound level	Source (Tablet, Mobile Phone,	Adjust volume at source.
	Laptop, etc.) volume too low.	
	Battery dead	Charge the Battery.
Sound distorted	Battery nearly dead	Charge the Battery.
No sound at all.	Source (Tablet, Mobile Phone,	Turn the source on.
	Laptop.) turned off.	
	Speaker turned off.	Turn the speaker on.
	Volume turned down source.	Adjust volume at source.
	Media paused on source.	Play media from source.

Care and Maintenance

Clean the product with a soft, damp cloth. Never use chemicals or hard abrasives. Keep this product away from wet or damp surroundings.

FCC Instructions

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device

must accept any interference received, including interference that may cause undesired operation.