

## Packing List




## Installation Steps



- 1. Select and clean installation position 2. Fix car holder
- 3. Arrange charging cable 4. Insert car adapter to cigar lighter socket
- 5.Insert memory card to device 5.Insert holder to device

## Instruction Manual



- r switch / OK (A)Reset button
- (B)MIC hole
  - (C)TF card slot
- 4.Down select button (D)Magnet DC in/Radiator

3.Up select button

- (E)Wide angel lens
  - (F)Optical coating tempering glass
  - (G)High-definition screen
  - (H)Working condition light
  - (I)Working condition light

## Key features

Button	Operational status	Conventional Functions					
	Power off	Short-press to turn it on					
	Arbitrary state	Long-press to turn it off					
Power	Preview mode	Short-press on "start/stop" to record					
Powei	Main menu	Short-press on "Confirm"					
	Photo mode	Short-press on" Photos-taking"					
	Playback mode	Short-press on "play/pause"					
	Recording state	Short-press on" lock recording"					
Menu	Main menu St	ort-press to change from Mode menu to Setting me					
	Main menu Lo	png-press to change mode from photos to preview to playback					
	Preview/recording/camera	Short-press on "Focus"					
UP	Preview state	Long-press on "180° rotate"					
OF	Menu state	Short-press on "UP"					
	Playing state	Short-press on "accelerate 2X,4X,8X"					
	Preview/recording/camera	Short-press on "Focus"					
Down	Preview state	Long-press on" turn MIC on/off"					
Down	Menu state	Short-press on" Down"					
	Playing state	Short-press on "accelerate 2X,4X,8X"					
RESET	Short-press to reset						
		Notes: The yellow marks are					

## Specifications

Chipsets	NT96658
Sensor	SONY imx322
Lens	F2.0 150 Diagonal Viewing Angle 6 layer glass + IR
Spectacles	Optical coating tempering glass
LCD	1.5" 480x240dots
Resolution/FPS	1080P / 30fps ,720P / 60fps
Battery	Built-in polymer Li-ion Battery
Loudspeaker	8Ω 0.5W
Storage	MAX:64G micro SD
lmage Technology	H.264/.MOV/x4 digital zoom/WDR
ecurity Application	G-sensor/Motion detection /LDWS /Parking Mode
Machine Features	Quick disassembling /Magnet power supply/360 rotation
king Temperature	- 20℃~70℃

#### Using tips

The device has the quick way of dismounting for portability; When it was taken out from the holder, LCD has the selection and notice of "Turn off". So it will turn off automatically without any operations.

#### FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

- following measures:
  -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### Recording Settings menu(Preview>short-press on menu)

-	-			-							-
Resolution	Dyclic recording	WDR WC	₹	🔀 Exposure	Motion detection	Record audio	Parking monitoring system	Off course	∰Date stamp	(C)) G-sensor	(E)
1080FHD1920×1080	Off			+0.0	0,11	011	011	0.11	O.L.	Off	
720P1280x720	3 minutes	On		+5/3 -2/3	Off	Off	Off	Off	Off	High	E
WVGA 848x480	5 minutes	Off		+4/3 -1.0 +1.0 -4/3	On	On	On	On	On	Middle	
VGA 640x480	10 minutes	011		+2/3 -5/3 +1/3 -2.0	_	On	On	OII	On	Low	

## System Settings menu (Preview>short-press on Menu>short-press on menu

	-							
te/Time	Beep sound	🐽 Language	<b>Hz</b> Frequency	Screensavers	License plate	Format	Default settings	V.1.1 Versior
		English/French/Spanish	- COL 1-7	Off				
sted	On	Portuguese/German/Italian	50HZ	1 minute	Existed	Existed	Existed	Existed
sted	Off	Simple- Chinese/Traditiona	60HZ	3 minutes	LAISTEG	LAISTEG	LAISTEG	LAISTEG
	OII	Chinese/Russian/Japanese	UUNZ	5 minutes				

#### Camera setup menu (Preview>long-press on Menu>short-press on Menu)

rsion	apture mode	Resolution	Sequence	mage quality	Sharpnes	Mhite Balance	<b>&amp;</b> Color	iso IOS	<b>E</b> xp	osure	Anti-shaking	Quick preview	📆 Date stamp
	0:1-	3M 2048x1536				Auto			+0	0.0			
ted	Single	2MHD 1920x1080	Off	Superior	Strong	71010	Color	Auto	+2.0	-1/3	Off	Off	Off
	20 1:	VGA 640x480	OII	·		Daylight		400	+5/3	-2/3	. OII		
	2S timer	1.3M 1280x960					-	100	<u> </u>	,			6.1
	- CO!:	12M 4032x3024		Normal	Normal	Cloudy	Black& White		+4/3	-1.0		2 seconds	Date
	5Stimer	10M 3648x2736				Tungsten		200	+1.0	-4/3			
		8M 3264x2448	On	Economy	Soft		Sepia	400	+2/3	-5/3	On	5 seconds	Date/Time
	10Stimer	5M 2592x1944	1			Fluorescent		400	+1/3	-2.0			

Notes: The gray marks are

# are Operation: Preview>>long-press on "Menu" >>long-press on "Menu" again>>short-press on "Menu" Esc: Back to Preview by pressing on "Menu"

#### Votes

O: How to select Micro SD card?

A: Pleases choose branded SD card, the maximal support of which is class 10 Micro SD card-64GB (this card has to be formatted before being used in Windows and it has to be set in FAT32 document system). Recordings will be lost and damaged if defective SD card being used.

Q: How long the car DVR can keep working?

A: Device has a built-in 420mAh polymer battery, and it can provide 60-minute recording without power supplying.

Q: How to use Parking Monitoring System?

A: When the G-sensor of the car DVR has been collided, it will record for 15 seconds automatically and save as an urgent file, The power of the machine is provided by its built-in battery.

O: Could the power supply line be changed?

A: We don't suggest that you change the power supply line according to the feedback from most customers. (Firstly, besides supplying power to the car DVR, our car adapter with double interface also could provide another interface for supplying power; The factory may reject providing maintenance if you have changed the original

Q: Shall we take Installation details into consideration when it is off course?

A: Yes, we should take it into consideration. Open this function when park the car at the middle of the street safely, and put the red identifying frame at the middle of the white line separator. The red frame of the Car DVR will be black in order to complete identification, and it will be the best installation angle at that time; Users would better not to rely on this function for security driving, because it is just an auxiliary function for your reference.

O: Shall we open Car mode function by hand?

A: We needn't to open function by hand when the power is supplied by the Car cigarette lighter for it will start recording when the car runs and stop in 15 seconds when the car flameout.

Q: How to flip the picture when the Car DVR used on SQ holder?

A: Device has an easily shooting access function. You can get 180 rotation pictures by a long-press on " ^" in Preview.

Q: What is to be noticed when users use SD card?

A: The Car DVR will turn off automatically or the recording will lost or be damaged when you take out the TF card whiling recording.

## Video playback menu

elete	╾ Protect	🗐 Photo play					
current	Lock current	2 seconds					
	Inlock curren	5 seconds					
ete all	Lock all	3 Seconds					
ote dii	Unlock all	8 seconds					

User Manual



## How to download APP?

- 1. Manufacturer provide the APP to user .
- 2. For Android OS phone: go to Google play to search "Lerccenker" to download it to install.
- 3. For IOS phone: go to APP Store to search "Lerccenker" to download it to install.

# How to turn on the WiFi (WiFi Off default)

- 1. Two ways to turn on WiFi
- a) Shortcut key: Long press "DOWN" button under Video Mode (recommend)
- b) Turn it on from Setting Menu: Video Mode ->press "Menu"->press "Menu", select WiFi setting to turn it on .
- 2. After turn on WiFi, the ID and PW and will be shown on the screen of DVR as following:



3. After connect WiFi by smart phone , the ID and PW will be disappear and the WiFi icon will be turn to be green .



4. The working distance between DVR and smart phone is about 10 meters max .

## APP connection

- 1. Download and install APP to Android and IOS smart phone.
- 2. Open APP and enter the login page.
- 3. Go to the WiFi setting of smart phone, search the SSID which shown on the DVR screen and connect to it . the PW is 12345678 . Connect it successfully and exit it .
- 4. Back to the APP, you can see the real video from DVR in your APP.