


EXHIBIT C - EUT INTERNAL PHOTOGRAPHS


200i receiver:









EUT – Main Board Bottom View




EUT – BT ANT View










500i receiver:




EUT – Main Board Bottom View


















800i-L receiver:

EUT –Uncover View




EUT - Main Board Top View



EUT - Main Board Bottom View





EUT – BT ANT View



EUT – RF ANT View








800i-H receiver:


EUT –Uncover View









EUT - Main Board Bottom View





EUT – BT ANT View






EUT – Main chip View






900i receiver:



EUT - Main Board Top View







EUT – BT ANT View

