

will be discarded

workout data will be removed

App Operation Instruction

iOS devices: iPhone5, iPad, iPad Mini or higher

Android devices: Android 4.3 or higher with Bluetooth

4.0 or higher with devices memory no less than 1GB

*The stored heart rate data can only be transmitted via

Bluetooth – please download the JAXJOX application

*The device has a memory space for 13 hours of use.

Once the data goes beyond this point, the oldest

non-rechargeable and rechargeable battery

2. Keep batteries and small articles away from

children. If a battery has been swallowed seek

3. The batteries supplied must not be recharged,

reactivated by any other means, dismantled, put

RISK OF EXPLOSION IF BATTERY IS

DISPOSE OF USED BATTERIES ACCORDING TO

REPLACED BY AN INCORRECT TYPE.

disposal at communal collection centers.

immediate medical advice

into fire or short-circuited.

THE INSTRUTIONS

CAUTION

B. Remove the old battery and insert the new

C. Replace the battery door by twisting it clockwise

battery with the +side upwards.

until it is firmly in place.




JOXJOX APP icon

Connect to the App

First Time Connection

1. Turn on the Bluetooth: Setup - Bluetooth - Turn on the Bluetooth ★ Do not try to find or pair with the device on this page.



3.Start a new training session: Dashboard page → ★ → Active



and make sure that the device is functioning properly. The data collected will be uploaded to the application. Please note that once the data has been sent to the application, it will be removed from the transmitter and will not be transmitted a second time.



J N X J O X°

Centrus Park LU5 5BN

IMPORTANT

higher than 30°C.

a.Cleaning of transmitter and strap in a washing

b.Before hand washing the device, detach the

transmitter of Heart Rate Monitor where electrodes

c. While washing the straps, make sure water is no

The transmitter uses 1 x CR2032 3V battery. The battery

is already installed. The battery typically lasts one year.

d.Ironing, bleaching or heating is prohibited.

machine or dryer is strongly prohibited.

are located, this part is not washable.

JAXJOX COPYRIGHT @2016

WWW.JAXJOX.COM

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.