

3.6. Test Photograph

Test Mode : Mode 1: Normal Operation (Adapter: GOE, GS018-120)

Description : Front View of Conducted Emission Test Setup



Test Mode : Mode 1: Normal Operation (Adapter: GOE, GS018-120)

Description : Back View of Conducted Emission Test Setup





Test Mode : Mode 2: Normal Operation (Adapter: Sunny, SYS1544-2412-T3)

Description : Front View of Conducted Emission Test Setup



Test Mode : Mode 2: Normal Operation (Adapter: Sunny, SYS1544-2412-T3)

Description : Back View of Conducted Emission Test Setup





Test Mode : Mode 3: Normal Operation (Adapter: Sunny, SYS1531-2412-W2)

Description : Front View of Conducted Emission Test Setup



Test Mode : Mode 3: Normal Operation (Adapter: Sunny, SYS1531-2412-W2)

Description : Back View of Conducted Emission Test Setup





4.6. Test Photograph

Test Mode : Mode 1: Normal Operation (Adapter: GOE, GS018-120)

Description : Front View of Radiated Emission Test Setup



Test Mode : Mode 1: Normal Operation (Adapter: GOE, GS018-120)

Description : Back View of Radiated Emission Test Setup





Test Mode : Mode 2: Normal Operation (Adapter: Sunny, SYS1544-2412-T3)

Description : Front View of Radiated Emission Test Setup



Test Mode : Mode 2: Normal Operation (Adapter: Sunny, SYS1544-2412-T3)

Description : Back View of Radiated Emission Test Setup





Test Mode : Mode 3: Normal Operation (Adapter: Sunny, SYS1531-2412-W2)

Description : Front View of Radiated Emission Test Setup



Test Mode : Mode 3: Normal Operation (Adapter: Sunny, SYS1531-2412-W2)

Description : Back View of Radiated Emission Test Setup

