
Energizer_®






Energizer.



- FR Le manuel complet et les consignes de sécurité sont disponibles sur le site web :
- El manual completo y las consignas de seguridad están disponibles en el sitio web:
- **EN** The complete manual and the safety instructions are available on the website:
- **PT** Manuais de segurança e instruções completas estão disponíveis no site:
- **RO** Instrucțiuni de manuale și de siguranță complete sunt disponibile pe site-ul:
- **вс** пълни ръчни и безопасност, инструкции са на разположение на интернет страницата:
- IT Manuale di istruzioni e di sicurezza completi sono disponibili sul sito web:
- Das vollständige Benutzerhandbuch und Sicherheitshinweise sind auf der Website zur Verfügung:
- **EL** πλήρεις οδηγίες χρήσης και ασφάλειας είναι διαθέσιμα στην ιστοσελίδα:
- **RU** Полные инструкции по эксплуатации и безопасности доступны на веб-сайте:
- **FI** Käyttöohje ja turvaohjeet ovat saatavilla:
- **NL** volledige handleiding en veiligheidsvoorschriften zijn beschikbaar op de website:
- **VI** Tay hoàn toàn và an toàn hướng d_n có sẵn trên trang web:
- HI पूर्णमैन्अलऔरस्रक्षानिर्देशोंवेबसाइटपरउपलब्धहैं
- **TL** Full manual at kaligtasan tagubilin ay makukuha sa website:
- **SV** Helt manuell och säkerhetsanvisningar finns på hemsidan:
- **TR** Tam manuel ve güvenlik talimatları web sitesinde mevcuttur:

UR مكمل دستى اور حفاظت كى بدايات كى ويب سائٹ پر دستياب بيں: AR تتوفر دليل والسلامة الكاملة الإرشادات التي تظهر على شبكة الإنترنت:

0




- **FR** Retirer le couvercle de la batterie
- ES Quitar cubierta de la batería
- **EN** Remove battery cover
- PT Retire a tampa do compartimento da bateria
- **RO** Îndepărtaţi capacul bateriei
- **BG** Махнете капака на батерията
- **IT** Rimuovere coperchio batteria
- **DE** Entfernen Sie den Batteriedeckel
- **EL** Αφαιρέστε το καπάκι της μπαταρίας
- **RU** Снимите крышку батарейного отсека
- FI Avaa akkukansi
- **NL** Verwijder de batterijdeksel


KR

- **VI** Tháo vỏ pin
- HI बैटरीकवरनिकालें
- TL Alisin ang takip ng baterya
- JA バッテリーカバーを取り外す
- **SV** Ta bort batteriluckan
- TR Pil kapağını çıkartın
- ZHX 取出电池盖
- ZHO 取出電池蓋


2



- FR Insérez la carte SIM
- **ES** Insertar tarjeta(s) SIM
- **EN** Insert SIM card(s)
- PT Insira o(s) cartão(ões) SIM
- RO Inseraţi cartela(lele) SIM
- **BG** Поставете SIM картата(ите)
- IT Inserire scheda/schede SIM
- **DE** Setzen Sie die SIM-Karte(n) ein
- **EL** Εισάγετε την/τις κάρτα/ες SIM
- **RU** Вставьте сим-карту (карты)
- FI Aseta SIM-kortti
- **NL** Plaats SIM-kaart(en)
- **KR** SIM
- **VI** Lắp thẻ SIM
- **HI** सिमकार्डडालें
- **TL** Ipasok ang SIM card (s)
- JA SIM カードを挿入する
- **SV** Sätt i SIM-kortet (s)
- **TR** SIM kartı takın
- ZHX 插入 SIM 卡
- ZHO 插入 SIM 卡




- FR Insérez la carte mémoire SD
- **ES** Insertar tarjeta de memoria SD
- **EN** Insert SD memory card
- PT Insira o cartão de memória SD
- RO Introduceți cardul de memorie SD
- **BG** Поставете SD картата памет
- IT Inserire scheda di memoria SD
- **DE** Setzen Sie die SD-Karte ein
- **EL** Εισάγετε την/τις κάρτα/ες SD
- **RU** Вставьте SD-карту памяти
- **FI** Aseta muistikortti
- **NL** Plaats SD-geheugenkaart
- KR SD
- **VI** Lắp thẻ nhớ SD
- **HI** एसडीमेमोरीकार्डडालें
- TL Ipasok ang SD memory card
- JA SD メモリーカードを挿入する
- **SV** Sätt SD-minneskort
- **TR** SD bellek kartı takın
- ZHX 插入 SD 记忆卡
- ZHO 插入 SD 記憶卡



- FR Insérez la batterie
- **ES** Insertar batería
- **EN** Insert battery
- PT Insira a bateria
- RO Introduceţi bateria
- **BG** Поставете батерията
- **IT** Inserire batteria
- **DE** Setzen Sie die Batterie ein
- **EL** Εισάγετε τη μπαταρία
- **RU** Вставьте батарею
- FI Aseta akku
- **NL** Plaats batterij
- KR
- **VI** Lắp pin
- HI बैटरीडालें
- **TL** Ipasok ang baterya
- JA バッテリーを挿入する
- **SV** Sätt i batteriet
- **TR** Pili takın
- ZHX 插入电池
- ZHO 插入電池

E



- FR Insérez le câble USB et laissez en charge pendant 8 heures
- **ES** Insertar el cable USB y cargar por 8 horas
- **EN** Insert USB cable and charge for 8 hours
- **PT** Insira o cabo USB e carregue durante 8 horas
- **RO** Conectați cablul USB și încărcați telefonul timp de 8 ore
- **BG** Поставете USB кабела и заредете за 8 часа
- IT Inserire cavo USB e caricare per 8 ore
- **DE** Stecken Sie das USB-Kabel ein und laden Sie für 8 Stunden
- **EL** Εισάγετε το καλώδιο USB και φορτίστε για 8 ώρες
- **RU** Вставьте USB-кабель и заряжайте 8 часов
- FI Aseta USB-kaapeli ja lataa 8 tuntia
- NL Sluit USB-kabel aan en laadt 8 uur op
- **KR** USB
- 8
- VI Lắp cáp USB và sạc trong 8 giờ
- HI 8 घंटेकेलिएयूएसबीकेबलऔरचार्जडालें
- **TL** Ipasok and USB cable at singil para sa 8 oras
- JA USB ケーブルを挿入して 8 時間充電する
- **SV** Sätt USB-kabel och ta betalt för 8 timmar
- TR USB kablosunu takın ve 8 saat şarj edin
- ZHX 插入 USB 电缆并充电 8 小时
- ZHO 插入 USB 電纜並充電 8 小時

Please remember to obey relevant rules and regulations whenever use your phone. This will prevent bad effect from you and the environment.

General security

	When driving, riding your bike or walking, do not use headphones or earphones. Your attention could be diverted, which may cause an accident and be against the law in certain geographical areas. For safety precautions do not use your phone while driving, always stay aware of your surroundings. Follow all safety instructions and regulations relating to the use of your device when you are driving a vehicle.
A	Don't use at petrol stations.
	Keep your phone at least 15 mm away from your ear or body while making calls.
	Your phone may produce a bright or flashing light.

	Small parts may cause a choking.
**	Don't dispose of your phone in fire.
19	To avoid any hearing damage, do not listen to high volume levels for an extended. Excessive sound pressure from earphones and headphones can cause hearing loss.
C.	Avoid contact with anything magnetic.
	Keep away from pacemakers and other electronic medical devices.
	Avoid extreme temperatures.
4	Switch off when asked to in hospitals and medical facilities.
争	Avoid contact with liquids. Keep your phone dry.



Switch off when told to in aircrafts and airports.



Don't take your phone apart.



Switch off when near explosive materials or liquids.



Only use approved accessories.



Don't rely on your phone for emergency communications.


Look at the adapter regularly, specifically at the plug and the layer to detect any damages. If the adapter is damaged, you can't use it until it's fixed.

Plug in the adapter to a power outlet which is easily accessible. Always unplug the adapter after using it.

Use only the adapter provided with the device.

Warning electrical hazard

To avoid serious injury, do not touch the plug of the charger!



To disconnect a charger or an accessory, pull the plug, not the power cable.

The power module is the element that allows you to disconnect the product.

The power plug must stay easily accessible.

Do not expose your device to direct sunlight, like on your car's dashboard, for example.

In case of overheating do not use the device.

Be careful when using the device while walking.

Do not subject the device to severe impact or drop it from high position, it could cause damages or malfunctions.

Do not disassemble, modify or fix the device by yourself.

To clean the device use a clean and soft rag. Do not use any chemical product or detergent.

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output. Before a new model phone is a available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body)as required by the FCC. For body worn

operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that Contains no metal and that positions the handset a minimum of 5mm from the body. Noncompliance with the above restrictions may result in violation of RF exposure guidelines.

م.م.ذ.ش لغوغ قائدر شال قور اجت تامال عيه عرفال التامال على او يالب لغوغ ,لغوغ ,لغوغ Google, Google Play and other marks are trademarks of Google LLC.

Energizer.

إن إنرجايزر و بعض تصاميم الجرافيك تعتبر علامة تجارية مملوكة لشركة انرجايزر براندز ذات المسئولية المحدودة و الشركات التابعة لها و يتم استخدامها بتصريح من شركة افونير للاتصالات أما فيما يتعلق بأي أسماء أخرى فهي علامات تجارية مملوكة لأصحابها ، افونير للاتصالات أو إنرجايزر براندز ذات المسئولية المحدودة غير تابعين لأي من أصحاب هذه العلامات

© 2017 Energizer. Energizer and certain graphic designs are trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by Avenir Telecom©. All other brand names are trademarks of their respective owners. Neither Avenir Telecom© nor Energizer Brands, LLC is affiliated with the respective owners of their trademarks.