# Energizer HARDINGE





FR Guide de Démarrage Rapide

ES Guía de Inicio Rápido

EN Quick Start Guide PT Guia de Início Rápido

RO Ghid de Pornire Rapidă

**BG** Наръчник за бързо начало

Guida di Avvio Rapido

**DE** Kurzanleitung

**EL** Σύντομος Οδηγός Έναρξης **RU** Руководство для быстрого старта

FI **Pikaopas** 

**NL** Snelle Start Handleiding UR کتاب چہ برائ ے فوری ر منمائ ی

AR دليل البدء السريع

# **Energizer**




ED	Le manuel	complet et	les consignes	de sécurité sont	dienoniblee eur	le cite web

- El manual completo y las consignas de seguridad están disponibles en el sitio FS
- EN The complete manual and the safety instructions are available on the website:
- РΤ Manuais de segurança e instruções completas estão disponíveis no site:
- RO Instructiuni de manuale si de sigurantă complete sunt disponibile pe site-ul:
- пълни ръчни и безопасност, инструкции са на разположение на интернет RG
- Manuale di istruzioni e di sicurezza completi sono disponibili sul sito web: IT
- Das vollständige Benutzerhandbuch und Sicherheitshinweise sind auf der Website DE
- FI πλήρεις οδηγίες γρήσης και ασφάλειας είναι διαθέσιμα στην ιστοσελίδα:
- RU Полные инструкции по эксплуатации и безопасности доступны на веб-сайте:
- FT Käyttöohie ia turvaohieet ovat saatavilla:
- NL volledige handleiding en veiligheidsvoorschriften zijn beschikbaar op de website: 전체 설명서 및 안전 지침은 웹 사이트에서 볼 수 있습니다. KR
- Tay hoàn toàn và an toàn hướng dẫn có sẵn trên trang web: VI पर्ण मैनअल और सरक्षा निर्देशों वेबसाइट पर उपलब्ध हैं: HI
- TI Full manual at kaligtasan tagubilin av makukuha sa website:
- JA 完全なマニュアルおよび安全に関する指示は、Webサイトで入手できます。
- sv Helt manuell och säkerhetsanvisningar finns på hemsidan:
- TR Tam manuel ve güvenlik talimatları web sitesinde mevcuttur:


HR






- FR Retirer le couvercle de la batterie
- FS Oultar cubierta de la batería
- EN Remove battery cover
- PT Retire a tampa do compartimento da bateria RO
- Îndepărtați capacul bateriei BG Махнете капака на батерията
- IT Rimuovere coperchio batteria
- DE Entfernen Sie den Batteriedeckel
- EL. Αφαιρέστε το καπάκι της μπαταρίας
- RU Снимите крышку батарейного отсека
- FI Avaa akkukansi
- NI. Verwijder de batterijdeksel
- 배터리 덮개 제거 KR
- VΙ Tháo vô pin н
- ब**ै**टरी कवर ननकालें
- TL Alisin ang takip ng baterya バッテリーカバーを取り外す
- JA
- SV Ta bort batteriluckan
- TR Pil kapağını çıkartın






- FR Insérez la carte SIM
- ES Insertar tarieta(s) SIM
- FN Insert SIM card(s)
- PT Insira o(s) cartão(ões) SIM
- RΩ Inserati cartela(lele) SIM
- BG Поставете SIM картата(ите)
- IT Inserire scheda/schede SIM DF Setzen Sie die SIM-Karte(n) ein
- EL. Εισάγετε την/τις κάρτα/ες SIM
- RU Вставьте сим-карту (карты)
- FI Aseta SIM-kortti NL Plaats SIM-kaart(en)
- KR SIM 카드 산인
- VΙ Lắp thẻ SIM
- н ससम्बर्ग र**्**ालें
- TL Ipasok ang SIM card (s)
- SIM カードを挿入する JA
- sv Sätt i SIM-kortet (s)
- TR SIM kartı takın



- FR Insérez la carte mémoire SD ES Insertar tarieta de memoria SD
- EN Insert SD memory card
- PT Insira o cartão de memória SD
- RO Introduceți cardul de memorie SD BG Поставете SD картата памет
- IT Inserire scheda di memoria SD
- DE Setzen Sie die SD-Karte ein
- EL Εισάγετε την/τις κάρτα/ες SD
- RU Вставьте SD-карту памяти
- FI Aseta muistikortti NL Plaats SD-geheugenkaart
- KR SD 메모리 카드 삽입
- VI Lắp thẻ nhớ SD
- HI एसर्ी में मोरी कार्न र्ालें TL Ipasok and SD memory card
- TL Ipasok ang SD memory card JA SD メモリーカードを挿入する
- SV Sätt SD-minneskort
- TR SD bellek kartı takın



- FR Insérez la batterie
- ES Insertar bateria EN Insert battery
- PT Insira a bateria
- RO Introduceti bateria BG Поставете батерията
- IT Inserire batteria DF Setzen Sie die Batterie ein
- EL Εισάγετε τη μπαταρία
- RU Вставьте батарею FI Aseta akku
- NL Plaats batterij
- KR 배터리 삽입
- VΙ Låp pin
  - ब**ै**टरी र**़ा**लें н
  - TL Ipasok ang baterya JA バッテリーを挿入する
- sv Sätt i batteriet
- TR Pili takın

UR AR





- FR Insérez le câble USB et laissez en charge pendant 8 heures
- ES Insertar el cable USB y cargar por 8 horas
- FN Insert USB cable and charge for 8 hours PT Insira o cabo USB e carreque durante 8 horas
- RO Conectati cablul USB și încărcați telefonul timo de 8 ore
- RG Поставете USB кабела и заредете за 8 часа
- IT Inserire cavo USB e caricare per 8 ore
- DF Stecken Sie das USB-Kabel ein und laden Sie für 8 Stunden
- EL Εισάνετε το καλώδιο USB και φορτίστε για 8 ώρες
- RU Вставьте USB-кабель и заряжайте 8 часов
- FI Aseta USB-kaapeli ja lataa 8 tuntia
- NI. Sluit USB-kabel aan en laadt 8 uur op
- KR USB 케이블음 넣고 8 시간 동안 충전하십시오 Lắp cáp USB và sạc trong 8 giờ
- VΙ
- н ८ घंटे के सलस्थएसबी केबल औरचार णरालें
- TI Ipasok and USB cable at singil para sa 8 oras
- USB ケーブルを挿入して 8 時間充電する JA
- SV Sätt USB-kabel och ta betalt för 8 timmar
- TR USB kablosunu takın ve 8 saat sari edin

کو اکس بک ککبا کو داخل کرک اور 8 گھنٹوں کے لکے چارج کرک أدخُل لأنال USB وقم بالأشرة لمردة 8 سراعات

#### SECURITY INFORMATION

Please remember to obey relevant rules and regulations whenever use your phone. This will prevent bad effect from you and the environment.

#### General security

When driving, riding your bike or walking. do not use headphones or earphones. Your attention could be diverted, which may cause an accident and be against the law in certain geographical areas. For safety precautions do not use your phone while driving, always stay aware of your surroundings. Follow all safety instructions and regulations relating to the use of your device when you are driving a vehicle. Don't use at petrol stations. Keep your phone at least 15 mm away from your ear or body while making calls. Your phone may produce a bright or

flashing light.



Small parts may cause a choking.



Don't dispose of your phone in fire.



To avoid any hearing damage, do not listen to high volume levels for an extended. Excessive sound pressure from earphones and headphones can cause hearing loss.



Avoid contact with anything magnetic.



Keep away from pacemakers and other electronic medical devices.



Avoid extreme temperatures.



Switch off when asked to in hospitals and medical facilities.



Don't rely on your phone for emergency communications.

Look at the adapter regularly, specifically at the plug and the layer to detect any damages. If the adapter is damaged, you can't use it until it's fixed.

Plug in the adapter to a power outlet which is easily accessible. Always unplug the adapter after using it.

Use only the adapter provided with the device.

#### Warning electrical hazard

To avoid serious injury, do not touch the plug of the charger!

Disconnect the charger when you do not



use it.

To disconnect a charger or an accessory,
pull the plug, not the power cable.

The power module is the element that allows you to disconnect the product.

The power plug must stay easily accessible.

Do not expose your device to direct sunlight, like on your car's dashboard, for example.

In case of overheating do not use the device.

Be careful when using the device while walking.

Do not subject the device to severe impact or drop it from high position, it could cause damages or malfunctions.

Do not disassemble, modify or fix the device by yourself.

To clean the device use a clean and soft rag. Do not use any chemical product or detergent.

# When the phone reaches its end of life, please remove the $% \left( \mathbf{r}\right) =\left( \mathbf{r}\right)$

battery before discarding the phone. This product is subject to that promote the re-use and recycling of used

lnis product is subject to that promote the re-use and recycling or used electrical and electronic equipment. This product required the extraction and use of natural resources and may contain hazardous substances. The symbol

above, on the product or its packaging, indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handling it over to a designated collection point for the recycling

of waste electrical and electronic equipment.

The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

For more information about where you can drop of your waste equipment for recycling, please contact your local city office, your household waste disposal service, or the store from which you purchased the product.

#### Recommendations:

- Do not disassemble, open or tear up the device or the batteries.
- Do not expose the product or the battery to heat or fire. Avoid storage the device directly to the sunlight.
- Do not short-circuit a battery. Do not stock batteries in a drawer where it could short-circuit between each other or get in contact by any other metallic objects.
- Do not cause mechanical shocks to batteries.
- In case of the leak, do not let the liquid get in contact with your eyes or skin. If that happens wash with clear water the affected zone and seek medical advice.
- Follow the marks plus (+) and minus (-) on the battery and the device and ensure that the use is correct.
- Do not use any accessories or batteries that are not made to be used with the device.
- · Monitor the use of batteries by children.
- Consult a doctor immediately in case of ingestion of an element or a battery.
- Always buy the battery recommended by the manufacturer of the device.
- Always maintain the product and the battery clean and dry.
- Wipe the terminals of the product or the battery, if it became dirty, with a clean and dry rag.

- It is necessary to charge the battery before its use. Always use
  the charger and read the manufacturer instructions or the
  manual of the device for the instructions regarding charging.
- . Do not leave a battery charged when it's not going to be used.
- After long periods of storage, it may be necessary to charge and discharge the battery several times in order to achieve maximum performance.
- Always keep the original documentation of the device, you might need it later for future reference.
- If it's possible, take out the battery of the device when it's not used
- Do not store your device in extremely hot or cold places like inside of a car during the summer. It might damage the device and cause explosion of the battery. It's recommended to use the device in a range of temperatures between 5°C and 35°C.

### Prevention of hearing loss

There are irreversible risks of hearing loss if the receiver, the earphones, the loudspeaker or the hands-free kit are used at a high volume. Adjust the volume to a level that does not present danger. Over time, you may accustomed to using a higher volume, but this may cause damage to your hearing. If you hear buzzing or muffled speech, stop using the devices and consult a specialist. The higher the volume, the more quickly your hearing may be damaged. Specialists give the following recommendations:

- Minimize high volume of headphones, the speaker or handset.
- Avoid increasing the volume to cover a noisy environment.
- Decrease the volume if you cannot hear people speaking near you.

#### Getting started

#### 1. Installing the SIM Card and Calling Phone

A SIM card carries useful information, including your mobile phone number, network information, contacts data, and short messages data.

Touch the Phone icon on the Home screen or in main menu interface.

Three tabs are listed at the top of the screen. Select the phone tab and you can find a dial pad screen where you can input phone number to originate

# 2. Connecting to WI-FI networks

a call.

WI-FI is a wireless networking technology that can provide

Internet access at distances of up to 100 meters, depending on the WI-FI router and your surroundings.

Touch Settings>Network>WI-FI. Check WI-FI to turn it on. The phone scans for

are indicated with a Lock icon.

3. Bluetooth

Pairing and connection of Bluetooth headset.

# 4.Browser

You can use browser to view webpage and search for information on the web.

5.Camera you can touch the "Camera" icon to take a photo, Drag the "Video" to the right, you can switch to the Video mode

available WI-FI networks and displays the names of those it finds. Secured networks

Can switch to the video mode.

# Note: you can also touch the upper right icon to switch sub camera 6. FM Radio

Please plug in the compatible earphone to the device and then turn on the radio. The earphone cable can be used as FM Antenna. Please adjust appropriate volume when listening to the radio. Continue to use higher volume is harmful for your ear.

# 7. Music

plays audio files that are stored on your phone's SD card, so before you

open Music, you must copy audio files from your computer onto the SD card. Music supports a wide variety of audio file formats, so it can play music that you purchase from online stores, music that you copy from your CD collection, and soon.

#### 8. Messages

Can use Messages to exchange text messages (SMS) and multimedia messages (MMS) with your friends on their mobile phones.

#### 9. Google

Can search and view something in phone or webpage after connect with internet through this function.

Notice: Observe the national local regulations in the location where the device is to be used. This device may be restricted for use in some or all member states of the European Union (EU)

#### Notes:

- Due to the used enclosure material, the mobile phone shall only be connected to a USB Interface of version 2.0 or higher. The connection to so called power USB is prohibited.
- The adapter shall be installed near the equipment and shall be easily accessible.
- Do not use the mobile phone in the environment at too high or too low temperature, never expose the mobile phone under strong sunshine or too wet environment. The suitable temperature for the phone and accessories is -10°C-55°C.
- When charging, please place the phone in an environment that has a normal room temperature and good ventilation. It is recommended to charge the phone in an environment with a temperature that ranges from 5°C~25°C. Please ensure to use only the charger offered by the manufacturer. Using unauthorized charger may cause danger and violate the authorization of the phone and the quarantee article.
- CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED WITH AN INCORRECT TYPE. DISPOSE USED BATTERIES ACCORDING TO THE INSTRUCTIONS

- Excessive sound pressure from earphones and headphones can cause hearing loss.

For more information you can go to www.energizeyourdevice.com

Additional information about electromagnetic fields and public health are available on the following site. http://www.who.int/pehemf

Your telephone is equipped whit a built-in antenna. For optimal operation, you should avoid touching it or degrading it.

As mobile devices offer a range of functions, they can be used in positions other that against your ear. In such circumstances the device will be compliant whit the guidelines when used with headset or USB data cable. If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the phone at least 1.0 cm away from the body.

# FCC Warning:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for

a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to

—Consult the dealer or an experienced radio/TV technician for help.

which the receiver is connected

# Specific Absorption Rate (SAR) information

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. Before a new model phone is a available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, tests for each phone are performed in positions and locations(e.g. at the Limb and worn on the body), as required by the FCC.

For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 10mm from the body. Non-compliance with the above restrictions may result in violation of RF exposure guideline.

# مظاومات لحراية

پرچى تنظر انباع لۇواغ والىتالىرپات ذات الىرلەللىم اسرىتخىچە ماتىفك سروف پودىي تاك لىرى مزح لىنائېر لىرېنى منك ومن لىبور؛

## األمن العام

	عند لؤنيادة أو راهوب الدراجة الخاصرة بله أو المؤني ل سنتخم سماجات الرفس أو سماجات الذن. قد يهنجول ارتباط مها قد بوربب حادث وقد يافين ضد الحازون نفر بحض الحزاطق الرجخ المربة راحيجهالت المراجة أن مرديخم ماشلة الناء القوادة والنبد طويا النبورة المرجهاة من حوالك. "لتبخ ججيع منافيهات المراجة واللواناح البنائجة بالماريخام الرجاد الخاص بلك عنهما " يقود المرتباءة			
A	ل ئىرينځېر لىڅتف نىي محطات البيززين.			
1-0	ليؤي النفك بهجيها عن اللذن أو الجهرم مجرالة 15 لجمع على الدقيل النزاء إجراء لمطالحات			
	يْد 'بچىرېر «انتىڭ ضرو ءًا سراط'غا أو ' وابېضرا			





نظر لدى المجول بانتظام وببخصرة عند قابس المحرباء والطبقة للكشف عن أبس المحرباء والطبقة للكشف عن أب أبض أب المح أي أضرار. فن حالة تنف المحول، أن يكنك استخطه جنو ينم إصلاح أن المحول أن مبدومان المحول أن مبدومان المحول أن مبدومان المحول المحو





افسل لشاحن عند عدم استخامه

لفصل الشراحن أو أحد البلحقات، اسحب القابس واليس البل المامة ق

وحدة الطاقة هي العنصر الذي يسمح لك بفصرل البنائج.

. يجب أن يِدِون مِوبِس الطاقة سلى الوصول

# ل تعرض ج\ازك الشرعة لشهس لهبشرة على سبول لهشل مثل على لوحة قهادة سهارتك

ل تستخم الجهاز في حالة ارتضاع درجة الحرارة

كن حذراً عند استخلم الجداز أنناء المشي

ل تعرض الجواز لتأذير فرديد أو إسرة الحد من مكان عال ألن ذلك يومكن أن مدر وافتر الد أو أعطال

. پسهب اضرار أو أعطال

ل تفكك أو تعلل أو تصلح الجداز من قبل نفسك

لتنظيف الرجماز استخدم قبطشة نظيفة وناعمة

ل تستخدم أي منتج كيم وياي أو منطف

# (SAR معدل المبتصاص المحد )سار

#### عرجي تخصيص بعض الوقة لقراءة هذا القبرم الممم

#### الحوجات الالسلكية

ينه طلب نائيل البخث ل للمخاوير العوارية أو لخرجيه الدوروسي 53/2014 الدوروسي من جهيرع طرازات العواشف المحجولة ؤبدأ أن ينه طرح ا نب العروق. حجاجية صحة ومرالعة العرستينم أو أي شرخص آخر دو شريط أمارين ل

يئوافق هذا الجاز مع الإبرشادات الدولية للتعرض للموجات الاسالكية

جهازك البرجيول .و جهاز ايرسال واستؤيال البرلمائي. وهو جمسهم بستهيث ل بينتجارز حدود الت غرض المدجرة الدارائية: إلمستود الباريائية بنه إلىجرالت المدروغ للجمائيوبريجا النهاز بمنزمين بسا المبدئين المدروبية المولوقة تم وضرع المبدلين المدروبية، من زياد مرتفظة علميتية ميدندانية الالمستودة وتشربه دامش آمان المادري يحفف إلى (DNIRP الدارية المجاورة بن الشرخاع كريد العزيد

ترينخ الرشادات التوكن للهوجات الابرائادية وحدة قوان توكف بالدم مجال الهتصاص وَبِدَاغُ الحِ الدُّمري لم عِلى الهتصراص المرحد للأرجوزة المرجولة 2 وات. SAR المحد أو مرار المجدد الدُّمري المعال المتصراص المرحد الله على المحدد المرجولة 2 وات. المحدد أو مرار

ئجرى اختبارات مجدل الجتصراص المحدد بالربتخاء اوضراع تشاغيل قوالرية للتجاز الذي يؤوم ببارسال الموجات عزد أغلى مرستوى قدرة مصردق له دني ججرع نطاقات المتردد للمختبرة

تم إجراء الإنجاز مخل المختصوص المجد على الجهم عند مرافة الفصال نطباغ 1.0 مرج المالية المهدى الشروبيوية المنتجرف المكرديات الالرائموة النواء غلوقة ليس المعقف نتو الجهربه ويجب وضرع المجاذ على الوقل سيدة المساقة ميها عن المجربير إذا الانت أن نسرت في المهاشة من المهاشة المهادال لهما أي يزنج تنور بالرينجالية دو غلبي من أي مرجون وأنه يضرع المعقف ني المهاشة المهادال لهما منها عن المجربة

www.energizeryourdevice.com لبزيد من المطورات يبادنك زيارة هوقع

يَنترنر مغومات إضافتية عن المجالت للمورمغ لطويه ولصرحة العاهة على لعوق التالي. http://www.who.int/peh-emf.

ينم تزويد النفك بموائي مدمج. من أجل التشغيل الهشل يجب تجزب لهس أو تحطيمه

والن اللجزة الزؤلة نتؤم مجهوعة من لوظليف نديان استخداجا فنه أوضاع أخرى غوير وضرعا غلى افزلك فنه بشل هذه المظروف، سروف بالدن الحياز بشواف مع المهبلدي المتوجهوية إذا لدن تدريخهم لمبتى أخر USB. يحد استخداج مع سهاعة الرأس أو المال سيوان وير اس سي تائد من أن أي بزنج تنؤم باستخداء دو خال من أي مجدن وأنه يشرغ للمشف على المؤلل على مرات والدي برنات 1.0 سر بطان على الحيار على



إن از جايزر و بعض تصاميم البرافيك تعبر علامة تجارية معلوكة لشركة انججايزر براندز ذات المسئولية للمعدودة و الشركات الثابعة لها و يتم استخدامها بالتصريح من شركة افينيز للاتصالات أما قيما يتعلق باتن اسعاء آخرى فهي علامات تجارية معلوكة لاصحابها ، افونير للاتصالات أو ايزجايزر براندز ذات المسئولية للمحدودة غير تابعين لأي من أصحاب هذه العلامات

©2017 Energizer. Energizer and other marks, including graphics, are trademarks of Energizer and are used under license by AVENIR TELECOM®. All other trademarks, brand names or product names are the property of their respective owners and are not affiliated with Energizer or AVENIR TELECOM®.