
FY-35 User Manual

Thank you for purchasing Bluetooth Mini Speaker from us. Please read the following instructions to learn how to configure and use more effectively your product.

Product Overview



Φ Luminous body	
Ø Hole for wearing rope	The hole is for wearing rope
3 LED light controller	a. Short press to change led light mode, there are 6
	LED light mode in total
	b. Long press to turn on/off led light.
⊕Forth/Volume up	a. Short press to move to next track or station.
	b. Long press to increase volume.
⑤Play/Pause/Mode	a. Short press: to play or pause. Under Bluetooth mode,
	to receive or reject incoming calls.

h Long pres	ss: to transfer from Bluetooth to TF
card/AUX n	
c. Iwins spe	aker feature: Two devices are under
bluetooth m	ode, double-click "one of them to pair
each other s	pontaneously, user could connect twins
speaker by o	ellphone bluetooth after both devices pair
each other s	uccessfully.
(Note: Be	patient, it will take time for first pairing
twins featur	
	<i>'</i>
© Power on/on	ng the key 3S to turn on/off the speaker. Blue
light on who	en it powers on.
	ess to go back to last track.
b. Long pr	ress to decrease volume.
&Micro USB charging port	
9 Microphone	
10 USB connector	
† TF card connector	
☐ Charging indicator	
☐ Aux Connector	
- Hax Connector	

TF Card Mode

Turn on the speaker, plug in TF card in the slot, it begins streaming music. Press the key "III" to play/pause; press the key "III" to go back to last track or decrease volume; press the key "III" to move on to next track or increase volume.

Bluetooth Mode

Turn on speaker. Bluetooth works spontaneously, searching previous pairing Bluetooth set. If the speaker fails to link, it starts pairing other Bluetooth devices. In this case, turn on your Bluetooth device to search the speaker. (The PIN code is "0000"). Please choose bluetooth pairing name "xxxx" from the list of found devices. Music streams after pairing successfully. Should there is incoming call, you can short press "III"

to receive or reject. Double-click "" to re-dial last call.

AUX Mode

Plug one end of 3.5mm cable into AUX slot of the speaker and the other end into audio slot of Mobile Phone, Notebook, Tablet PC, MP3/MP4 Player etc. After that, you'll be able to enjoy the music.

Charging

Plug the charging cable into Micro USB slot of the speaker, USB slot of PC or other USB slot of chargers to get charged. When the speaker is being charged, indicator light turns red. Once it is fully charged, indicator light turns off. (We'd suggest users turning off the speaker while charging. It takes longer time to get completely charged if the speaker works when being charged.)

Warnings

- 1. If the speaker cannot be turned on after pressing the POWER key, or it turns off on turning on, the user shall check whether it is powerful. If it's out of power, please get it charged and try again later.
- 2. Please do not increase the volume of your Mobile Phone, PC, MP3/MP4 Player, CD, DVD etc to a large extend, or sonic boom or sound distortion may occur. In case of sonic boom or sound distortion, please decrease volume either of Mobile Phone, PC, MP3/MP4 Player, CD, DVD or the speaker. The sound gets normal soon.
- 3. If Bluetooth device of Mobile Phone, PC etc fails to link to the speaker or if fails to playing music after being connected, the user shall check if he/she enters the correct PIN code or if Bluetooth device of his/her Mobile Phone, PC etc supports A2DP.

Technical Information

Sound Track	Mono
Function	TF Card, AUX, Bluetooth, LED
Bluetooth	V4.2
Power Supply	DC 5V,lithium battery
Battery	3.7V 2000MAH lithium battery
Output	5W
Frequency	150Hz-18KHz

Diameter of Loudspeaker	52mm
Charging time	Around 2-3 hours
Playing time	Around 6-10 hours
Anti-magnetic function	Available
Material	PC + ABS plastic

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - -Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.