

Label location:

Positioned on the external surface of the enclosure at the rear and centred towards the bottom.

