User Manual

Quad-coreMiniPC:CR9/S CR11/S

Table of contents 9. Web Browsing 10. Local audio &video playback 12.Switch input methods ····· 13.RK-RemoteControl······· 5.9ScreenShot Setting ·····

Quad-core MiniPC: CR9S PLUS

4.Main Screen Introduction

Click to show up all the installed program

🔐 🏮 🧓 🔝 🚾

■If the first desktop page file with icon, then pull or rolling mouse will move it to second desktop page;

In the system user can setup according to their own requirements, such as network connection, language, input methods, video output resolution, When opened WIFI player would search available wireless router signals within 20 meters ,user just choose a router and input correct password then could browse internet; if the router without nd output and check storage space.

Declaration

●The user manual includes all the information of safe and correct operation instruction. To avoid accident and product damaged, please make sure go through all the

upgrading otherwise it will cause operation system error.

Do not dismantle the device. Do not clean it by alcohol,

We keep the right to upgrade and modify the product.

the warranty and after service. The users have to take care of their data in the device by themselves. We do not responsible for any data or related lost.

e pictures in the instruction are just for reference.

e product is not water-proof.


1.Connector


2.0 HOST: External mobile equipment (Suppor

Micro-USB: Support OTG(for upgrading software)
HDMI: High Definition Multimedia Interface Outp

TF card slot :support expanded 2GB- 32GB TF card Reset: for upgrading software LED :Power indicator(blue), equipment start bright







5.2Bluetooth devices


local disk for this computer.


5.3 Ethernet setting


5.4 More Device


8. Airplay/DLNA/Miracast

Example: Xiaomi2S Click "settings"=>"enable WLAN"=>"Properties"=>WLAN Display "=>device










4.Main Screen Introduction



§ 15.19 Labelling requirements.

§ 15.105 Information to the user. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This device complies with part 15 of the FCC Rules. Operation is subject to the

following two conditions: (1) This device may not cause harmful interference, and (2)

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and

on, the user is encouraged to try to correct the interference by one or more of the

following measures:

-Consult the dealer or an experienced radio/TV technician for help.



5.Settings

5.14 Backup & reset



You can download QQ or skype (applied to Android 15.Question & Answer

 Screen flicker or unstable working : please check if the HDMI cable has been connected tightly.
 Cannot start device : please download FW file from Cloudnetgo official website: www.cloudnetgo.com still cannot be solved, please contact the distributor which you bought from.

• Keep restarting system automatically: please check if the device get enough power supply. Sometimes, external HDD cause power shortage. Please plug additional power supply for external HDD or other

14. How to use camera and microphone external devices,

Cannot find file in SD card or open drive: please check all the connection of the device. And make sure you have tick of SD and USB Host in "setting". (only for cr10s,cr11s)

16.Specification Quad-Core Specifications: Quad-Core Specifications: HDMI(Mate), Micro TF card , USB HDMI(Mate),Micro IF card ,USB host2,0,USB power port, LED(Blue)

CR10/S:DCSV.R.145,Optical.HDMI.AV OUT TF-Flash. 4+USB.MIC.IR.CAM.RESET.LED(Blue)

Accessory

HDMI cable ,USB power cable ,manual , USB power adapter

5.6 Sound Open Bluetooth devices, check the allow attachment search Bluetooth devices, the Bluetooth devices named If your family or office network need dial-up, then click PPPOE settings and input account and password. lume : Click to setup volume level for music, video RJ45 LAN cable, click "setting" → "More" cloudnetgo equipment, paired with a phone or other Bluetooth devices, after successful pairing will be transmitted via Bluetooth playback multimedia files to a "PPPOE setting" →input account and password. Screen lock sound: Click to open or close screen lock **5.7 Display**Font size: Click to setup system font size according This function user could exchange data between If there is no wireless and have to use cable to access internet. But first, you should buy a USB2.0 LAN Adapter and plug it on USB Host or OTG ports ,(Notice :the USB2.0 LAN Adapter supported is limited, please reference related type.)Connect RJ45 LAN Cable ,click "setting" — "More" — "Ethernet" —click "Use Ethernet". computer and player, then connect the player

and TV with HDMI cable;

2. Setting: After device access to the main screen, click settings "USB" —connect PC, Press confirm. After the device go to USB mode, press Turn on USB storage, Now your computer could find the device,

When connected internet, you could use the following

9.Web Browsing

name=>invite the device -=> connected=> ok
Samsung S3: "settings => Enable WLAN=>more
settings"=>"Allshare cast=> invite the device
=>connected=> OK.

Considering android habit, new opened page will
show on the webpage upper in the form of tag you
can click "+" and new webpage, or click " ×" close

2.Output Interface :Default HDMI
3.HDMI mode :User could set appropriate output resolution according to their television

10.Local audio & video playback

User can through file manager external TF card, USB flash drive and HDD box and playback the inside music, video, picture and files.

5.9ScreenShot Setting Select delay time to capture the screen Set the location of screenshot storage in flash

11.Use soft keyboard

would appear soft keyboard, if the equipm

Google

- q W e r t y u i o p

by Android system not visible. All the free space are the two visible areas(0.98GB INTERNAL STORAGE+1.60GB NAND FLASH=2.58GB). In this option , user could view installed and running apps, at same time Could check DDR parameters.

5.12 Security User can set password according to their needs. 5.13 Language & input

In this option, user could view local storage space and external storage space , besides, user could uninstall or format storage equipment.

Notice: System divided the whole storage into seven area

only two areas visible, the other five areas are taken up

12.Switch input methods

When you click any input box, you can setup your preference input methods, please click desktop

英语(美国) Android 键盘 (AOSP)

5:19 😵 8

and you can choose one of you prefer:

● 谷歌拼音输入法

5.10 Storage

1.User can set language for system menus according to their Country or preference(60

5.15 Add account 5.16 Date & time manual set date and time can't be saved, user can use

2. System default support Chinese and English, user need manual installing other input methods.

13.RK-RemoteControl

virtual keyboard, virtual remote control:

make sure the remote control device

RemoteControl can be achieved using Android phones

and the equipment plate interact with native remote control, touch, mouse models, remote control game,

a.First official website to download the remote Control

program (RK-RemoteControl), as well as installation instructions file, installed in your phone or Tablet PC. **b.**WIFI Connect :before you use this feature, first two

device (the device with your phone) connected to the same WIFI network, turn on the TV the eHomeMediaCenter icon in the toolbar, select set the

c.On phones or pad of the drive control program (RK-RemoteControl) when you open the application, software searches for the last time the user control the device,

automatic date & time, so when the device conne 5.17 Developer options USB debugging: when connected with PC exchange date need open this option; 5.18 About device This option show current system information display;

Backup: when you have very important files or apps, you'd better choose backup in case files lost.

Reset: when choose this option, and confirm, system will erase user's settings and all the apps missing and

apply default configuration immediately(Not sugges

rignten. SATA: when insert SATA HDD, fronts brighten other computer.

15. Question & Answer

• Start the program guide, Open microphone icon, Press

6.Explorer :Browse /copy Files

3: when plug-in USB device (HDD, U-disk), fronts

6.Explorer :Browse /copy Files

third-party apps .you could install or uninstall apps freely, there are two methods available install APPS: 7.1 Online installation

User could login built-in Google play store download Apps (User need have an G-mail account), user also could login android market download Apps or other market. After download system would prompt you install the Apps. 7.2 Local installation

7.Install/Uninstall Apps

User also could download Apps from computer , then copy to U-disk or TF card, insert the U disk or TF card to your device, then install from APK install or access to Explore find out the Apps then install.

Reorient or relocate the receiving antenna.

Increase the separation between theequipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.