# USER MANUAL Portable Mini Sound Bar



Chialstar Portable Sound Bar 21 Inch Mini Wireless Stereo 4\*6W Speakers Powerful TV Soundbar Bluetooth Speaker with Remote Control For Indoor and Outdoor

## 1. Introduction

Congratulations and thank you for choosing Our Chialstar Wireless Stereo Bluetooth Mini Sound Bar. This manual will help you operate the Mini Sound Bar.

Any problem please feel free to contact our after-sales service email:

# service@chialstar.com


## Safety Rules:

- (1) Please follow the instructions depicted in this manual closely to ensure your safety. Before using this Bluetooth Speaker, we would strongly encourage you to read through this user manual.
- (2) Do not modify, repair or dismantle this Bluetooth Speaker. Doing so may result in fires, electric shocks, complete breakdown of this Bluetooth Speaker, etc.
- (3) Do not use the Bluetooth Speaker in a hazardous location.

# 2. Package includes

Overview of Sound Bar and Remote Control

## 2.1 KEY



Previous: Short press " • " is for previous song/previous channel.

Next: Short press " • " is for next song/next channel.

Play/Pause: Short press to play when the device is pausing and press to pause when the device is playing.


Pairing: Short press (M) to change different mode (Bluetooth/FM), details refer to the next part.

Volume up: Long press " 🛨 " is for volume up.


Volume down: Long press"  $\bigcirc$  " is for volume down.

#### \*The remote control could realize these functions

## 2.2 REMOTE CONTROL



#### **2.3 SLOT**



# 3. Pairing

#### 3.1 Bluetooth:

- (1)Keep press the MODE button until the LED light blinks with "Bluetooth Mode"voice
- (2)Initiate Bluetooth of mobile phone/other devices
- (3)Select "Q5" (some mobile phone need to input PIN "0000" as password), and the speaker will automatically connect with your phone/ other devices

#### 3.2 FM Radio:

- (1)Keep press the MODE button until the LED light blinks with "FM Mode" voice (2)Short press @ to search FM channels
- 3.3 USB
- (1) Make sure the speaker has been switched on
- (2) Plug USB cable (Included) into the USB port of speaker
- (3) The speaker will get into "Aux In" mode automatically with "Aux In mode" voice

## 3.4 Micro SD

- (1) Before inserting Micro SD make sure the speaker has been switched on
- (2) Insert Micro SD into the slot, the speaker will get into "Micro SD" mode automatically with "Micro SD Mode "voice.

### 3.5 AUX IN

- (1) Plug 3.5mm audio cable(Included) into the 3.5 mm charging port of speaker; plug the other side of 3.5mm audio cable into the audio device (PC/MP3/MP4/Mobile phone)
- (2) The speaker will get into "Aux in" mode automatically with "Aux in mode" voice

# 4. Charging

This speaker uses a non-detachable built-in rechargeable battery. In order to prevent damage of the speaker, please do not remove the battery.

- (1)Before charging, make sure the speaker has been switched off.
- (2)Plug USB cable (Included) into the Micro USB port of speaker , plug the other side of USB cable into USB charging or other charging device; charging will be start and the red light remains blink on the speaker
- (3) The red light will be out when fully charged

<sup>\*</sup>The indicator light will flash quickly and have warning voice when sound bar on low battery

# 5. Technical Specifications:

Speaker Drivers: 4\*52mm Full frequency

Battery Capacity: 7.4V 4000 mAh rechargeable battery

Rated power:4\*6W Rated voltage: DC 5V

The audio Interface: 3.5cm Audio line The bluetooth specification: V4.1

Size:510\*55\*70 mm

#### Salient features:

Bluetooth music play: Bluetooth 4.1 stereo music playing with 4\*5W speakers and 2 passive radiators

FM radio with remote control: support auto scan the FM Channels

AUX In: work as the external speaker by connecting to the audio source of computer, mobile, PSP/MP3/MP4 etc

Support Micro SD: Support MP3/WMA/APE coding rate, micro SD card up to 32G

USB music player: Support MP3/WMA/APE coding rate

Remote control: Use the remote control to tune the different modes and functions.

# 6. Package content:

- 1\* Sound Bar
- 1\* User manual
- 1\* USB cable
- 1\* 3.5mm Audio cable,
- 1\* Remote control

#### Federal Communications Commission (FCC) Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generate, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

#### RF exposure warning

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

The equipment must not be co-located or operating in conjunction with any other antenna or transmitter.