WiFi Digital Photo Frame lets you view digital photos directly a your smart phone & memory cards. You will be able to sate a slideshow using multiple transition effects or display ne photo at a time. No computer, digital camera or cable connection is required. Important safety precautions

Always follow these basic safety precautions when using your WiFi Digital Photo Frame. This will reduce the risk of fire, electric shock and injury.

f you use a commercial LCD cleaning kit, do not apply to cleaning fluid directly to the LCD screen. Clean the LCD with the cleaning solution applied to the cleaning cloth. How to the Phone Application ----How to the WiFi Digital Photo Frame - 10 Specifications ----

t & stable to WIFI wireless network, small frame to ayback with rhythmic beat and video supported in

h-Definition (1280 x 800) Touchscreen, viewing photos ur own family members album, one WiFi Photo Frame ole for several binding accounts.

one APP account to bind several WiFi Photo Frames,

photos to all of binding frames in one time esign and various color available, the most sweetest derable weather forecast & Clock, practical functions for sensor makes the panel automatically adjust its brightness

Step 1: Plug in the power adapter.

If the WiFi is set to invisible, your can build the connection by Other Network and enter the WiFi name & password.

juage: Different languages for options. ntry: Different countries for options. Id: To adjust the media volume and notification volume, enable wick counts.



This option display system information of the frame.

Power Consumption ≤10W



