

Instructions

1. Q1 speaker power on

- 1. Connect with power (you should use the original adapter and charging cable to charge the speaker more than 8 hours before the first time turn on).
- 2. Press the power button 2 seconds, boot tone; at the same time the green light is constant on (When the speaker is charged, it turns red and slowly flash).

2. Bluetooth pairing with smart devices

Method one:

When the first time to use, the speaker will automatically enter the Bluetooth pairing mode after powering on (time lasted 15 seconds), the Bluetooth light flashes rapidly, release the Bluetooth button, and selecting the Bluetooth device named XPAC Q1, if pairing is successful, the Bluetooth light is always on.

Method Two:

When paired with a new smart device, press and hold the Bluetooth key until the Bluetooth light flashes quickly, release the Bluetooth button, open the smart device Bluetooth search options, selecting the Bluetooth device named XPAC Q1, if pairing is successful, the Bluetooth light is always on.

Method three:

Bluetooth speaker will automatically connect back to the last connected device, each speaker can memory to match 8 smart devices as maximum, and can connecting two at the same time.

3. Answer or hang up the phone (Bluetooth pairing successful state)

Answer: When the phone calls in, click the phone answer button to answer the call.

Refused to answer: When the phone is called, double-click the answer button to reject the call.

4. Set the cascade function

Activation: Double-click the Bluetooth button to activate the cascade mode.

Exit: Triple-click the Bluetooth button to exit the cascade mode.

5. Bluetooth speaker charging

When the battery is low, the red light blinks quickly and needs to be charged immediately, use the power adapter and the charging cable connect to the DC IN port for Charging.

Speaker charging, the red light slowly flashing.

When fully charged, the green light is on.

6. AUX interface

You can play music by inputting the audio signal through the AUX connector.

7. Reset button

When the device does not respond, press the reset button for 1 second, speaker reboot, reset successfully.

8. Other functions

Auto power off: Bluetooth speakers without any operation, after 15 minutes, the speaker will automatically shut down.

9. Precautions and safety warnings:

- To reduce the risk of fire or electric shock, do not expose this product to liquids or moisture.
- This product may not be splashed or sprayed with liquid. Do not place liquids containing objects on or near this product. As any electronic product, beware of splashing liquid into any part of the product. Contact with liquids may cause malfunction or fire.
- Do not place any flame (such as a lit candle) on or near this product.
- Do not subject the battery to mechanical shock.
- If the battery leaks, avoid touching the liquids with the eyes or skin. If already in case of contact, flush with plenty of water for the liquid contacted part, and contact with the doctor for advice.
- Do not use any chargers not specifically provided for this device.
- Do not charge the battery for a long time when it is not in use.
- After prolonged storage, the battery may need to be charged and discharged several times to get the best performance.
- The battery performs best when operated at room temperature (20 °C ~ 45 °C).
- The battery provided by the system is not a user-serviceable component. If there is any problem with the battery, contact the shop or authorized dealer.

Caution:

Never change the product without authorization, as this may affect the safety and reliability of the product and make the warranty become invalid.

Warning: Containing small parts may cause a safety case. Not suitable for children under 3 years of age to use.



Warning: This product contains magnetic materials that can affect the operation of implanted medical devices. Please consult with doctor.

Warning: Equipment should not be subject to water droplets or water splashes, do not put liquids containing objects on this product.

Warning: Only for the safe use of the area below altitude 2000m.

Note:

- This product label is located on the bottom of the product.
- This product must be used indoors. The use of this product outdoors, on cars, or on ships does not conform to the design or testing intent of this product.
- This product can only be charged using the power adapter provided in the product package.
- This product does not contain user-serviceable components. All maintenance questions, please contact authorized dealers and authorized retail stores. The Company hereby declares the complete declaration of conformity to which this product is strictly compliant. You can find it at: www.xpac.cn.



1. Telephone answering button /
Bluetooth pairing button /
Cascade function button
2. Increase volume key
3. Power button / Play / Pause
4. Decrease volume key
5. The microphone
6. AUX interface
7. Reset button
8. Micro USB charging interface

Package Contents:

1. Q1 speaker x 1
2. Micro USB charging cable x 1
3. Power adapter x 1
4. Warranty card / certificate x 1
5. Operating manual x 1

297mm

正面

210mm

2


3

Q1 Bluetooth portable speaker Operating Instruction

dedx

虚线为折叠线，不印刷

背面



正面
99mm

背面

After testing the product meets the technical standards, allowed to leave the factory.

Product Name: XPAC Bluetooth portable speaker

Product Type: Q1

Inspectors:

Inspection Date:

纸张材料厚度，
参照邮寄样品

140mm

Warranty card

We make sure that your XPAC device has been inspected at the factory, and that no defects have been found on the assembly. You have a one-year warranty from the invoice date (the date of purchase), products need to be repaired with an effective sales certificate and warranty card, in accordance with the following item for the warranty.

1. The warranty card and proof of purchase (sales invoices or machine bills) prove that the product was purchased from an authorized distributor or agent by Runhang (Hong Kong) Co., Ltd, and enjoy free maintenance and replacement service during the warranty period.

2. The product warranty does not apply to the following situations:

The cause of the malfunction of the product is not caused by improper use or negligence, such as impact, static or accident (flood, fire, external pressure, crashes, etc.) or natural disasters caused failure or damage.

3. Customer came to customer service center to get the repaired product, must show the counterfoil of the "REPAIR SERVICE ACCESS SLIP" and must be fulfilled in case (or repair card).

4. If the customer's repair request is a repaired product, the manufacturer has the responsibility to keep the replacement parts. Customer needs to keep "Customer Retention Document" for proof, if the customer has not come to any possible service due to customers receive products overdue, we will not undertake any possible loss due to customers receive products overdue.

* If product testing by customer service center to confirm the existence of the fault, and can be repaired, we will not charge for testing costs.

* The company has the final power of interpretation.

RESOURCES XPANDING (HK) LIMITED.

Warranty card

Number:

Hello, Thank you for choosing our products.
Please fill information in the space, and read the warranty policy.
You will enjoy one year warranty from the date of purchase.

User information:

Name	Region	Telephone
Mail		Postcode
Model and serial number		
Purchase voucher number		
Purchase date		
Dealer/store seal		

虚线为折叠线，不印刷