


Check your
local and state
hunting laws for
legal and recommended
use of electronic
game calls.

3 AA Batteries Included

LIMITED



Electronic Deer Call

Patent Pending

Estrus™ Bleats, Grunts, Snort-Wheezes and Rattling Horns

• Remote works from 60 yards (180 feet) • Compact, easy-to-carry, lightweight

• Straps to trees, posts, bushes, etc. • Teaching Tool • Water resistant

Replaceable batteries

Includes: Wireless Remote, Tree Strap, Batteries

All the advantages an electronic call can offer are yours with the C-DEER™. Place the e-DEER™ speaker set where you need the deer to go and set-up where you are concealed. The C-DEER™ remote works from as far as 60 yards (180 feet) away. Other electronic calls produce sounds that pale in comparison to the realism of the sounds of the e-DEER™. When you want an electronic call that actually "Speaks The Language®", you want the e-DEER™.

Speak The Language®,

Will Primos

Will Primos

IMPORTANT: Please read all instructions and warnings before using this product to ensure safe and proper use.

INSTRUCTIONS

Simply press the designated button for the distinctive deer sound that you want to reproduce.

EXERCISES


Grunt -A call made by deer to announce their presence. Make this call when trying to attract a buck into range by making the buck think there is another buck invading his territory.

Doe Estrus™ Bleats - Estrus™ bleats are made by adult does to tell bucks they are ready to breed. Repeat two to three times every 10-15 minutes.

Snort-Wheeze - The snort-wheeze is an especially aggressive sound. It is like one buck calling another buck out for a fight. The ultimate challenge call, especially during mating season.

Rattle - The sound of a dominant buck fight. Their antlers crashing together as they struggle. This tends to call other bucks in to join in the action. Use this call in conjunction with the snort-wheeze and kick the dirt and bushes to add realism to the fight.

FREE CATALOG IN USA 800-622-8076





Bleat LIMITED 180 DAY WARRANTY

Primos® Hunting Calls™ warrants the e-DEER™ to be free from defects in workmanship and materials, under normal use and conditions, for a period of 180 days from the original date of purchase. If service is required for any reason of any defect or malfunction during the warranty period, Primos® Hunting Calls™ will repair or replace it, at its discretion, with proof of purchase, without cost (except for a \$10.00 charge for handling, packaging and shipping).

For warranty or service information, service@primos.com or call customer service at

(601) 879-9323 ext. 147.

Check your local and state hunting laws for legal and recommended use of electronic game calls.

WARNING: Primos® game calls are so accurate that you might attract other hunters, as well as game. The user of this product assumes all risk of injury in association with the use of this product.







User Information

The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For a Class B digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the manual

The Federal Communications Commission Radio Frequency Interference Statement includes the following paragraph.

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 for the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate frequency energy and, if not installed and used in accordance with the instruction may cause interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to my to correct the interference by one or more of the following measures:

- -- Recrient or relocate the receiving antenna.
- --Increase the separation between the equipment and receiver.
- ... Connect the equipment into an outlet on a circuit from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio / TV technician for help.

