6018678

Ages 5+ 5 ans et plus

Long Range VALKIE-TALKIE Set ALKIES-TALKIES à longue portée

- How to Operate your Walkie-Talkie
 1. Open the battery cover and install a 9V battery, following the polarity markings.
- Turn the OFF/ON/VOLUME dial to the right to turn the unit on.
- Further adjust the OFF/ON/VOLUME dial to the desired volume level.
- 4. Press and hold the TALK button to talk. Release the button to receive a message.

Note: When speaking, hold the unit about 3" (7.5cm) away from your mouth. The best transmission and reception is achieved when the unit is held in a vertical position.

How to Use Morse Code

- 1. Ensure the unit is turned on.
- While pressing and holding the TALK button, press the MORSE CODE button and release for the desired length of time to send morse code.
- 3. Receive morse code message in the same manner as voice messages.

CAUTIONS:


- Your Walkie-Talkie has been fully adjusted prior to shipping. Do not touch the internal components (other than to replace the battery).
- When sound becomes weak, install a fresh battery
- After use, always ensure the OFF/ON/VOLUME dial is set to the OFF position.
- Only store the unit in clean, dry place.


WARNING: CHOKING HAZARD – Small parts, not suitable for children under 3 years.

AVERTISSEMENT : DANGER D'ÉTOUFFEMENT - Petites pièces, non recommandé pour les enfants de moins de 3 ans.

WARNING: Not suitable for children under three years of age as this toy is electrical and mechanical in nature.

AVERTISSEMENT : Jouet de nature électrique et mécanique non recommandé pour les enfants de moins de 3 ans





- Comment faire fonctionner vos walkies-talkies

 Ouvrez le compartiment de la pile et y insérer une pile de 9 V en respectant les symboles de polarité.
- Tournez le bouton OFF/ON/VOLUME vers la droite pour mettre l'appareil en marche.
- Par la suite, ajustez le bouton OFF/ON/VOLUME au niveau de volume désiré.
- Appuyez et maintenez le bouton PARLER enfoncé pour parler. Relâchez le bouton pour recevoir un message.

Remarque: Lorsque vous parlez, tenez l'appareil à une distance d'environ 3 po. (7,5 cm) de votre bouche. Les meilleures transmissions et réceptions sont atteintes lorsque l'appareil est maintenu en position verticale.

Comment utiliser le code Morse

- Assurez-vous que l'appareil est en marche.
 Tout en maintenant le bouton PARLER enfoncé, appuyez sur le bouton MORSE CODE (CODE MORSE) et relâchez-le lorsque le temps nécessaire s'est écoulé pour envoyer le code Morse désiré.
- Vous recevez des codes Morse de la même manière que les messages vocaux.

MISES EN GARDE:


- Vos walkies-talkies ont été ajustés avant l'expédition. Ne touchez pas les composants internes (autre que pour remplacer la pile).
- Lorsque le son s'affaiblit, installez une pile neuve.
- Après l'utilisation, assurez-vous toujours que le bouton OFF/ON/VOLUME se trouve à la position OFF.
- Entreposez toujours le produit dans un endroit



Distributed exclusively Orbyx Electronics, LLC 501 South Cheryl Lane, Walnut, CA 91789

Imported in Canada for/ Importé au Canada pour Orbyx Electronics, Concord, Canada, L4K 4M3

Manufactured in China



Each unit requires 1 x 9V battery (not included) / Chaque unité requiert une pile de 9 V (non comprises)



THE FCC WANTS YOU TO KNOW

Your vehicle or transmitter might cause TV or radio interference even when it is operating properly. To determine whether your vehicle or transmitter is causing the interference, turn off

your vehicle and release the transmitter's control levers. If the interference goes away, your vehicle or transmitter is the cause.

Try to eliminate the interference by:

Moving your vehicle and transmitter away from the TV or radio.
 If you cannot eliminate the interference, the FCC requires that you stop using your vehicle. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Industry Canada RSS-GEN

"Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device."

Industry Canada RSS-310
"The carrier frequency is 27.145 MHz, or 49.860 MHz. The RF output power is 5.3 mW." This device complies with the limits of standard RSS-310 issue 1.

LA FCC VEUT QUE VOUS SACHIEZ

Votre véhicule ou votre poste émetteur peut causer de l'Interférence à la radio ou au téléviseur méme lorsqu'il fonctionne correctement. Pour déterminer si le véhicule ou le poste émetteur est la cause de l'Interférence éteignez votre véhicule et relâchez ceste, le véhicule ou le poste émetteur en était le cause. Essayez d'éliminer l'Interférence : ur en était le cause.

 Éloignez votre véhicule et votre poste émetteur de la télévision ou de la radio.

Si vous ne pouvez pas éliminer l'interférence, la FCC recommande que vous cessiez l'utilisation du véhicule. Les changements ou les modifications apportés à cet appareil, non expressément approuvés par le parti responsable de la conformité, peut annuler le droit de l'utilisateur de faire fonctionner l'appareil.

Industrie Canada CNR-GEN

"L'utilisation de ce dispositif est autorisée seulement aux deux conditions suivantes : (1) il ne doit pas produire de brouillage, et (2) l'utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif."

Industrie Canada CNR-310

La fréquence porteuse est de 27,145 MHz ou 49,860 MHz. La puissance de sortie RF est de 5,3 mW. Ce dispositif est conforme aux limites des normes RSS-310, point 1, d'Industrie Canada.



LIMITED WARRANTY

Who is Providing This Warranty?

 Orbyx Electronics, LLC ("Orbyx"), as the distributor of this Wasaki[™] product (your "Product").

What Does This Warranty Cover?

 This warranty covers defects in materials or workmanship in your Product under normal use and conditions.

What is the Period of Coverage?

 This warranty covers your Product for 90 days from the original purchase date.

Who Is Covered?

 This warranty covers the original consumer purchaser. Coverage terminates if you sell or otherwise transfer your Product.

What Will We Do To Correct Problems?

 We will repair your Product or replace your Product with a new or reconditioned equivalent product, at our option.

How Do You Get Service?

- Call Orbyx TOLL FREE at 1-866-363-3059 for instructions for obtaining warranty service from Orbyx's authorized service providers.
- Or, return your Product directly to the retail store from which you purchased the Product.
- When you obtain service for your Product, you must provide a purchase receipt (or other proof of the original purchase date) and a description of the

What Does This Warranty Not Cover?

- This warranty DOES NOT COVER
- damage due to misuse, abuse, alteration, unauthorized repair, or accident (such as improper electrical current);
- damage due to "acts of God" (such as lightning) or other contingencies beyond our control;
- cosmetic damage;
- externally generated static, signal reception or antenna problems not caused by your Product; or batteries.
- This warranty also DOÉS NOT COVER, and in no case will we be liable for, any incidental damages (such as transportation costs to and from an authorized service

provider, or loss of time) or consequential damages (such as costs of repairing or replacing other property which is damaged, including tapes, discs, speakers not included with your Product or other accessories, or external electrical systems) resulting from the use of your Product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

 the above limitation or exclusion may not apply to you.
 Defacing the serial number, or using your Product for commercial or institutional purposes, voids this warranty.

Are There Other Warranties?

- There are no express warranties other than those expressed herein. Neither the sales personnel nor any other person is authorized to make any other warranties or to extend the duration of any warranties.
- ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY (AN UNWRITTEN WARRANTY THAT A PRODUCT IS FIT FOR ORDINARY USE). ARE LIMITED TO 90 DAYS. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

How Does State Law Apply?

 This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Distributed exclusively in the U.S. by Orbyx Electronics, LLC 501 South Cheryl Lane. Imported in Canada for/ Importé au Canada pour Orbyx Electronics, Concord, Canada, L4K 4M3

Walnut, CA 91789 Manufactured in China

For product support please contact www.orbyxelectronics.com or 1-866-363-3059

Pour le service à la clientèle, s'il vous plaît, visitez-nous sur le site Internet au www.orbyxelectronics.com ou appelez au 1-866-363-3059



Limited Warranty/Garantie Limitée U.S.A & Canada

@ 2005 ORBYX Electronics. All Rights Reserved.



LIMITED WARRANTY

ORBYX ELECTRONICS WARRANTY

ORBYX Electronics warrants that this product will be free from defects in materials and workmanship for a period ninety (90) days from the date of purchase. Within this period, simply take the product and your proof of purchase to any ORBYX Electronics store or dealer and the product will be repaired without charge for parts and labour. ORBYX Electronics reserves the right to charge for transportation. Any product which has been subject to misuse or accidental damage is excluded from this warranty.

This warranty is only applicable to a product purchased through ORB/X Electronics company owned stores and dealers and to a product that is presented for repair in a country where ORB/X Electronics offers the product for such which was a country where ORB/X Electronics offers the product for such which will war on the control of the product of such which will war out may have additional statutory rights which will vary under the laws of the various countries, states, province and other governmental entities in which ORB/X Electronics operates. This warranty is subject to all statutory rights you may have in the country of purchase.



GARANTIE LIMITÉE

GARANTIE ORBYX ELECTRONICS

ORBYX Electronics garantit ce produit contre tout vice de matière ou de fabrication pour une période de quatre-ving-dix (09) jours à compter de la date d'achat. Au cours de cette période, vous n'acce qu'à retourner le produit, accompagné d'une preuve d'achat, à tout magasin ou détaillant ORBYX Electronics où il sera réparé sans frais pour les pièces et la main-d'oeuvre. ORBYX Electronics se réserve le droit d'imposer des frais de transport. La garantie ne s'applique pas aux produits endommagés suite à un mauvais usage ou à un accident.

La garantie s'applique uniquement à un produit acheté dans un magasin de la compagnie ORBYX Electronics ou chez un détaillant ORBYX Electronics de à un produit vendu dans le pays oi l'on fait la demande de réparation au titre de la garantie. Bien que cette garantie n'accorde aucun droit particulier autre que ceux susmentionnés, vous pouvez avoir des droits statulaires additionnels qui varient selon le pays, l'état, la province ou l'entité gouvernementale où ORBYX Electronics exerce ses affaires. Cette garantie se conforme à tous les droits légaux que vous pourirez avoir dans le pays d'achat.



NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.