OFFROAD RACING BUGGY ACTION! I/10th Baja Raceı

ion. For use by ages 5 and up. perating Baja Racer.

ner Service, Toll Free 1-800-816-1135



PACKAGE CONTENTS











Transmitter

Rechargable Battery & Charger


Instructions





PRODUCT DESCRIPTION

whip antenna










Transmitter



BATTERY INSTALL/REPLACEMENT











Install 9 V battery with polarity as shown in battery box. Replace battery cover.

Remove battery cover on bottom

of controller.

3. Plug battery wire into car plug harness fully. 4. Replace battery hatch and fasten in place with screw driver.

Plug adaptor into AC power outlet as shown. 1. Attach battery pack to

adaptor as shown.






BATTERY USE IMPORTANT NOTES - PLEASE READ!

Battery Pack

•After charging, battery will be warm. THIS IS NORMAL! When car is not used, disconnect the battery from the car NEVER charge the battery longer than 6 hours. This will damage it! Charge battery for 6 hours the first two times. Subsequent charges take only 4 hours.

DRIVING YOUR BAJA RACER



Basic Operation

Make steering and throttle inputs slowly at first Turn power switches on both the car and the transmitter

Baja Racer works well on all surfaces.

WARNING!

- 1) Only operate your car on sidewalks and playgrounds but NOT on roads where traffic is present.
- 2) Avoid using your car outside when it is raining, snowing, thundering or in strong winds or other poor weather conditions

RECHARGEABLE NIMH BATTERY PRECAUTIONS

1) Charging the battery takes 4 hours approx.

The improper use of the controller batteries may cause excessive heat, battery leakage, explosion and damage or lead to injury. Please read the instructions below.

 Turn off power when installing or replacing batteries Only use alkaline batteries in transmitter

- Charger will not overcharge batteries.
- Only use supplied charger, others may damage batteries! Do NOT leave battery/charger unattended while charging!
- PLEASE READ THIS CAREFULLY BEFORE USING.
- When you are running your Baja Racer, always keep it in your sight. Keep your Baja Racer away from roads or other areas where you might collide with people, pets or cars. Avoid driving your Baja Racer under parked cares, etc.
- front or rear wheels. Keep your fingers, hair, face and clothing away from the spinning
- It is recommended that children should be under adult supervision when they are playing with the Baja Racer.

- Keep away from fire or hot and/or humid environments.

Do not disassemble the product.

- Do not start your Baja Racer when the fornt and rear wheels are unable to turn freely. Do not place any objects on the spinning wheels
- Please keep this toy from children under 5 years old.
- controller/transmitter: Other cautions when using the Baja Racer and its

 Do not short circuit or diassemble. Keep away from fire. Remove the batteries when the product is not in use. Please install the batteries with the correct polarity, as indicated by the +/- signs.

- If any batteries you are using start to leak, carefully remove them without letting them contact any part of the body, properly dispose of batteries and replace with fresh batteries.
- When other radio controlled products with the same
- frequency are used nearby, this may cause interference and your Baja Racer may not work properly.
- Do not bend, tear, strongly hit or drop the car, transmitter antenna shaft, or antenna wire.

FCC REQUIREMENT


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not nstalled and used in accordance with the instructions, may cause harmful interference to radio communications lowever, there is no guarantee that interference will not occur in a particluar installation.

the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning

- Increase the separation between the equipment and receiver.
 Consult the dealer or an experienced radio/TV technician for help.
- -Connect the equipment into an outlet on a circuit different from that to which the rec eiver is needed.

NOTE: Changes or Modifications not expressly approved by the party responsible could void the user's authority to operate this device.





Toll Free Hot Line: 800-816-1135 www.kidgalaxy.com
Kid Galaxy, Inc.
150 Dow Street,
Tower 2, Suite 425B
Manchester, NH 03101



Copyright 2012 @ Kid Galaxy,