

Zspire Metal Bluetooth Zspire Metal Bluetooth Mous□ Myst99

// instructions & warranty //

LIMITED LIFETIME WARRANTY ON METAL PARTS OF MOUSE:

PLASTIC AND ELECTRICAL PARTS ARE COVERED UNDER A 90 DAY WAR-RANTY. Zspire Technologies warrants to the original purchaser that its products are free from defects in materials and workmanship. This product has been designed in accordance with the highest traditional quality standards of craftsmanship, using high grade metals treated with special finishes. Thus, a mark, slight color variation, and/or other distinguishing characteristics afforded to the product over its lifetime due to its usage, is considered one of the product's prestigious features, making all of our mice unique, and making it hard to find identical products.

This warranty does not cover accidental damage, misuse, improper care or alteration, or acts of God, such as floods and earthquakes. This warranty lasts as long as the original owner owns the product. Coverage terminates if the original owner sells or otherwise transfers the product. Coverage does not extend to any physical damage made by the owner. Customer access to the internal operations of the product are limited by this warranty to the battery compartment and battery cover. Any additional intrusion into the product's inner operation will effectively void this warranty.

To report a warranty defect, please contact customer support at 1.877.891.6598. Please include your telephone number so that we may contact you. If, after inspection, we find that the product is defective in materials or workmanship, we shall, at no charge to you, repair or replace the product at our discretion, and return the product to you. You are responsible for shipping costs to Zspire Technologies but there is no charge for the inspection or the return postage.

Post-warranty, the customer may request a repair service for an applicable fee.

DISCLAIMER: ZSPIRE IS NOT LIABLE OR RESPONSIBLE FOR ANY CLAIM AS A RESULT OF INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY SORT RELATED TO YOUR USE OF THIS PRODUCT. THE MAXIMUM RECOVERY FOR ANY LOSS OR CLAIM IS LIMITED TO THE COST OF YOUR PRODUCT PURCHASE. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF EXCLUSION MAY OR MAY NOT APPLY TO YOU. TO THE EXTENT ALLOWED BY APPLICABLE LAW. COLORADO LAW CONTROLS ANY CLAIMS, AND THE EXCLUSIVE JURISDICTION AND VENUE FOR SUCH CLAIMS SHALL BE THE COURTS LOCATED IN THE STATE OF COLORADO IN THE COUNTRY OF THE UNITED STATES OF AMERICA. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS. WHICH YARY FROM STATE OF SCUOUNTRY TO COUNTRY.

HEALTH WARNING

Use of desktop computers, keyboards, computer mouse/accessories, etc., may be linked to serious injuries or disorders.

Use of a computer may cause occasional discomfort or pain in the hands, arms, shoulders, neck or other parts of the body. If you find that you experience symptoms such as persistent or recurring aches, burning sensations, discomfort, numbness, pain, stiffness, tingling, or throbbing SEEK IMMEDIATE PROFESSIONAL HELP FROM A QUALIFIED HEALTH SERVICES PROFESSIONAL. Musculoskeletal disorders (MSDs) such as carpal tunnel syndrome, tendonitis, tenosynovitis, and other conditions may initially present themselves with these symptoms, and are painful and sometimes permanently disabling disorders.

For more information on MSDs, or if you feel that you are suffering from MSD-related symptoms, SEEK IMMEDIATE PROFESSIONAL HELP FROM A QUALIFIED HEALTH SERVICES PROFESSIONAL

WARNING

To prevent potential injury, shock, or equipment damage:

- Do not immerse any part of this product in water or liquid.
- Do not spray liquid on the product.
- Do not use this product if it has sustained significant damage due to shock, impact, etc.
- Remove batteries before cleaning the product.

Any and all information is this document is subject to change without notice, including URLs and other internet/web-related information. Complying with all applicable copyright laws is the responsibility of the user. Without limiting the copyright rights, no part of this document may be reproduced, stored into a retrieval system, or transmitted in any form without the express written consent of Zspire. Zspire's patents, patent applications, trademarks, copyrights, or other intellectual property rights covering the subject matter of this document may be pending, etc. Except where noted in writing from Zspire, furnishing this document does not afford any license to the patents, etc., trademarks, or other intellectual property.

WILKOMMEN! YOUKOSO! BIENVENUE! WELCOME!

We congratulate you on your choice of Zspire's mouse with Bluetooth $^{\text{TM}}$ wireless technology. We are certain that you will enjoy the performance, precision, elegance, and mystique that the Zspire mouse will bring to your desktop for many years to come.

These instructions will guide you through the process of quickly engaging your Zspire mouse.

THE ZSPIRE MOUSE PRODUCT PACKAGE

The Zspire Mouse Product Package includes everything you need to get started and driving your new Zspire mouse. Enclosed, you will find:

- Zspire Mouse
- 2 AAA Batteries
- Instruction/Warranty Booklet
- Zspire Sticker

NOTE: Before boarding any aircraft, be sure to either remove the batteries or turn the Zspire mouse "off." The Zspire mouse may emit radio frequency (RF) energy similar to cellular telephones. More information is available in the Zspire Help (see below).

SECTION I: INSTALLING BATTERIES

Before your Zspire mouse is ready to drive, you will need to install the batteries. Your Zspire mouse uses two AAA batteries included.


Remove the battery cover. The battery cover is located on the bottom of the mouse.

Insert the batteries with the proper positive/negative configuration. Place the negative side of the battery (the non-pointy end) against the spring. Do not worry if the batteries do not exactly line up before you replace the cover. The battery cover has been designed to force the batteries into the proper configuration.

Replace the battery cover so the slot on the cover is closest to the lens of the mouse (otherwise you will have a difficult time replacing the batteries next time!)

The Zspire mouse is now ready for configuration and operation.

See the "Battery Precautions" section of this guide for additional information regarding the batteries for your Zspire mouse.



SECTION II: ZSPIRE MOUSE CONFIGURATION

- 1. Activate the Zspire mouse. To turn the Zspire mouse on, move the switch on the bottom of the mouse to the "On" position. The switch is located on the bottom of the mouse under the lens cover. The red laser light will be activated.
- 2. Follow the instructions for your Bluetooth adaptor to connect the mouse.
- 3. Configure your mouse and allow your computer to "see" it. To do so, use a pen or pin to depress the recognition button on the bottom of the mouse for five seconds (time varies from computer to computer).
- 4. If asked for a passkey, select Do Not Use a Passkey.
- 5. Drive it! You are on your way to enjoying the Zspire mouse.

Making it YOUR Zspire

For a customized driving experience, the Zspire mouse has several variable configurations that you may tailor to your preferences. You can set your mouse buttons to specialized commands, control the cursor speed, etc. and make the Zspire your own personalized mouse.

For WindowsTM, go to your Control Panel and select "Mouse Properties." The Mouse Settings window will appear. Select your particular settings according to your preferences.

Additional Product and Company Information

For more information on Zspire products and services, or for more specifics about the Zspire mouse, visit www.zspire.com.

SECTION III: TROUBLESHOOTING AND PRODUCT SUPPORT INFORMATION

The Zspire mouse is built to exacting specifications and as a truly enjoyable and elegant, yet functional and durable, accessory. Under normal operating circumstances, the mouse will operate and position a cursor up to thirty feet from the computer, though results may vary depending on potential interference from other devices that use a radio frequency. An optimum driving experience requires that the device be situated as far as possible from items that may interfere with its transceiver, including radios, microwave ovens, cordless phones, etc.

If the Zspire mouse is not functioning properly, please check that:

- The batteries were installed properly and contain a charge.
- The activation switch on the bottom of the mouse is set to "On."
- All Bluetooth instructions have been followed.

If conditions persist, refer to the Zspire Help or visit us at www.zspire.com for more information.

REGULATORY INFORMATION

The Zspire mouse has been tested to comply with FCC Standards for home or office use. It is not intended for use in machinery, medical, or industrial applications. Any change or modifications not expressly approved by Zspire could void the user's authority to operate the device.

To comply with FCC RF exposure requirements, the antenna must be installed by the manufacturer and no changes can be made. This product is for use with NRTL Listed (UL, CSA, ETL, etc.) and/or IEC/EN 60950 compliant (CE marked) Information Technology equipment. No serviceable parts included.

This device is rated as a commercial product for operation at $+41^{\circ}$ F ($+5^{\circ}$ C) to $+95^{\circ}$ F ($+35^{\circ}$ C).

OPTICAL MOUSE INFORMATION

User-observable light is 15 microwatts in normal operation.

Components of this product have been tested to comply with International Standard IEC 60821-1-1993/A2-2001. This product uses LEDs that are inherently Class 1.1-1993/A2-2001. This product uses LEDs that are inherently Class 1.

BATTERY PRECAUTIONS

- Keep batteries out of the reach of children.
- Insert the batteries in the proper direction as indicated by the positive (+) and negative (-) markings on the battery and battery compartment.
- Do not mix old and new batteries, or batteries of differing types (e.g., carbon and alkaline).
- Always remove old, weak, or discharged batteries properly and dispose of them in accordance with Local and Federal Disposal Regulations.
- Remove batteries if the product is not being used for an extended period of time.
- If a batteries leak, remove all batteries and recycle or dispose of them in accordance with the battery manufacturer's instructions and Local and Federal Disposal Regulations. Before inserting new batteries, thoroughly clean the battery compartment with a damp paper towel or follow the battery manufacturer's recommendations for cleanup. If fluid from the battery comes in contact with the skin or clothes, flush with water immediately.
- DO NOT INSTALL BATTERIES INCORRECTLY. Carefully observe the markings on both the device and the batteries themselves for the the positive (+) and negative (-) markings.
- Do not puncture, open, or mutilate the batteries.
- Do not heat batteries.
- Do not use a fire to dispose of batteries.

Product Disposal Information

Dispose of your Zspire mouse in accordance with Local and Federal Disposal Regulations.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications (including the antennas) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement: This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not

be co-located or operating in conjunction with any other antenna or transmitter.

// www.zspire.com //

P.O. Box 6356, Denver, CO 80206, U.S.A.