







3-42 NAVIGATION SYSTEM 3-43











### PART 3 NAVIGATION SYSTEM

3-52 NAVIGATION SYSTEM

# Adaptive volume control ON/OFF Press the desired setting button. 1 INFORMATION Adaptive Volume Control If the speed of the vehicle is over approximately 60 mi/h (100km/h), the volume level can be increased one level higher than the current level. If the speed of the vehicle falls under 60 mi/h (100km/h), the volume level will return to its original level. 1 INFORMATION • Display Traffic and Freview Provise Prov





displayed)

• The above list can be sorted by either

Distance (Default) or Category.

traffic details.



1. Press the Advanced button at No. 2.



3. The user can check points of accidents and traffic details.

(b) Changing Traffic Category

Traffic Information

Advances

2. After selecting the desired menu among the six menus, press the Done Dutton to save. Once returning to the previous List screen, the corresponding Category list will be shown and maintained until Category information is changed.

NAVIGATION SYSTEM 3-53



### PART 4 XM DATA

### XM Data mode

The XM Data Service is a paid membership satellite radio service which provides users with traffic, stock, sports, and weather information. However weather information is not supported for vehicles purchased in Canada. For information on registration or related content, please visit the XM radio website (www. xmradio.com).

### Entering XM Data mode

1. From the current location map screen within the navigation, press the XM DATA



2. The main XM data service screen will be displayed. Within the main screen, there are four categories of Traffic, Stocks, Sports and Weather.

## XM Data mode screen and

### Traffic data Service Information

- Automatic route recalculation (guidance) according to changes in traffic conditions.
- · Provides short-cuts for initially searched routes.
- + Displays increased detour distance and estimated driving times.
- · Displays icons by each traffic situation on the man
- 1. Route calculation by incorporating actual road traffic conditions
- . Incorporation of traffic information to route calculations is a user option which can be turned on or off by the user.

### 2. Displays Road Traffic situations

• RTM (Road Traffic Message) is a feature which displays symbols of icons for each type of road traffic condition, such as locations under construction, accidents, basic weather, and others on map locations based on Traffic information provided by XM.

### 3. Avoidance of locations where traffic situations have occurred.

• If a traffic situation occurs somewhere along the route, the route is recalculated to avoid such locations and an avoidance recalculation popup will be displayed.

### 4. Displays Traffic Event List


· A list providing details on accidents and an icon which will display the accident location are displayed. The user can view details by pressing on the list or move the map to the accident location by pressing on the accident icons.

### Stock Data Service Information

XM Stock data Service is a service which provides real-time updated information on the NYSE, NASDAQ, and AMEX (approximately 11,000 symbols).



- 1. Press the Stocks button to display the Search screen where symbols can be searched. Input the name of the symbol you wish to search and press the Ust button to show search results.
- 2. For symbols which you are interested in, press the <Favorites> icon to save the symbol as a part of <My Favorite>. Saved symbols can be viewed from the My Fovorites 1. Press the desired Sports button to view button on the Stock Main screen.



### Sport Data Service Information

This service provides real-time updated information on scores and schedules for major sports, such as NFL, NBA, NCAA Football, NCAA Basketball, NHL, MLB, NASCAR and



related sports information.

XM DATA 4-3

4-2 XM DATA

# PART 4 XM DATA

### 2. My teams

You can save teams which you are interested in as part of <My teams> to easily view related scores and schedules.

Within the <My teams> screen, teams can be added by pressing the Add button or deleted by pressing the button.





### Weather data Service Information

The Weather Service is a service which provides weather information updated every 5 minutes for your region.

The Weather Service includes Tabular Weather, Graphical Weather, Warnings and Advisories Services.

- 1. Tabular Weather Service
- Provides current weather information and weather information for the coming next three days for your region.

To change the region, press the Other City button and select the desired region.

- 2. Graphical Weather Service (Map button)
- This service provides weather information, such as Cloud, Fog, Rain, Snow, and Road
   Conditions on the Navigation map as symbols. Details can be viewed on specific regions by using the zoom in and zoom out features.

- 3. Warning and Advisories Service
- This service provides weather warnings and advisories, such as Tornado, Storm, Flood etc. as symbols on the Navigation map.
   Details can be viewed on specific regions by using the zoom in and zoom out features.

4-4 XM DATA

Operating voice command	5-2
Condition for voice command system	5-2
Basic operation for voice	
command control	5-2
Voice command Help	5-3
Setting up the voice command system	n 5-4
Setting voice Prompt ON/OFF	5-4
Speaker adaptation	5-4
Voice command list	5-6
Command list of Audio system	5-6
FM/AM Radio	5-6
XM Radio	5-7
CD	5-8
MP3	5-9
USB MP3	5-10
USB IMAGE	5-10
iPod	5-11
Others	5-11

Command list of Navigation system	5-12
Map	5-12
Destination	
Route	5-15
Others	5-16
Searching destination by	
voice command	5-19
Find address	5-19
Find nearest POI	5-20
Find nearest < POI name >	5-21
Destination POI by phone number	5-22
Find emergency <category></category>	5-23
Destination by address book	5-24
Previous destination	5-24
Previous start point	5-25
Go home	5-25
Destination by memory	
point <1 to 5>	5-25

### Operating voice command

# Condition for voice command system

Most of the functions within the Audio and Navigation system can be operated by voice. Please follow the following instructions for optimal voice recognition performance.

- Close all windows and the sunroof. The performance of the voice recognition can be improved if the environment of the car interior is guiet.
- Press the voice recognition button and say the desired voice command after the sound of the beep.
- The microphone is positioned above the driver so that voice commands can be spoken while maintaining a proper posture.
- Pronounce the voice commands naturally and clearly as if in a normal conversation.

# Basic operation for voice command control



 Press the Ka key on the steering wheel remote controller. A voice command window will be displayed on the lower side of the screen followed by a "Command please" system voice comment.

### 1 INFORMATION

The System voice comment "Command Please" will not be provided when the Voice prompt is turned OFF.

# GPS WELVS.Prv

Find Address
Find Registed POI

- ous destination)

  [9] [Voice command list], page 5-6.
- [Searching destination by voice command], page 5-19.

on the pop-up screen with a beep sound,

say the desired voice command (ex : previ-

If the exact command is not known, use the "Help" command to view the commands list in detail.

### 1 INFORMATION

Press the 1 key shortly to input a voice command from among the system voice comments. The system voice instruction comment will immediately terminate. When the 1 con changes into the 1 icon with a beep sound, input the desired voice command.

### Voice command Help

 Press the Key on the steering wheel remote controller. A voice command window will be displayed on the lower side of the screen followed by a "Command please" system voice comment.

### **1NFORMATION**

S N TOWNLINE DO SANDUSKY MI

**(1)** INFORMATION

0.8 second.

recognition system.

3. The inputted command is fed back to the

was not recognized properly, say "Back".

• The commands which can currently be

inputted are displayed on the screen in yel-

• To terminate the voice recognition system,

• Be aware that during the operation of the

voice recognition system, pressing the hard

keys or the screen will terminate the voice

either say "cancel" or press the 🦬 for over

screen and voice system. If the command

The System voice comment "Command Please" will not be provided when the Voice prompt is turned OFF.

Once the long icon changes into the long icon on the pop-up screen with a beep sound, say "Help". If the proper Help menu is already known, voice commands, such as "destination help" can be inputted directly.

### **1 INFORMATION**

The "help" command can be used even while voice recognition dialogue is operating. At such time, help instructions appropriate to the state of the dialogue will be provided.



Say the name of the desired menu.
 (ex: "Destination help")



4. Say the desired voice command.

5-2 VOICE COMMAND SYSTEM

inputted if the current state is already the screen.





sound, say "Speaker adaptation".



5. Listen and repeat the 20 commands

(approximate) as instructed by the device.

next letter

 Reset Speaker adaptation: Returns to previous state prior to applying Speaker adaptation. 1. Press the Makey on the steering wheel remote controller. 2. Once the 3 icon changes into the icon on the pop-up screen with a beep sound, say "Reset Speaker adaptation".

5-4 VOICE COMMAND SYSTEM

### Voice command list

The voice commands for this system are divid- FM/AM Radio ed into Global commands and Local com-

- Global command (●) : Commands which operate in all operating modes.
- Local command (○) : Commands which operate only when the corresponding mode is operating or when the mode screen to the corresponding mode is dis-

### Command list of Audio system

	Command	Operation
•	Radio	Plays the most recent frequency for the most recently operated band.
•	(Radio) AM	Plays the most recent frequency for the corresponding band.
•	(Radio) FM	Plays the most recent frequency for the corresponding band. In the case of FM, the most recent frequency within the most recently played FM1 or FM2 band is played.
•	FM <1 or 2>	Plays the most recent frequency for the corresponding band.
•	AM frequency <530 to 1710> (ex. AM frequency 1310)	Plays the desired AM band frequency.
•	FM frequency <87.5 to 107.9> (ex. FM frequency 99.1)	Plays the desired FM band frequency.
•	AM Preset <1 to 6>	Plays the desired AM band preset frequency.
•	FM <1 or 2> Preset <1 to 6>	Plays the desired preset frequency of FM1 or FM2 band.
0	Preset <1 to 6>	Plays the desired preset frequency for the current band.
0	Seek Up	Searches and plays the next frequency of the current band.

		Command	Operation
C	2	Seek Down	Searches and plays the previous frequency of the current band.
Ç	٥	Preset Up	Plays the next preset frequency of the current band.
Ç		Preset Down	Plays the previous preset frequency of the current.
0	0	Scan	Scans all frequencies within the current band.
(	0	Preset Scan	Scans the 6 preset frequencies of the current band.
0	0	Auto Preset / Auto Store	Searches all frequencies within the current band and stores the 6 frequencies with the most superior reception as preset buttons.

### XM Radio

	Command	Operation	
•	MX	Plays the last channel within the last band from XM1, XM2, and XM3.	
•	XM <1 or 2 or 3>	Plays the most recent channel for the corresponding Band.	
•	XM Channel <0 to 255>	Plays the desired XM band channel.	
•	XM <1 or 2 or 3> Preset <1 to 6>	Plays the desired preset channel for XM1 or XM2 or XM3 band.	
0	Channel < 0 to 255 >	Plays the desired channel of the current band.	
0	Preset <1 to 6>	Plays the desired preset channel of the current band.	
0	Channel Up	Plays the next channel of the current band.	
)	Channel Down	Plays the previous channel of the current band.	

5-6 VOICE COMMAND SYSTEM VOICE COMMAND SYSTEM 5-7

O Repeat track

Normal play

O Random

	Command	Operation	
0	Preset Up	Plays the next preset channel of the current band.	
0	Preset Down	Plays the previous preset channel of the current band.	
0	Scan	Scans all channels within the current band.	
0	Preset Scan	Scans all preset channels within the current band.	
CD			
	Command	Operation	
•	DISC	Plays the DISC already inserted in the CD Player.	
	CD	If the DISC inserted in the CD Player is either a CD or MP3 DISC, then the CD or MP3 will be played.	
•	CD track <1 to 665>	If the DISC inserted in the CD Player is a CD, then CD Mode will start and plays the desired track.	
0	Track <1 to 665>	Plays the desired track.	
0	Next track	Plays the next track.	
0	Previous track	Plays the previous track.	

Scans all tracks on the CD DISC.

Repeats the current playing track.

Plays the tracks of the CD DISC in random order.

Turns off the Scan, Repeat, and Random functions.


Comm	d Operation
DISC	Plays the DISC already inserted into the CD Player.
CD	If the DISC inserted in the CD Player is either a CD or MP3 DISC, then the CD or MP3 will be played
MP3	If the DISC inserted in the CD Player is an MP3 DISC, then the MP3 will be played.
Next file	Plays the next file.
Previous file	Plays the previous file.
Next folder	Plays the first file in the next folder.
Previous fold	Plays the first file in the previous folder.
Scan	Scans all files within the MP3 DISC.
Folder Scan	Plays all songs in the folder in which the current playing file is located for 10 seconds each.
Repeat File	Repeats the current playing file.
Repeat Folde	Repeats all tracks within the current playing folder.
Random	Plays all files within the MP3 DISC in random order.
Random Fold	Plays all files within the current playing folder in random order.
Normal play	Turns off the Scan, Repeat, and Random functions.

U	ıs	В	M	<b>P3</b>	

	Command	Operation	
•	USB	If the USB has been connected to the device, plays the MP3 files within the USB.	
0	Next file	Plays the next file	
0	Previous file	Plays the previous file.	
0	Next folder	Plays the first chapter of the next folder.	
0	Previous folder	Plays the first chapter of the previous folder.	
0	Scan	Scans all files within the USB.	
0	Folder Scan	Plays all songs in the folder in which the current playing file is located for 10 seconds each.	
0	Repeat File	Repeats the current playing file.	
0	Repeat Folder	Repeats all songs within the current playing folder.	
0	Random	Plays all files within the USB in random order.	
0	Random Folder	Plays all files within the current playing folder in random order.	
0	Normal play	Turns off the Scan, Repeat, and Random functions.	


### USB IMAGE

	Command		Operation
•	USB	If the USB IMAGE has been connected to the	
0	Next file	Moves to the next file.	
0	Previous File	Moves to the previous file.	



	Command	Operation	
•	Line in	Plays the unit connected with the AUX terminal.	
•	Audio on	Turns on the Audio/Video.	
,	Audio off	Turns off the Audio/Video.	

Command	Operation	
Map Current location	Displays the current position of the vehicle,	
Zoom In	Decreases the map zoom by one level.	
Zoom Out	Increases the map zoom by one level.	
Zoom minimum	Displays the map screen in the maximum zoom level.	
Zoom maximum	Displays the map screen in the minimum zoom level.	
Zoom level <1 to 14>	Displays the map in the zoom level selected from the 14 levels.	
Zoom <scale factor=""></scale>	Displays the map in the corresponding zoom.	
150 feet / 50 meters 300 feet / 100 meters 700 feet / 200 meters 0.25 miles / 400 meters 0.5 miles / 800 meters 1 mile / 1.6 kilometers 2 miles / 3.2 kilometers 4 miles / 6.4 kilometers 8 miles / 12 kilometers		



De			

	Command	Operation
•	Find address	Sets the destination through address search for route guidance.
,	Find nearest POI	Sets a POI near the current position as the destination for route guidance through POI category search.
	Find nearest <poi name=""></poi>	Sets a POI near the current position as the destination by directly inputting the POI name for rout guidance. $^{\circ}$ [POI Category list], page 5-17.
	Destination POI by phone number	Sets the destination by searching the phone number of the facility.
	Find Emergency <category> (ex. Find Emergency Hospital)</category>	Searches for an emergency facility which is nearby the current position and sets it as the destination for the guidance. Emergency facilities are police stations, hospitals, and dealerships.
	Destination by address book	Sets one of the list of previously registered addresses in the address book for the user as the destination.
,	Previous destination	Sets one of the previous destination as the current destination.
	Previous start point	Sets the previous start point as the current destination.
,	Go home	Sets the previously registered home address as the destination for route guidance.
,	Destination by memory point <1 to 5>	Sets a previously registered memory point as the destination for route guidance

Route

Command	Operation
Cancel route	Deletes the designated destination and terminates the route guidance.
Repeat voice guidance	Repeats the route guidance.
Detour <1 or 2 or 5 or 10> miles	Searches detour routes within a <1 2 5 10> mile radius.
Detour <1 or 2 or 5 or 10> kilometers	Searches detour routes within a <1 2 5 10> kilometer radius.
Replan recommended route	Recalculates the route with the recommended route,
Replan shortest route	Recalculates the route with the shortest route.
Distance to destination	Reports the remaining distance until destination by voice.
Time to destination	Reports the remaining time until destination by voice.
View route	If the destination has been set, displays the whole route screen until the destination.
Start guidance	Sets the scroll mark displayed on the map as the destination and starts route guidance.

POI Category list

All restaurants

Fast Food restaurant

American restaurant

French restaurant

Italian restaurant

Continental restaurant

Mexican restaurant

Japanese restaurant

Chinese restaurant

Korean restaurant

Seafood restaurant

Asian restaurant

African restaurant

Other restaurants

All automotive

Hyundai Dealership

Coffee Shop

Gas Station

Auto service

Road Assistance

Automobile Dealership

Parking

Rest Area

Vegetarian Food restaurant

Latin American restaurant

Car Wash

All Travel

Airport

Hotel

Motorcycle Dealership

Tourist Information

Tourist Attraction

Rental Car Agency

Campground

Ferry Terminal

**Bus Station** 

Local Transit

Train Station

All Shopping

Department Store

Convenience Store

Shopping Center

Music Store

Bookstore

Gifts shop

Grocery Store

Electronics Store

Hardware Store

Sporting Goods store

Travel Agent

City Cnter

Home Specialty Store

Clothing shop

All Recreation

Amusement Park

Sports Activities

Sports Complex

Video & Game Rental

Golf Course

Shoe Store

Pharmacy

Museum

Cinema

Winery

Bank

ATM

Ski Resort

Recreation Area

Other Recreation

All Financial Service

Check Cashing Service

Money Transfer

Business Facility

All Community

Police Station

Post Office

Library

Court House

City Hall

School

Civic Center

All Services

Photography

Medical Service

Funeral Director

Cleaning & Laundry

Communication services

Hair & Beauty

Social Service

Tailor & Alteration

Mover services

Physician

Tax Service

Attorney

Hospital

Dentist

Fire Department

Convention Center


Government Offices

Waste & Sanitary Utilities

### PART 5 VOICE COMMAND SYSTEM

O	th	er	S


	Command	Operation	
•	Voice guidance on	Turns the Voice Guidance On.	
	Voice guidance off	Turns the Voice Guidance Off.	
•	Voice guidance louder	Increases the Voice Guidance volume by 1 level.	
•	Voice guidance softer	Decrease the Voice Guidance volume by 1 level.	
•	Store marked location to <text tag=""> (ex. Store marked location to user 1)</text>	Registers the selected location into the selected Address book.	








5-22 VOICE COMMAND SYSTEM





position on the map.





1. Press the 1 key on the steering wheel remote controller.

2. Once the 1 icon changes into the 1 icon position on the map.

Select the desired location from the list and say the line command.

ex)"Find emergency hospital"

3. Select the desired user name(Address book

name).





73 N TOWNLINE RD. SANDUSKY, MI

selected position is desired, or say "Show" 3. Select the desired location from the list and

map" to verify the location of the selected say the line command.



selected position is desired, or say "Show map" to verify the location of the selected position on the map.

# **Previous start point** Sets the previous start point as the current remote controller.

Go home Sets the previously registered home address as the destination for route guidance.

1. Press the Kall key on the steering wheel 1. Press the Kall key on the steering wheel remote controller.

2. Once the o icon changes into the icon 2. Once the icon changes into the icon on the pop-up screen with a beep sound, say "Go home".



selected position is desired, or say "Show

map" to verify the location of the selected

on the pop-up screen with a beep sound,

say "Previous start point".

position on the map.

Destination by memory point <1 to 5> Sets a previously registered memory point as the destination for route guidance.

1. Press the M key on the steering wheel remote controller.

3. Say "Start guidance" if guidance to the 2. Once the 3 icon changes into the 1 icon on the pop-up screen with a beep sound, say "Destination by memory point 1".

VOICE COMMAND SYSTEM 5-25

5-24 VOICE COMMAND SYSTEM

5. Say "Start guidance" if guidance to the

position on the map.

### PART 6 BLUETOOTH® HANDSFREE

# PART 6 BLUETOOTH® HANDSFREE

Before using the Bluetooth	
Handsfree	6-2
What is Bluetooth?	6-2
Functions supported by	
Bluetooth Handsfree	6-2
Converting Bluetooth Handsfree	
mode	6-2
Converting from Audio/Navigation mode to	0
Bluetooth Handsfree mode	6-2
Converting from Bluetooth Handsfree	
mode to Audio/Navigation mode	6-3
Pairing and connecting a Bluetooth	
phone	6-4
Pairing a mobile phone	6-4
Deleting a paired phone	6-6
Connecting a mobile phone	6-7
Disconnecting a mobile phone	6-8

uetooth Handsfree screen layout 6-9	Operating menus during a call 6-14
uetooth Handsfree screen and	Switching call to the mobile phone 6-14
nctions 6-9	Activating Call waiting 6-14
When there is no mobile phone	Ending a call 6-15
connected 6-9	
When a mobile phone is connected 6-9	Phone Book 6-16
When receiving an incoming call 6-10	Making a call from the Phone book 6-16
When already on a call 6-10	Searching the Phone Book 6-17
When there is a call waiting 6-10	Searching by name 6-17
	Searching by number 6-18
aking a call 6-11	
aking a call by dialing a phone	Call History List 6-19
mber 6-11	Making a call from Call history 6-19
aking a call from Speed Dial 6-11	Sorting call history 6-19
aking a call by redialing 6-12	Dialed number 6-20
	Received number 6-20
nswering a call 6-13	Missed number 6-20
swering an incoming call 6-13	

# PART 6 BLUETOOTH® HANDSFREE

Phone Music 6-2
Before playing Phone music 6-21
Starting Phone Music 6-2
Phone music screen layout 6-22
Selecting Phone music files 6-2
Bluetooth settings 6-24
Pairing and connecting a mobile phone 6-24
Setting mobile phone auto connect
priority 6-24
Setting Handsfree volume 6-25
Setting Audio streaming 6-25
Advanced settings 6-26
Setting Contacts Auto Download (Sync)6-27
Searching and modifying my device
properties 6-27
Changing passkey 6-28
Deleting all paired phones 6-28
Initializing Bluetooth handsfree 6-29

Important information 6-3	0
About pairing mobile phones 6-3	0
About making/answering phone calls 6-3	1
About Bluetooth device environment 6-3	1
Mobile Phone Compatibility 6-3	2

BLUETOOTH® HANDSFREE 6-1

### PART 6 BLUETOOTH® HANDSFREE

### Before using the Bluetooth® Handsfree

### What is Bluetooth®?

- Bluetoothe allows wireless transmission of information between PC, mobile phones, headsets, PDAs, printers and other devices within • Downloading a Call history list close ranges by using 2.45Ghz frequency short- Playing music saved in a Bluetooth® phone distance wireless telecommunication technolo-
- free calls, transmit mobile phone data, and some mobile phone. play audio streaming files by connecting a mobile phone with the system.



**Functions supported by** Bluetooth® Handsfree

- Pairing mobile phones (Up to 5 phones)
- Connecting/disconnecting mobile phones
- Making/Answering phone calls
- Downloading a Phone Book
- in the vehicle

• Within this vehicle, users can make hands— Some functions may not be supported in

Converting Bluetooth® Handsfree mode

Converting from Audio/Navigation mode to Bluetooth® Handsfree mode



1. While in Audio mode or Navigation mode, press the PHONE key or the key on the steering wheel.



**Converting from Bluetooth** Handsfree mode to Audio/ **Navigation mode** 

1 2ABC 3 DE

4 GHI 5 JKL 6MNC

7PGRS 8 TUV 9WXY

END Del END \* 0 #

Contacts Private 🔅 Settings

2. The system will change to Bluetooth®

if no mobile phone has been connected.

Handsfree mode and display the PHONE



1. While in Bluetooth\* Handsfree mode, press an Audio/Navigation mode key, such as FM/AM or MAP VOICE



2. The corresponding mode will be displayed.

**1NFORMATION** 

Most of the functions of the Audio or SETUP modes are not supported while on a Bluetooth® Handsfree call. The call volume and Navigation (MAPVOICE, DEST, ROUTE) screens can be operated.

BLUETOOTH® HANDSFREE 6-3

6-2 BLUETOOTH® HANDSFREE

### PART 6 BLUETOOTH® HANDSFREE



Pairing a mobile phone



1. Press the Settings button on the PHONE screen.



2. Press the Pairings button on the Settings



displayed. Press the Add to button to pair a new mobile phone.

### **1NFORMATION**

For safety reasons, pairing a Bluetooth\* phone is not possible when the vehicle is in motion. Park the vehicle in a safe location to pair a new phone. It is possible to pair up to five when there are already five mobile phones While conducting a Bluetooth" device search paired, you must first delete one of the pre- from the mobile phone, operating to another viously paired phones.



3. The list of currently paired phones will be 4. From the Bluetooth® device list within the mobile phone, add the car handsfree. The default name of the car system is SONATA.

For more information on registering Bluetooth\* devices from the mobile phone, please refer to the mobile phone user's

screen will prevent the car handsfree from being found in the mobile phone. Always conduct searches for Bluetooth® devices with the Search Bluetooth® device screen displayed.



5. When pairing the car handsfree from the mobile phone, a passkey input window will become displayed on the mobile phone screen. Input the passkey set within the car system into the mobile phone input window. (The factory state passkey is 0000.) As shown in the figure, once the passkey becomes successfully inputted, the Bluetooth\* mobile phone will start.



6. Once Bluetooth® connection is successful the name of the connected mobile phone will become displayed on the PHONE screen and Bluetooth® handsfree functions

### **1** INFORMATION

Some functions may not be supported due to connection between the car system and 
limited Bluetooth® compatibility between the car system and mobile phone.

6-4 BLUETOOTH® HANDSFREE

BLUETOOTH® HANDSFREE 6-5