









VE

VE

3. The list of currently paired phones will be 4. The Bluetooth® connection between the car system and mobile phone will start.



[Pairing and Connecting a Bluetooth® phone 5. Once Bluetooth® connection is successful, the name of the connected mobile phone will become displayed on the PHONE screen and Bluetooth® handsfree functions will operate.

6-6 BLUETOOTH® HANDSFREE BLUETOOTH® HANDSFREE 6-7

Settings screen.



- 4. If the connection between the mobile phone and Bluetooth® fails, the following pop-up will be displayed. If problems occur while connecting Bluetooth®, check for the following conditions.
- Whether the mobile phone you wish to connect is in the vicinity of the car system
- Whether the power of the mobile phone Bluetooth® has been turned off
- Whether the mobile phone Bluetooth* has been set to hidden state.
- issues between the car system and another mobile phone

Disconnecting a mobile phone



1. Press the Settings button on the PHONE



Settings screen.



3. The list of currently paired phones will be displayed. Select the phone you wish to disconnect from the list and press the Disconnect button.



 Whether there are Bluetooth® compatibility
 2. Press the Connections button on the 4. pop-up asking whether you wish to disconnect the mobile phone will be displayed. Press the Yes button to disconnect the mobile phone and the No button to cancel.

Bluetooth® Handsfree screen layout

Bluetooth* Handsfree screen and functions

When there is no mobile phone connected



Settings: the user can set desired settings for the Bluetooth® handsfree, such as pair/ delete mobile phone, connect/ disconnect mobile phone, set call volume, change device name and change passkey.

When a mobile phone is connected



- 2 Phone battery charge status : displays the battery charge status of the connected mobile phone. The battery charge status may not be displayed in some mobile pho-
- 3 Signal strength : displays the mobile phone signal strength. The signal strength may not be displayed in some mobile pho-
- Bluetooth^e connection state: becomes displayed when a Bluetooth® phone has been connected with the car system
- 5 Name of connected mobile phone : displays the name of the connected mobile phone.

- 6 Phone number input window : displays the inputted phone number.
- Dial: input the phone number through the dial pad. 8 SEND : if a number has not been entered into the phone number input window.
- Pressing the send button displays the call history list screen. 9 Del : deletes the inputted number one
- digit at a time. 10 END: if a number has been inputted, then erases the entire number.
- ft Contacts: displays the phone book screen. The user can search previously saved phone numbers. The phone contact list may not be displayed in some mobile pho-

BLUETOOTH® HANDSFREE 6-9

6-8 BLUETOOTH® HANDSFREE











Press and hold (over 0.8 second) the SEND button on the PHONE screen or the key on the steering wheel.

1 INFORMATION

Redialing is not possible when there is no call history or the call history list is being down-loaded from the mobile phone. When there is no call history list, the SENO button will be inactive.

2. The recently called number is redialed.

1NFORMATION

It is not possible to display the Audio mode and Settings screen when on a phone call. Only the call volume and Navigation (MAPVOICE, DEST, ROUTE) screens can be operated.

Answering a call

Answering an incoming call



 The following screen will be displayed when you receive an incoming call.



 To answer the incoming call, press the Accept button or the key on the steering wheel.

Rejecting an incoming



 The following screen will be displayed when you receive an incoming call.




 To reject the incoming call, press the Roject button or the key on the steering wheel. The incoming call will be rejected.

1NFORMATION

Upon receiving a call, the [Reject] function may not be supported in some mobile pho-

ETOOTH* HANDSF

6-12 BLUETOOTH® HANDSFREE





1. If you wish to switch the call to the mobile phone while talking on the car handsfree. press the Private button or press and hold (over 0.8 second) the key on the steering wheel.



6-14 BLUETOOTH® HANDSFREE

Operating menus during a call 2. As shown, the call will be switched to the Activating Call waiting mobile phone.

1NFORMATION

If you wish to switch the call to the car handsfree while talking on the mobile phone, press the Use handsfree button or press and hold (over 0.8 second) the key on the steering wheel. The call will be switched to the car handsfree.

Phone	68 F	10 Test 1	_	
Daniel		2 _{ABC}	3 DEF	
2-345-6789-01:	4 GHI	5 JKL	6мно	
Timer: Call wa	7PQRS	8 TUV	9 wxyz	
Switch Del	END		0	#
Contacts Priv		vate	(B) N	lute

- 1. If another person calls while already on a call, the following screen will be displayed.
- 2. Press the Accept button or the key on the steering wheel to receive the incoming call by switching to the new caller.



3. To switch again to the other caller, press the Switch button or the key on the steering wheel. The other call will be received and the previous call will switch back to call waiting.

1 INFORMATION

Press the End button or the key on the steering wheel to end the current call and call waiting.



Contacts Private ® Mute 1. To end a call, press the End button or the key on the steering wheel.

D Del END * 0 #




2. The call will be ended.



일반문서/1608467/이황의/멀티설계1팀/2010-09-14 17:11 본 문서는 보안문서로서 외부 반출을 금합니다.






6-18 BLUETOOTH® HANDSFREE

PART 6 BLUETOOTH® HANDSFREE Dialed number Missed number

Call history TU Elisa TU Elisa TU Peter Dicied TU 2-34-676-9012 Rocelved | VI Henry Missed | VI Kote

1 INFORMATION



5-789-456-3212

Dialed | 1-789-456-1230

Issed TE 2-582-963-7411

Received number



Phone Music

Before playing Phone music

Music saved in the mobile phone can be played in the car through Bluetooth* audio streaming.

Phone music can be played only when a Bluetooth* phone has been connected. To play phone music, connect the Bluetooth* phone to the car system. For more information on connecting Bluetooth*, please refer to the user's manual [Pairing and Connecting a Bluetooth* phone].

If the Bluetooth* is disconnected while playing phone music, the music will be discontinued.

The audio streaming function may not be supported in some mobile phones.

Only one function can be used at a time between the Bluetooth® handsfree or Phone music function.

For example, if you convert to the Bluetooth* handsfree while playing Phone music, the music will be discontinued.

Playing music from the car is not possible when there are no music files stored in the mobile phone.

Starting Phone Music





 Repeatedly press the MEDIA key on the front panel or the MODE key on the steering wheel to enter Phone music mode.

6-20 BLUETOOTH® HANDSFREE

(1) INFORMATION

Each press of the MEDIA key on the front panel will change the function in the order of DISC → USB or iPod → AUX → Phone Music

Each press of the MODE key on the steering wheel will change the audio mode in the order of FM1 \rightarrow FM2 \rightarrow AM \rightarrow XM1 \rightarrow XM2 2. The Phone music screen is displayed. →XM3 → DISC → USB or iPod → AUX → Phone Music → FM1...

the mobile phone is not connected or if the automatically begin playing after converting audio streaming setting within Bluetooth* to the Phone music screen, this music player 2 File Down button : plays the previous handsfree settings has been set to [Disable function may not be supported in some mobistreaming audio).

For more information on audio streaming set
If music does not begin playing even after

4 File Up button: plays the next song.




1NFORMATION

le phones.

[Bluetooth* settings > Setting Audio strea- starting the music directly from the mobile phone.



- It is not possible to enter Phone music mode if While music saved in the mobile phone will 1 Information Bar : displays information for the currently playing song.
 - sona. 3 Play/Pause button: plays/pauses the song.



Selecting Phone music files



Phone music screen or the the system.

The previous or next song will be played each time the button or key is pressed.

1 INFORMATION

The file selection function may not be supported in some mobile phones.

6-22 BLUETOOTH® HANDSFREE BLUETOOTH® HANDSFREE 6-23







6-24 BLUETOOTH HANDSFREE 6-25




Setting Contacts Auto Download (Sync) **1NFORMATION** Searching and modifying my device • If Contacts Sync is turned ON, the contacts properties and call history in your mobile phone will automatically be downloaded to the vehicle each time you connect a Bluetooth® device. Delete all paired phones Restore factory settings 1.While in Advanced setup press the Contools Sync 1. Press the Device information button on the Advanced setup screen. Device Information 2. After turning Contacts Sync ON/OFF, press 2. Displays the Device information such as the name and address of the car system. To modify the device name, press the Change name button.

BLUETOOTH® HANDSFREE 6-27

6-26 BLUETOOTH® HANDSFREE





Important information

About pairing mobile phones

- Q. I cannot search for mobile phones through the car system. What is the cause?
- A: Check to see whether the mobile phone you wish to connect supports Bluetooth* function. If your mobile phone supports Bluetooth*, check to see that whether the Bluetooth* settings in the mobile phone have been set to hidden state or if the Bluetooth* power has been turned off. If the device has been set to hidden, release the hidden state and if the Bluetooth* power has been turned off, turn the power ON and try searching again.
- Q. What is the difference between pairing a mobile phone and connecting a mobile phone?
- Paring is the process of creating a secure communication connection between the mobile phone and the car Bluetooth* system.
- Through a two-way passkey between the car system and mobile phones, up to 5 mobile phones can be paired with the car system. The paired mobile phone will remain paired with the car system until the user deletes it manually.

 In addition, the call history lists and
- phone number books saved in each mobile phone will also be maintained until the paired phone is deleted. For more information on pairing mobile phones, please refer to the manual [Pairing and Connecting a Bluetooth* phone > Pairing a mobile phone].

Connecting a mobile phone to Bluetooth* by selecting the desired mobile phone from the paired phones. Within the car system, only one Bluetooth* phone can be connected at one time. For more information, please refer to the manual [Pairing and Connecting a Bluetooth* phone > Pairing a mobile phone].

Q. What is a Passkey?

 A. A passkey is an authentication code used for two-way communication of the car system and the mobile phone.
 Only 4-digit numbers can be used as pas-

Skeys. Passkeys are registered only once when pairing the phone number for the first time. The factory-set passkey is 0000.

About making/answering phone calls

- O. How can I answer a call?

 A. When you receive an incoming call, press
 the property button on the PHONE screen to
 answer. To reject the incoming call, press
 the property button on the PHONE screen to
 answer. To reject the incoming call, press
 the property button on the PHONE screen.
- What should I do if I am talking on the Handsfree but wish to switch the call to the mobile phone?
- A To switch the call to the mobile phone, press the PNOTE button on the PHONE screen or press and hold (over 0.8 second) the A button on the steering wheel. If you wish to switch the call back to the car handsfree, press the Note handsfree button on the PHONE screen or press and hold (over 0.8 second) the key on the steering

About Bluetooth device environment

- Q. What is the range for Bluetooth® wireless connection?
- A. The wireless connection range is within Aproximately 30 feet.
- How many mobile phones can be paired?
 It is possible to pair up to five phones with the car system.
- Q. What is the reason why the call quality deteriorates?
- A. First, check to see the signal strength of the mobile phone. The call quality may deteriorate when the signal strength is low. Call quality may also deteriorate if metal objects, such as drink cans, are placed near the mobile phone.

6-30 BLUETOOTH® HANDSFREE



A CAUTION!

Mobile Phone Compatibility

Depending on the manufacturer, product and product specification, some mobile phones functions may not be supported or may not operate to specification. Carefully read the cautions listed below.

- The occurrence of problems upon using mobile phones may be caused by the mobile phone and not by the Audio/Navigation Unit.
- Even mobile phones which support Bluetooth function may not operate properly if the mobile phone connection has been locked. Release the connection lock and try connecting the mobile phone with the system again.
- The Mobile phone battery icon and signal strength icon may not be properly displayed depending on the type of mobile phone.

- Call waiting is supported only when the connected mobile phones support this feature. The call waiting pop-up may not be displayed in some mobile phones.
- Audio streaming mode will operate only when a Bluetooth® phone has been connected. Connecting or disconnecting a Bluetooth phone while audio streaming is operating will stop music play.
- The audio streaming function may not be supported in some mobile phones.
- The phonebook may take a prolonged period of time to download or may not operate in some mobile phones.
- The quality of Bluetooth® handsfree calls may differ depending on the mobile phone.

6-32 BLUETOOTH® HANDSFREE

PART 7 **HYBRID**

About HYBRID	7-2
Entering the Hybrid mode	7-2
Hybrid Info Screens	7-2

HYBRID

HYBRID 7-1





1. Press the HYBRID key on the control panel. The most recently operated hybrid info

2. Hybrid is comprised of 4 Info screens of Earth, Car, Energy Flow, and Fuel Economy.

screen will be displayed.



Displays the engine, motor power delivery

state according to hybrid vehicle driving state

and 8-stage ECO driving information.

Hybrid Info Screens

ECO Level : Displays the 8-stage ECO driving state. 2 Engine: Displays the engine operating

> Motor: Displays the Hybrid electric motor operating state..

Engine Power: Displays the state of power delivery from the engine.

5 Motor Power: Displays the state of power delivery from the motor.



The ECO levels of Earth mode are displayed by stages in the following way. The stage increases according to economic and eco-friendly driving.







Displays the 8-stage ECO driving info during hybrid vehicle driving.

1 INFORMATION

The ECO levels of Car mode are displayed by stages in the following way.



2 Motor: Displays the Hybrid electric motor operating state. 3 Battery: Displays the Hybrid battery operating state and levels. Displays the power delivery flow between

Energy Flow

each component. • Green Line : Displays the power using


• Engine Displays the engine operating state.

Displays the power delivery state of each

component during Hybrid vehicle driving.

- electric power from the battery. White Line : Displays the power from the
- Blue Line : Displays the battery power and charging energy from the wheels.

HYBRID 7-3



7-2 HYBRID

PART 7 HYBRID

5 Displays the driving state of the Hybrid

(1) INFORMATION

The driving states of the Hybrid vehicle are as

Idle Mode

The vehicle is in a waiting state with no power delivery.



Hybrid Mode

The vehicle is being driven with simultaneous use of the engine and motor power.



Engine Mode

The vehicle is being driven through use of only the engine power.



Engine Mode Charging

The vehicle is being driven through use of only the engine power while the battery is being charged simultaneously



Idle MOde Charging(1)

The vehicle is in a waiting state while the battery is being charged through the engine



Charging HV Battery

The battery is charged by using the deceleration energy from the vehicle brakes.



Engine Brakeing

The vehicle speed is slowed by reducing engi-



Electric Mode



Electric Mode Charging

While charging the battery through the engine power, the vehicle is simultaneously driven through the motor power.



Idle MOde Charging(2)

The vehicle is being driven by using the motor
The battery is charged by using the decelerapower which uses the battery power. The — tion energy from engine power and vehicle



Engine Braking Charging

The battery is charged by slowing the vehicle speed by reducing engine power and simultaneously using deceleration energy.



7-4 HYBRID

HYBRID 7-5

PART 7 HYBRID PART 8 HVAC MODE **Fuel Economy 1NFORMATION** Displays fuel info during vehicle driving. • For the Fuel Economy Graph, improved fuel economy will change the graph from gray Cautions upon operating HVAC • Fuel economy info is reset upon turning off the vehicle ignition. HVAC mode screen layout **HVAC System operations...** Adjusting cabin temperature..... Adjusting the driver-side and passenger-side 1 Instantaneous Fuel Economy: Displays the temperature simultaneously 8-3 Adjusting the driver-side and passenger-side instantaneous fuel economy for current temperature separately 8-4 Setting fan direction Average Fuel Economy: Displays average 8-5 Setting fan level fuel economy from point of starting ignition until current time. 3 Fuel Economy Graph: Displays fuel economy info for the last 30 minutes. A new graph is shown every 2 and half minutes. @ Reset Button: Resets the displayed Instantaneous Fuel Economy, Average Fuel Economy and Fuel Economy Graph info. 7-6 HYBRID HVAC MODE 8-1

PART 8 HVAC MODE

Cautions upon operating HVAC mode

Upon operating the HVAC system, the display is as shown below.



1. Press the CLIMATE key to display the HVAC system status on the entire screen.



handsfree mode screen, press a HVAC key, such as TEMP AUTO , or A/C to display the HVAC system status bar at the top



2. When in the AV, Navigation, or Bluetooth" HVAC mode screen layout





- fan direction display : displays the set fan 2 Driver-side temperature display : displays
- the driver-side temperature. 3 AUTO display : displays whether the heating/cooling auto function is ON/OFF.

Airflow level and lonizer Display : displays the airflow level and ionizer state.

- 5 DUAL : upon turning on DUAL, the driverside and passenger-side temperature can be set separately.
- 6 Passenger-side temperature display : displays the passenger-side temperature. Displays the outside temperature.

HVAC System operations

Adjusting cabin temperature

1 INFORMATION

- Cabin temperature can be adjusted within a range of 17.5 °C ~ 31.5 °C in units of 0.5 °C .
- Setting the temperature below 17.5℃ will display the message "LOW" on the temperature display while setting the temperature above 31.5°C will display the message 1. Turn off the DUAL setting. "HIGH" on the temperature display.
- Although the driver-side and passengerside temperature can be set independently when the DUAL key is active, the temperature on both sides will be set simultaneously when the DUAL key is inactive.

Adjusting driver-side and passengerside temperature simultaneously





2. When adjusting the driver-side temperature with DUAL turned off, the passenger-side temperature will be set simultaneously.

8-2 HVAC MODE


HVAC MODE 8-3

PART 8 HVAC MODE



1 INFORMATION

When adjusting the passenger-side temperature, the DUAL setting will turn on automati- 1. Turn ON the DUAL setting. cally to allow the driver-side and passengerside temperatures to be set independently.







in DUAL ON state, the driver-side temperature can be adjusted separately.

1 INFORMATION

While adjusting the driver-side temperature, the DUAL key will turn be inactive when the driver-side temperature becomes set to LOW



1. Press the MODE key. The fan direction will



2. The changed fan direction will be displayed on the screen.





1. Press the > % A key. The fan level will be changed.








8-4 HVAC MODE

HVAC MODE 8-5



PART 9 PGS (Parking Guide System) PART 10 APPENDIX About PGS (Parking Guide Operating sequence of the PGS System) PGS System is a system which provides 1. Position the ignition key in ACC or ON. monitored parking guidance. Troubleshooting guide Before thinking the product has • The PGS will operate automatically when 2. Position the transmission lever to R. malfunctioned 10-2 the ignition Key is turned ON and the trans-Troubleshooting. . 10-3 mission lever is set to Reverse. The PGS will 3. The PGS mode will be displayed on the automatically stop operating when the transmisson shift lever is set outside of Map legend . 10-5 **1** INFORMATION Road color 10-5 POLicons 10-5 • The PGS (Parking Guide System) is an optio-Guidance track is as follows: Landmark icons 10-7 nal feature. • Red line - 1.64 feet from the rear bumper • Yellow line - 3.28 feet from the rear bumper Blue line - 9.84 feet from the rear bumper INDEX ... • Red line - Track following left side driver side wheel Yellow line - Track following right side passenger side wheel

APPENDIX 10-1

9-2 PGS (Parking Guide System)

PART 10 APPENDIX

Troubleshooting guide

10-2 APPENDIX

Before thinking the product has malfunctioned

- 1. Errors which occur during the operation or installation of the device may be mistaken as a malfunction of the actual device.
- 2. If you are having problems with the device, try the suggestions listed below.
- 3. If the problems persist, contact your HYUNDAI dealer.

Problem	Function		
There are small red, blue, or green dots on the screen	Because the LCD is manufactured with technology requiring high point density, a pixel deficiency or lighting may occur within 0.01% of total pixels.		
The sound or image is not working	Has the Switch for the vehicle been turned to [ACC] or [ON]? Has the SYSTEM been turned OFF?		
The video is being displayed but sound is not working	Has the volume been set to a low level? Has the volume been set on mute?		
When the power is turned on, the corners of the screen are dark	The display looking somewhat darker after prolonged periods of use is a normal phenomenon with LCD panels. It is not a malfunction. If the screen is very dark, contact your nearest HYUNDAI dealer for assistance.		
Sound is working from only one speaker	Is the position of FAL/BAL sound controls or volume adjusted to only one side?		
Sound and video does not work in AUX mode	Are the audio and video connector jacks fully inserted into the AUX terminal?		
The external device is not working	Is the external device connected with a standard connector cable?		
The road is missing	Some map data may be missing or incorrect.		
The road name is spoken incorrectly	The TTS (Text To Speech) engine speaks the street name based on the phonetic spelling. This will continuously be update with the map database.		

Troubleshooting

Problem	Possible Cause	Solution		
The power does not turn	The fuse is blown.	Replace with a suitable fuse. If the fuse is blown again, please contact your nearest HYUNDAI dealer for assistance.		
on.	Device is not properly connected.	Check to see that the device has been properly connected.		
XM only goes through one category	The XM mode is in category.	Press the mode button to change to channel mode.		
	The DISC has not been inserted or has been inserted upside down.	Insert the disc properly so that the sides are facing the correct direction.		
	The DISC has been contaminated.	Wipe dirt and other foreign substances from the DISC.		
The CD does not play.	The vehicle battery is low.	Charge the battery. If the problem persists, please contact you nearest HYUNDAI dealer for assistance.		
	A disc which is not supported by the device has been inserted.	Insert a disc which is supported for play by the device.		
The video does not work.	The brightness level has been set to the lowest level.	Adjust the brightness to a higher level.		
	The volume level is set the lowest level.	Adjust the volume level.		
The sound does not	The connector is not properly connected.	Check the connection.		
work.	The device is currently fast-forwarding, rewinding, scanning, or playing in slow mode.	The sound will not work when the device is fast-forwarding, rewinding, scanning, or playing in slow mode.		

APPENDIX 10-3

PART 10 APPENDIX

Problem	Possible Cause	Solution			
	The DISC is dirty or scratched.	Wipe off water or dirt from the DISC. Do not use a disc wh has been scratched.			
The sound or video quality is low.	Vibration is occurring from the position in which the conversion switch has been installed.	The sound may be short-circuited and the image distorted if the device begins to vibrate. The device will return to norm operation once the vibration has stopped.			
	The color and tone quality of the image is low.	Aging of the video display and deterioration in performance may cause certain quality degradations.			
	USB memory is damaged.	Please use after formatting the USB into FAT 12/16/32 format.			
	USB memory has been contaminated.	Remove any foreign substances on the contact surface of the USB memory and multimedia terminal.			
The USB does not work.	A separately purchased USB HUB is being used.	Directly connect the USB memory with the multimedia termin on the vehicle.			
	A USB extension cable is being used.	Use standard USB Memory,			
	A HDD type, CF, SD Memory is being used	Use standard USB Memory.			
	There are no music files which can be played.	Only MP3,WMA file formats are supported. Please use only the supported music file formats.			
	There are no titles which can be played.	Use iTunes to download and save MP3 files into the iPod.			
The iPod is not recognized even though it has been connected.	The iPod firmware version has not been properly updated.	Use iTunes to update the firmware version and reconnect the iPod with the device.			
it has been connected.	The iPod device does not recognize downloads.	Reset the iPod and reconnect with the device.			

Map legend		PO	licons						
Road color		No	Category	Sub Category	Icon	No	Category	Sub Category	Icon
Day Road Type	Color	1		Representation	0	16		Coffee Shop	0
Freeway	COIOI	2		Fast Food		17	Restaurants	Others	刊
Arterial		3		American	21	18		Representation	
County		4		French	7	19		Gas Station	QNS.
Collector		5		Italian	21	20		Parking	P
Local		6		Continental	62	21		Auto service	2
Unpaved local		7		Mexican	-	22		Road Assistance	160
Ferry		8	Restaurants	Japanese	71	23	Automotive	Hyundai Dealership	B
Night Road Type	Color	9		Chinese	7	24		Automobile Dealership	S
Freeway		10		Korean	2 () () () () () ()	25		Auto Parts	00
Arterial		11		Vegetarian Food	-	26		Rest Area	Rest Area
County	_	12		Seafood	(2)	27		Car Wash	
Collector		13		Latin American	-	28		Motorcycle Dealership	3
Local Unpaved local		14		Asian	8	29		Representation	
Ferry		15		African	*	30	Travel	Airport	8

10-4 APPENDIX

PART 10 APPENDIX **POlicons POlicons** No Category Sub Category Sub Category **Sub Category Sub Category Sub Category** 31 Music Store 61 32 92 2 . 62 Golf Course Library Medical Service 33 Travel Agent MA Court House Bookstore 63 Tourist Attraction 64 Video & Game Rental Funeral Director 35 Popular Spot Hardware Store 65 Ski Resort Hair & Beauty Shopping Rental Car Agency Cleaning & 51 Gifts Recreation Area 81 Community City Hall Campground Sporting Goods Other Recreation 2 Civic Center 97 Social Service Home Specialty Ferry Terminal 立 53 School Physician Bus Station Government Clothing 69 â Communication Local Transit 70 ATM Shoe Store Waste & Sanitary Alteration Train Station Mudanzas Utilities 42 Representation 73 43 Department Store 58 Museum 44 Shopping Convenience Store 74 Cinema Dentist 75 Police Station 0 -Sports Activities Photography

APPENDIX 10-7

10-6 APPENDIX

INDEX

10-8 APPENDIX

A	Before thinking the product has	Connecting AUX 2-2
About Bluetooth device environment 6-3		Connecting iPod device 2-2
About making/answering	Before using the Bluetooth Handsfree 6-2	Connecting the USB 2-2
phone calls 6-3	Bluetooth Handsfree screen and functions 6-9	Control panel1-
About pairing mobile phones 6-30	Bluetooth Handsfree screen layout 6-9	Controller and functions 1-
About PGS (Parking GuideSystem) 7-2	Bluetooth settings 6-24	Converting Bluetooth Handsfree mode 6-
Activating Call waiting 6-14	Wit.	Converting from Audio/Navigation mode to
Adaptive volume control ON/OFF 3-52	C	Bluetooth Handsfree6-
Adding to address book 3-27		Converting from Bluetooth Handsfree mode to
Adding waypoints 3-32		Audio/ Navigation mode 6-
Adjusting audio volume1-7	CD 5-8	Current position map screen
Advanced settings 6-20	CD screen and functions 2-14	(without route) 3-
Answering a call 6-13	Changing destination position 3-27	
Answering an incoming call 6-13	Changing passkey 6-28	D
Auto volume control ON/OFF 1-10	Changing Route option 3-32	Daylight Saving Time 1-1
AUX 2-29	Changing the map scale	Deleting a paired phone6-
AUX screen 2-29	Clock Type 1-12	Deleting all avoid areas 3-4
	Command list of Audio system 5-6	Deleting all paired phones 6-2
В	Command list of Help 5-18	Deleting an address book 3-4
Basic operation and setting 1-6	Command list of Navigation system 5-12	Deleting an address of address book 3-4
Basic operation for voice	Command list of Phone 5-18	Deleting avoid area 3-4
command control 5-2	Condition for voice command system 5-2	Deleting favorite place 3-5
BASS/MID/TREB 1-10	Conditions for voice recognition system 1-8	Deleting home address 3-4
Before playing Phone music 6-2	Connecting a mobile phone 6-7	Deleting waypoints 3-3

Destination	5-14
Destination by address book	5-24
Destination by memory point <1 to 5>	5-25
Destination menu screen and functions	3-12
Destination POI by phone number	5-22
Dialed number	6-20
Disc/Content format compatibility	2-12
Disconnecting a mobile phone	6-8
Display mode	1-11
Display ON	1-11
Display Photo Frame	1-13
Display setting	1-11
Displaying / Hiding POI icons on the map .	3-9
Displaying the list	1-7
Displaying/Hiding Q.POI icons	3-9
E	
Editing an address of address book	3-45
Editing avoid area	3-40
Editing waypoints	3-32
Ejecting a Disc	2-13
Ending a call	6-15
Entoring VM Data made	4.2

F	
FAD/BAL	1-9
Find address	5-19
Find emergency <category></category>	5-23
Find nearest <poi name=""></poi>	5-21
Find nearest POI	5-20
Finishing route guidance (Delete	
Destination)	3-30
FM/AM Radio	2-2
FM/AM Radio	5-6
FM/AM screen and functions	2-2
For safe and efficient operation	2-10
Functions supported by Bluetooth	
Handsfree	6-2
G	
Giving voice command	1-9
Go home	5-25
GPS signal reception state	., 3-2
GPS Time	1-12
Н	
Help	3-54
How to operate menu by voice command.	1-8

1	
Imp	ortant information 6-30
Imp	ortant information about this manual 1-2
Initia	alizing Bluetooth handsfree 6-29
Initia	alizing system 3-37
Inpu	tting letter by using screen keyboard 1-7
Inse	rting a Disc 2-13
Inse	rting/Ejecting Disc 2-13
ntro	oduction 1-2
Pad	5-11
iPod	screen and functions 2-23
Pod	* 2-22
L	
Land	dmark icons 8-7
Limi	tations of the navigation system 3-2
Liste	ening to CD music 2-14
Liste	ening to iPod music 2-22
Liste	ening to MP3 music 2-18
Liste	ening to the FM/AM radio2-2
	ening to the XM radio 2-6

APPENDIX

APPENDIX 10-9

INDEX

10-10 APPENDIX

M		0	POI Category list 5-1
Main setting	3-37	Operating after setting a destination 3-28	POI icons 8-
Making a call	6-11	Operating external devices 2-22	Precaution for safe usage1-
Making a call by dialing a phone		Operating menus during a call 6-14	Precautions upon handling discs 2-1
number	6-11	Operating sequence of the PGS 7-2	Precautions upon handling USB 2-2
Making a call by redialing	6-12	Operating the CD Player 2-10	Previous destination 5-2
Making a call from Call history	6-19	Operating the radio 2-2	Previous start point 5-2
Making a call from Speed Dial	6-11	Operating typical screen menu 1-7	
Making a call from the Phone book	6-16	Operating USB IMAGE Mode 2-31	
Making a call to POI	3-10	Operating Variable EQ 1-10	Received number 6-2
Map	5-12	Operating voice command	Registering avoid area 3-3
Map Functions	3-5	Others 5-11	Registering favorite place 3-4
Map legend	8-5	Others 5-16	Registering home address 3-4
Missed number	6-20		Registering new address in address
MP3	2-17	P	book 3-4
MP3	5-9	Pairing a mobile phone 6-4	Rejecting an incoming 6-1
MP3 disc related information and		Pairing and connecting a mobile	Re-ordering waypoints 3-3
precaution	2-17	phone 6-24	REW/FF CD track
MP3 screen and functions	2-18	Pairing and connecting a Bluetooth	REW/FF iPod song 2-2
My places setting	3-43	phone 6-4	REW/FF MP3 file 2-2
		Phone Book 6-16	Road color 8-
N		Phone Music 6-21	Route 5-1
Navigation setting	3-38	Phone music screen layout 6-22	Route Guidance 3-
		Playing AUX 2-29	Route guidance 3-3

Route guidance screen 3-28	Searching from MAP 3-26	Setting mobile phone auto
Route menu screen and functions 3-30	Searching POI by local POI list 3-26	connect priority 6-24
Route overview (View Entire Route) 3-31	Searching the Phone Book 6-17	Setting Q.POI icons
Route Re-calculation 3-4	Searching your Home 3-25	Setting Random function for CD music 2-15
	Selecting an iPod song 2-23	Setting Random function for iPod song 2-25
S	Selecting an item in a list1-8	Setting Random function for MP3 file 2-20
Scanning CD track 2-16	Selecting FM/AM broadcast frequency 2-3	Setting Repeat function for CD music 2-15
Scanning FM/AM broadcast frequency 2-5	Selecting other route 3-29	Setting Repeat function for iPod song 2-25
Scanning MP3 file 2-21	Selecting Phone music files 6-23	Setting Repeat function for MP3 file 2-20
Scanning XM broadcast channel 2-9	Selecting the CD track 2-14	Setting the Clock 1-12
Scrolling map 3-11	Selecting to MP3 music 2-19	Setting units (mile/ km) 3-38
Searching a Destination 3-13	Selecting XM broadcast channel 2-7	Setting up the voice command system 5-4
Searching a POI 3-20	Setting a destination 3-12	Setting voice command feedback
Searching a Previous Destination 3-17	Setting arrival time and distance	ON/OFF 3-37
Searching an Address 3-13	display 3-38	Setting voice Prompt ON/OFF 5-4
Searching an Intersection 3-17	Setting as Destination / waypoint 3-27	Setup and Information 3-36
Searching and modifying my device	Setting Audio streaming 6-26	Setup menu screen and functions 3-36
properties 6-27	Setting avoid streets on route 3-35	Sorting call history 6-19
Searching by number 6-18	Setting detour distance 3-35	Sorting items from list 1-8
Searching destination by voice	Setting Display OFF 1-13	Sound setting 1-9
command 5-19	Setting estimate travel time 3-42	Speaker adaptation 5-4
Searching favorite places 3-26	Setting Handsfree volume 6-25	Sport Data Service Information 4-3
Searching for Emergency facilities 3-25	Setting keyboard for inputting letter 3-37	Starting navigation system 3-5
Searching from Address book 3-24	Setting Language 3-37	Starting Phone Music 6-21

APPENDIX 10-11

INDEX

Starting Route Guidance 3-28	Turning the Power ON1-6
Starting USB IMAGE Mode 2-30	The same of the sa
Steering wheel remote controller 1-5	U
Stock Data Service Information 4-3	USB 5-10
Storing XM preset 2-9	USB IMAGE Mode 2-30
Supported disc formats 2-11	USB IMAGE mode menu screen
Switching call to the mobile phone 6-14	configuration 2-30
Switching map mode	USB MP3 2-26
(North Up / Heading Up)3-6	USB MP3 related information and
Switching the XM mode	precaution 2-26
(Channel / Category) 2-7	
System information and update 3-51	V
System Power ON 1-6	Variable EQ Setup (Optional) 1-10
	Vehicle position display 3-3
T	Viewing Current Time 1-12
Time Format 1-12	Viewing detail information for MP3 file 2-20
Touch screen beep ON/OFF 1-10	Viewing GPS signal state 3-7
Traffic data Service Information 4-2	Voice command Help 5-3
Traffic Information	Voice command list5-6
Traffic Setup 3-52	Voice guidance volume control 3-51
Troubleshooting 8-3	Voice guidance volume setting 3-51
Troubleshooting guide 8-2	
Turning the Audio ON/OFF 1-6	W
Turning the Power OFF 1-6	Weather data Service Information 4-4

 What is Bluetooth?
 6-2

 When a mobile phone is connected
 6-9

 When already on a call
 6-10

 When treeving an incoming call
 6-10

 When there is a call waiting
 6-10

 When there is no mobile phone connected
 6-9

 X
 X

 XM Data mode
 4-2

 XM Data mode screen and functions
 4-2

 XM radio
 2-6

 XM Radio
 5-7

 XM screen and functions
 2-6

Microsoft® Windows® Automotive Operating System

Important Safety Information Read and Follow Instructions

Before using your Windows Automotive-based system, read and follow all instructions and safety information provided in this end user manual ("User's Guide"). Not following precautions found in this User's Guide can lead to an accident or other serious consequences.

MS

Keep User's Guide in Vehicle

When kept in the vehicle, the User's Guide will be a ready reference for you and other users unfamiliar with the Windows Automotive-based system. Please make certain that before using the system for the first time, all persons have access to the User's Guide and read its instructions and safety information carefully.

Warning:

Operating certain parts of this system while driving can distract your attention away from the road, and possibly cause an accident or other serious consequences. Do not change system settings or enter data non-verbally (using your hands) while driving. Stop the vehicle in a safe and legal manner before attempting these operations. This is important since while setting up or changing some functions you might be required to distract your attention away from the road and remove your hands from the wheel.

General Operation

Voice Command Control

Functions within the Windows Automotive-based system may be accomplished using only voice commands. Using voice commands while driving allows you to operate the system without removing your hands from the wheel.

10-12 APPENDIX

MS

Prolonged Views of Screen

Do not access any function requiring a prolonged view of the screen while you are driving. Pull over in a safe and legal manner before attempting to access a function of the system requiring prolonged attention. Even occasional short scans to the screen may be hazardous if your attention has been diverted away from your driving task at a critical time.

Volume Setting

Do not raise the volume excessively. Keep the volume at a level where you can still hear outside traffic and emergency signals while driving. Driving while unable to hear these sounds could cause an accident.

Navigation Features

Any navigation features included in the system are intended to provide turn by turn instructions to get you to a desired destination. Please make certain all persons using this system carefully read and follow instructions and safety information fully.

Distraction Hazard

Some navigation features may require manual (non-verbal) setup. Attempting to perform such set-up or insert data while driving can seriously distract your attention and could cause an accident or other serious consequences. Stop the vehicle in a safe and legal manner before attempting these operations.

Let Your Judgment Prevail

Any navigation features are provided only as an aid. Make your driving decisions based on your observations of local conditions and existing traffic regulations. Any such feature is not a substitute for your personal judgment. Any route suggestions made by this system should never replace any local traffic regulations or your personal judgment or knowledge of safe driving practices.

Route Safety

Do not follow the route suggestions if doing so would result in an unsafe or illegal maneuver, if you would be placed in an unsafe situation, or if you would be directed into an area that you consider unsafe. The driver is ultimately responsible for the safe operation of the vehicle and therefore, must evaluate whether it is a safe to follow the suggested directions.

Potential Map Inaccuracy

Maps used by this system may be inaccurate because of changes in roads, traffic controls or driving conditions. Always use good judgment and common sense when following the suggested routes.

Emergency Services


Do not rely on any navigation features included in the system to route you to emergency services. Ask local authorities or an emergency services operator for these locations. Not all emergency services such as police, fire stations, hospitals and clinics are contained in the map database for navigation features.


Use of Speech Recognition Functions


Speech recognition software is inherently a statistical process which is subject to errors. It is your responsibility to monitor any speech recognition functions included in the system and address any errors.

10-14 APPENDIX

HMC GFE(YFE) [EN]AVN 매뉴얼 검토요청(2010.0910)







MEMO

10-22 APPENDIX

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum 20 cm between the radiator and your body. This transmitter must not be collocated or operating in conjunction with any other antenna or transmitter unless authorized to do so by the FCC.

IC Warning

Operation of this device is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.