
# NIER®



JH-BM667-1

Wireless headphone manual for two way radio

### **Product Introduction**

Wireless headphone is high end accessories for 2way radio headphone And it's connected to two way radio headset, two way radio and PTT with wireless dongle. It gets rid of defects for wire two way radio headset which is not so convenient for use, and it is suitable for various of occasion especially firefighting, forest defending, Military field, steeplejack, heavy industry and so on. Best Talent developed a wireless headphone for 2way radio with good quality for conversation and low rate design, is the best choice for professional communication purchaser.

### **Product Components**

Wireless headphone.(Diagram 1)

- 2. Wireless PTT(With 3M glue, hamulus fixed belt and strap) (Diagram 1)
- 3. Two way radio dongle (Diagram 1)
- 4. Chager (while charge for earphone, PTT and dongle)
- 5. Rubber case (suitable for PTT and Dongle) User Manual. Warranty card.




Diagram 1

### within 10m), After seconds, green indicator of both headset and dongle will flicker

1. Wireless connection between Wireless headphone, PTT and wireless

2. High frequency 2.4G wireless FHSS communication technology, avoid

Voice spring saving power circuit require lowest power and bring longer

4. dynamic voice compress technology, it makes voice more verisimilitude,

Wireless PTT, headphone and Wireless dongle are matched ready before

charger to charge for your wireless headset, wireless PTT and wireless

Switch on: Press switch on/off button of wirless donale for 3s until the

dongle over 6 hours. (with charge indicator), to assure it's working in

- Preparation: When you use the product for the first time, pls use

5. Automatic search mode, can connect automatically after temporary

donale, more convenient and freedom for using.

6. Simple button operation make more convenient using.

8. Wireless dongle suitble for most two way radio.

7. Built-in lithium Battery, with charge and low power indicator.

ex-factory, please follow up the following operation steps:

normal and connect wireless donglewith two way radio.

interference from two way radio, more reliable.

slowly, which indicates that the connection successfully. and they are in standby mode; (Diagram2)

wireless dongle and wireless headset is

green indicator flicker qusickly, and it's in

on two way radio power, about 5 seconds

standby mode. Then connecting

dongle with connect with the two

way radio which is power off. Switch

the green indicator for dongle flicker

quickly and step connected mode;

( PIs make sure the distance of

Product Features

conversation time.

disconnecting.

Operation

**Important Manual:** 

approach point 2), power consumpation is quite low. When the other side get call signal input and press PTT, the circuit automatically transfer to work states, the spring process takes about 200ms. When there's no calling within 2mins, the circuit will transfer to standby mode automatically and this will prolong working life time of the battery. 四、 Conversation: Wear wirless headset and wireless PTT. press wireless PTT, green indicator for wireless PTT and wireless dongle bright for long

Standby Mode: When headset and dongle are in standby mode(i.e.

time, it means PTT works normally, at this moment you start calling, pepole on the other side will hear voice. Release PTT.vou can hear response from the other side. Press VOC+VOC- button without grade to adjust volume control for long time.

Press PTT: the green indicator will bright for long time when you press PTT, release PTT, the green went out. Charge: When you charge it, the red indicator will turn bright for long time, after charging fully, the red indicator went out.Low power: Green indicator flicker slowly.

- 1. Wireless headset: press swith on/off/ button on wireless headset for long time until the green indicator go out and power off.
- 2. Wireless Dongle: pull out the connector for dongle or switch off two way radio power, Dongle will be automactically power off automatically within 5seconds.
- 六、Special function and operation:
- 1. Auotmatic Search mode: After connecting wireless dongle with wireless headset, when wireless headset is far away Dongle, the effective distance is more than 10 metres, wireless dongle will automatically step into searching mode, if the wireless headset back to effective distance 10metres within 5minutes, the wireless dongle will connect to automatically and working normally, if not, wireless dongle and headset will be both power off automatically and reduce the consumpation for energy of battery. (Whatever switch off automatically or manual, pls follow to the 2nd approach when vou switch on nex time.)

Lower power: the green indicator strobe tardily.

Charge: Red indicator bright for long time, when it's charge fully, the red

Receive the singal from PTT: the green indicator will be bright for long time.

Press PTT: the green indicator will bright for long time when you press PTT release PTT

Wireless dongle

Dimension: 45\*25\*10.5mm

Battery Compacity: 150mAh

Standby time: >30hours.

Sequence conversation: >8hours.

the green ndicator go out. Low power: RED indicator Charge:green indicator Charge fully:greent indicator go out.

Charge: Pls charge for headphone, dongle and PTT above 6hours before using the product. They power off automatically when it's in charging.



### Product Spec

Wireless Headset

Dimension: 60\*23\*14.5mm

2.Indicator Instruction:

1. Headphone/dongle:

Switch on/login:the green indicator flicker guickly

Standby: the green indicator flicker tardily Working: the green indicator flicker slowly

Wireless Headset

Working frequency: wireless 2.4GHz Working frequency: wireless 2.4GHz

Battery Compacity: 85mAh

Continuous coversation: >8hours.

Standby: >30hours.

Wireless PTT Dimension: 40\*25\*10.5mm

Working Frequency: wireless 2.4GHz

Battery compacity: 85mAh

### Mainteance and Warranty

It is adopt design waterproof design up to IP54 water proof standard, but pls avoid rain as possible as you can during the using. Also pls avoid threwing and don't use as weapons. Wireless PTT and adapter has been paired before ex-factory, if lose or damage, pls send back to the seller and after-sales service dept for new match.

ShenZhen Best Talent Technology Co., Itd MADE IN CHINA

## Warranty

Date Waranty Terms troubleman

1. User can enjoy waranty for one year according to three packs of regulations in china since buving (exclude take apart by yourself without permit from us, artificial factor and

2. After user buy this product, and you can go to the maintenance station we appointed by this warranty and invoice within one month, then transact register procedure.

outwards broken)

Note: Warranty factory must charge for user, pls carefully fill out waranty record as above when you repair.

wireless headphone

ime till the

Diagram2

Dongle

#### FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for and radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.