Wireless Memo Mouse User Manual

PRODUCT FEATURES

Model.:9865-W

- 1. Radio frequency 27MHz, enjoy your freely wireless space.
- 2. It has 256 ID code, there is no interference even many mice being used at the same time.
- 3. Automatically sleeping and manpower taking off dual functions, the battery life be prolonged.
- 4. No driver required for Win 98 / Me / 2000 / XP / NT / Vista or upper.
- 5. Memo pad and clip can be put in the inner tray inside the mouse. Memo pad size is 5.1 cm x 3.8 cm.






THE STEPS OF INSTALLBATTERY

- 1. Prepare for two pcs AAA batteries.
- 2. Open the battery cover under the mouse.
- 3. Insert the batteries correctly according to the polarity marks of the battery grooves.

RECEIVER INSTALLATION & ID SETUP

- 1. Connect the receiver to the USB port directly.
- 2. Move the mouse near to the receiver.
- 3. Press the ID button of the receiver. The receiver light begins to flash.
- 4. Press the ID button of the mouse bottom within 10 seconds. The receiver light will flash very fast in a few seconds.
- The light will be on which shows it is successfully connected and ready to use.
- 6. Working distance: within 1-2 meters.





ATTENTION

- 1. Please do not make the mouse far away from the receiver in order to work more smoothly.
- 2. You could better use the mouse on the white desk. In this way the batteries can be used for a long time.
- This mouse is with save power sleeping functions. Please press any key or scroll the wheel to wake up the mouse when it is sleeping.
- 4. If you want to take off the mouse power immediately, please continue to press the ID, switch of the mouse button at least three seconds.
- 5. The optical mouse will not work freely on a smooth desk, glass, any reflecting surface or 3D mouse pad.

CAUTION

Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with Part 15 of FCC RF Rules. Operation is subject to the following two conditions:

- 1) this device may not cause interference and
- 2) this device must accept any interference, including interference that may cause undesired operation of the device.