
lechnosonic

AST288A-1 DVD-PLAYER

WIRELESS 5.1CH HOME THEATER SYSTEM

DVD RECEIVER SYSTEM



INSTRUCTIONS MANUAL













IMPORTANT SAFETY PRECAUTIONS

- 1. READ INSTRUCTIONS- All the safety and operating Instructions should be read before the product is operated.
- 2. RETAIN INSTRUCTIONS-The safety and operating Instructions should be retained for future reference.
- 3. HEED WARNING- All warnings on the product and in the operating instructions should be adhered to.
- 4. CLEANING- Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol
- cleaners. Use a damp cloth for cleaning.

 5. WATER AND MOISTURE-Do not use this product near water for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool.
- 6. POWER SOURCES-This product should be operated only from the type of power source indicated on the marking label
- 7. LIGHTNING- For added protection of this product during a lightning storm, or when it is left unattended and unused for long periods of time: Unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.
- 8. SERVICING- Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

 9. DAMAGES REQUIRING SERVICE- Unplug this product from the wall outlet and refer servicing to
- qualified service personnel under the following conditions.
- When the power-supply cord orplug is damaged.
- If liquid has been spilled, or objects have fallen into the product.
- If the product has been exposed to rain or water.
- If the product does not operate normally when following the operating instructions. Adjust only those controls that covered by the operating instructions, as improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
- When the product exhibits a distinct change in performance- this indicates a need for service.
- 10.REPLACEMENT PARTS- When replacement parts are required. Be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result infire, electric shock or other hazards.
- 11. SAFETY CHECK-Upon completion of any service or repair to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.



PRECAUTIONS FOR DISCS

- To keep the disc clean, do not touch the play sides of the disc
- Do not attach paper ortage to the disc ō
 - Keep the disc away from direct sunlight or heat sources.
- Store the disc in a case after playback



ne lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the ser to the presence of uninsulated dangerous voltage within the products enclosure that may be sufficient magnitude to constitute a risk of electric shock topersons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance

- WARNING: To reduce the risk of fire or electric shock, do not expose this app
 - liance to rain or moisture. Dangerous high voltages are present
 - inside the enclosure. Do not open the cabinet.
- CAUTION:
 - The unit employs a laser system. To ensure the proper use of the unit, read this manual carefully and keep it for future reference. If the unit requires servicing, contact the seller or your service center. To prevent direct exposure to the laser radiation, do not open the cabinet. Visible laser may radiate when the cabinet is opened. Do not stare into the laser beam.

Use of any controls, adjustments, or procedures other than those specified herein may result in hazardous radiation exposure.

Changes or modifications to this unit not expressly approved by the party responsible for compliance will void the user's authority to operate the equipment. Any change to the equipment will void FCCgrant.

IMPORTANT SAFETY PRECAUTIONS

This equipment has been tested and found to comply with the limits for a Class $m{B}$ digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- --Increase the separation between the equipment and receiver.
- --Connect the equipment into an outleton a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


Normal operation should be possible within a distance of about 30m, but the presence of obstacles in between the transmitter and the wireless speaker may result in reception problems; such obstacles can be anything, but not limited to, certain types offurniture, constructions, wall materials, etc. Theradio waves may be disrupted by other electrical appliances operated in 2.4GHz.

SUITABLE DISCS


MARK	CONTENT	SIZE
DVD	Audio + Video	12 CM 8 CM
VIDEO™		8 CM
COMPACT COMPACT COMPACT Audio	Audio	12 CM
DIGITAL AUDIO	, , , , , , , , , , , , , , , , , , , ,	8 CM
CD-RW 3	Audio	12 CM
		8 CM
Kodak Picture CD COMPATIBLE	JPEG PICTURE	12 CM
		8 CM
CD-R	Audio + video	12 CM
CD-RW		8 CM
AM/tuner	AM/FM TUNER	
PRO LOGIC	This technology decodes source audio encoded in two-channel Surroundfor four-channel (Left/Center/Right/Surround) playback.	

REFERENCE DRAWING FOR FRONT /BACK PANEL

FRONT PANEL



- 2.Disc tray
- 3.Remote sensor
- 4. Display window
- 5. Open/close key
- 6.Play/pause key
- 7.Stop key
- 8. Function key
- 9.CH select
- 10.Master volume



- 1.front speaker R/L output
- 2. Center speaker output
- 3.Ant output
- 4. Subwoofer output
- 5. Video output
- 6.S-video output
- 7. Optical output
- 8. Coaxal output
- 9.AM antenna input
- 10.FM antenna input
- 11.Audio output
- 12.Aux input