


Two antenna connectors








One antenna connector





Page 3




Antenna 1: DQ661500301(Main) / DQ661500301(Aux)





Page 4







Antenna 2: 37LX6AATP00 (Tx1) / 37LX6AATP00 (Tx2)




Antenna 3: 37LX7AATP00 (Tx1) / 37LX7AATP00 (Tx2)




Page 6



Antenna 4: 3ASP8AATP20 (Tx1) / 3ASP8AATP20 (Tx2)




Antenna 5: 25.90675.001 (Rx) / 25.90676.001 (Tx)




Page 7



Antenna 6: 25.90669.001 (Rx) / 25.90670.001 (Tx)




Antenna 7: 3209970 (Rx) / 3210002 (Tx)




Page 8



Antenna 8: 25.90598.001 (Rx) / 25.90597.001 (Tx)




Antenna 9: 25.90587.001 (Rx) / 25.90586.001 (Tx)




Page 9



Antenna 10: 25.90653.001 (Rx) / 25.90654.001 (Tx)




Antenna 11: 25.90649.001 (Rx) / 25.90650.001 (Tx)




Page 10



Antenna 12: 024-01F0-2242 (Rx) / 024-01F0-2243 (Tx)




Antenna 13: 3176658 (Rx) / 3176674 (Tx)






Antenna 14: WDAN-L1WK1001-DF (Rx) / WDAN-L1WK1002-DF (Tx)




Antenna 15: HMT14-MAIN (Rx) / HMT14-AUX (Tx)





Antenna 16: 25.90700.001 (Rx) / 25.90702.001 (Tx)




Antenna 17: 25.90800.001 (Rx) / 25.90802.001 (Tx)




Page 13



Antenna 18: APM6P-700033 (Rx) / APM6P-700034 (Tx)




Antenna 19: 14G152168231LV (Rx) / 14G152168131LV (Tx)




Page 14



Antenna 20: APM6P-700027 (Rx) / APM6P-700029 (Tx)



Antenna 21: 2023940-1 (Rx) / 2023944-1 (Tx)




Page 15



Antenna 22: APM6P-700028 (Rx) / APM6P-700030 (Tx)




Antenna 23: 2023946-1 (Rx) / 2023950-1 (Tx)




Page 16



Antenna 24: LX-0980-11-000-R (Rx) / LX-0983-11-000-R (Tx)




Antenna 25: 3172525 (Rx) / 3172566 (Tx)




Page 17



Antenna 26: LX0970-11-000-R (Rx) / LX0968-11-000-R (Tx)




Antenna 27: WDAN-L1ML3001-DF (Rx) / WDAN-L1ML3002-DF (Tx)



Page 18



Antenna 28: 3172467 (Rx) / 3172509 (Tx)



Antenna 29: DQ6GC200100 (Rx) / DQ6GC200200 (Tx)






Antenna 30: DQ6GC300100 (Rx) / DQ6GC300200 (Tx)




Antenna 31: QADCPS1_WL_M (Rx) / QADCPS1_WL_A (Tx)






Antenna 32: QADCFL3 WL M (Rx) / QADCFL3 WL A (Tx)




Antenna 33: 25.90929.001 (Rx) / 25.90930.001 (Tx)






Antenna 34: 25.90934.001 (Rx) / 25.90935.001 (Tx)





Antenna 35: 25.90919.001 (Rx) / 25.90920.001 (Tx)







Page 23



Antenna 36: C-1334-11-000-26 (Rx) / C-1335-11-000-26 (Tx)



Antenna 37: 25.90979.001 (Rx) / 25.90980.001 (Tx)





Antenna 38: 81.EEO15.001 (Main) / 81.EEO15.002 (Aux)





Page 25



Antenna 39: 81.EHD15.003 (Main) / 81.EHD15.002 (Aux)





Page 26



Antenna 40: 81.EHD15.005 (Tx1) / 81.EHD15.004 (Tx2)





Antenna 41: 81.EHD15.004 (Main) / 81.EHD15.006 (Aux)





Page 28



Antenna 42: 81.EHD15.004 (Main) / 81.EHD15.007 (Aux)





Page 29




Antenna 43: 81.EHD15.G09 (Tx1) / 81.EHD15.G10 (Tx2)





Antenna 44: WDAN-M1WC1001-DF(Main) / WDAN-M1MM1001-DF (Aux)





Page 31




Antenna 45: SS-03-03-099 (Main) / SS-03-03-100 (Aux)







Antenna 46: WDAN-M1WC1001-DF (Main) / WDAN-M1BN1001-DF (Aux)





Page 33





Antenna 47: WDAN-M1NY1001-DF (Main)





Antenna 48: WDAN-M1PB1001-DF (Tx1) / WDAN-M1PB1002-DF (Tx2)







Page 35



Antenna 49: WDAN-M1SN1002-DF(Main) / WDAN-M1SN1001-DF (Aux)






Page 36



Antenna 50: WDAN-M1OS1001-DF (Main) / WDAN-M1OS1002-DF (Aux)






Page 37



Antenna 51: WDAN-M1WC1002-DF (Main) / WDAN-M1WC1001-DF (Aux)







Page 38



Antenna 52: HFT40 (Tx1) / HFT40 (Tx2)



Antenna 53: HFT60 (Tx1) / HFT60(Tx2)



Page 39




Antenna 54: WNC001 (Main) / WNC001(Aux)








Antenna 55: WNC002 (Main) / WNC002 (Aux)




Antenna 56: TBN001 (Main) / TBN001 (Aux)



Page 41



Antenna 57: TBN003 (Main) / TBN003 (Aux)







Page 42



Antenna 58: HBY07 (Tx1) / HBY07 (Tx2)




Antenna 59: HBY051 (Tx1) / HBY051 (Tx2)




Page 43



Antenna 60: HBY052 (Tx1) / HBY052 (Tx2)




Antenna 61: HBY061 (Tx1) / HBY061 (Tx2)




Page 44



Antenna 62: HBY062 (Tx1) / HBY062 (Tx2)





Antenna 63: HFT65 (Tx1) / HFT65 (Tx2)





Antenna 64: HCT01 (Main) / HCT01 (Aux)






Page 46



Antenna 65: WDAN-TQ (Tx1) / WDAN-TQ (Tx2)






Page 47









Antenna 66: TBN005 / TBN006





Page 49









Antenna 67: WNC004 (Main) / WNC004 (Aux)





Page 51







Antenna 68: TBN008 (Tx1) / TBN008 (Tx2)





Page 53



Antenna 69: TBN008 (Tx1) / TBN008 (Tx2)





Page 54



Antenna 70: TBN008 (Tx1) / TBN008 (Tx2)






Page 55




Antenna 71: TBN007 (Tx1) / TBN007 (Tx2)





Antenna 72: 03-FR021-016 (Tx1) / 03-FR021-016 (Tx2)






Page 57



Antenna 73: 81XCAE15.G07 (Main) / 81XCAE15.G08 (Aux)







Antenna 74: AMP8P-700130 (Main) / AMP8P-700131 (Aux)






Page 59



Antenna 75: WNC005 (Main) / WNC005 (Aux)




Antenna 76: MSA-00005A (Main) / MSA-00005A (Aux)




Page 60



Antenna 77: WNC003 (Main) / WNC003 (Aux)




Antenna 78: HFS23



Page 61



Antenna 79: HFS40





Antenna 80: TBN004 (Main) / TBN004 (Aux)





Page 63