

Part #: 3010105949

ASSY-PCB RFID FCC/RTTE

Revision Details					
Rev	Description	REA	Date	EC#	
Α	Initial Release	CS	02/07	10935	
В					
С					
D					
Е					
F					
G					

Table of Contents

Introduction	2
Required Materials	2
Jigs and Fixtures	
Tool List	
Supplies	
Assembly Steps	2

Introduction

This Assembly Instruction to detail the application of the FCC/IC label to the OIN 3010105499 RFID PCB and identify the new assembly as OIN 3010105949.

Required Materials

Jigs and Fixtures

None

Tool List

None

Supplies

Use the Panduit PanTher LS8 labeller.

Assembly Steps

- 1. Apply Label OIN 3010105893 to OIN 3010105499 RFID PCB as shown below:
- 2. Print and Apply Label to identify the new Assembly as OIN 3010105949 (RoHS Declaration DEC_VEN PANDUIT CORPORATION). Use the Panduit PanTher LS8 labeller.

