Resolution

RF245 Wireless Keychain Transmitter

User and Installation Instructions

Introduction

The RF245 Wireless Keychain Transmitter is a wireless 4-button transmitter for security system control. Typical use of this device is for arming and disarming the system, as well as control of lights and other devices. The transmitter's button layout is shown in Figure 1.



Figure 1: RF245 Button Layout

In order to eliminate the possibility of false activations, buttons on the transmitter must be pressed for at least ½ second before the transmitter activates. Successful activation of the transmitter is indicated by a short, bright LED flash.

The Wireless Keychain Transmitter uses a small alkaline battery, designed to provide long battery life.

Transmitter Programming

Each RF245 Wireless Keychain Transmitter is shipped with a unique serial number pre-programmed into the transmitter. Upon installation, the RF245 must be programmed into the security control panel. Each button on the RF245 may be programmed for a different function, or "loop", on the control panel. The control panel's documentation should be consulted for full instructions.

Specifications

Dimensions: 1.3 x 2.35 x 0.5"

RF transmission frequency: 345MHz

Operating Temperature: 10° to 120°F (-12° to 49°C)

Battery Type: 27A 12V alkaline

FCC Notice

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference that may be received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the Resolution Engineering, LLC could void the user's authority to operate this equipment.

FCC ID: U5X-RF245